MODEL IDENTIFICATION AND SPECIFICATION CHART

Engineering Symbol	Model Code	Year Built	U. S. Government Registration Nos.	U. S. Government Contract No.	Rate Type Wh'l Base	Starting Serial No.	Finished Serial No.	No. Built	TYPE BODY	Individual Parts List No.	Technical Manual No.
T202	VC-1	1940	W-205790 to W-206259	W-398-QM-7739	½ T 4x4 116	8643462		470	Command Reconnaissance	D-9249	—
T202	VC-1	1940	W-206260 to W-206471	W-398-QM-7899	½ T 4x4 116	8644348		212	Command Reconnaissance	D-9381	—
T202	VC-1	1940	W-204249 to W-205721	W-398-QM-7500	½ T 4x4 116	8640001		1473	Command Reconnaissance	D-9147	—
T202	VC-2	1940	W-601426 to W-601454	W-398-QM	½ T 4x4 116	8643462		29	Radio	D-9249	—
T202	VC-2	1940	W-60430 to W-60434	W-398-QM-7500	½ T 4x4 116	8640001		5	Radio	D-9147	—
T202	VC-3	1940	W-24146 to W-24506	W-398-QM-7739	½ T 4x4 116	8643462		179	Closed Cab Pickup	D-9249	—
T202	VC-3	1940	W-22134 to W-24111	W-398-QM-7500	½ T 4x4 116	8640001	8644641	637	Closed Cab and Pickup	D-9147	—
T202	VC-4	1940	W-24112 to W-24113 W-00278 to W-00279	W-398-QM-7500	½ T 4x4 116	8640001		4	Closed Cab Pickup Without Troop Seats	D-9147	—
T202	VC-5	1940	W-24146 to W-24506	W-398-QM-7739	½ T 4x4 116	8643462		182	Open Cab and Pickup	D-9249	—
T202	VC-5	1940	W-22134 to W-24111	W-398-QM-7500	½ T 4x4 116	8640001		1342	Open Cab and Pickup	D-9147	—
T202	VC-5	1940	W-22134 to W-24111	W-398-QM-7899	½ T 4x4 116	8644348		83	Open Cab and Pickup	D-9381	—
T202	VC-6	1940	W-205696 to W-205719	W-398-QM-7812	½ T 4x4 116	8643462		24	Carry All	D-9249	—
T203	VF401	1940	W-313605 to W-317173	W-398-QM-7471	1½ T 4x4 143	8827101		3122	Closed Cab and Cargo	D-9068	—
T203	VF402	1940	W-313605 to W-317173 W-317497 to W-317540	W-398-QM-7471	1½ T 4x4 143	8827101	8831036	431	Closed Cab with Winch	D-9068	—
T203	VF403	1940	W-317174 to W-317496	W-398-QM-7471	1½ T 4x4 143	8827101		323	Closed Cab and Dump Body	D-9068	—
T203	VF404	1940	W-317911 to W-320374	W-398-QM-7813	1½ T 4x4 143	8831038		1956	Closed Cab and Cargo	D-9250	—
T203	VF405	1940	W-317911 to W-320374	W-398-QM-7813	1½ T 4x4 143	8831038	8833572	509	Closed Cab and Cargo with Winch	D-9250	—
T203	VF406	1940	W-320375 to W-320441	W-398-QM-7813	1½ T 4x4 143	8831038		67	Closed Cab and Dump	D-9250	—
T203	VF407	1940	W-71074 to W-71076	W-398-QM-7813	1½ T 4x4 143	8831038		3	Ambulance	D-9250	—
T207	WC-1	1941	W-24615 to W-25789	W-398-QM-8039	½ T 4x4 116	8644701		1175	Closed Cab with Express Body and Longitudinal Seats	D-9589	—
T207	WC-1	1941	W-25792 to W-27189	W-398-QM-8286	½ T 4x4 116	8644701		1398	Closed Cab with Express Body and Longitudinal Seats	D-9589	—
T207	WC-3	1941	W-27190 to W-29999 W-210000 to W-214671	W-398-QM-8286	½ T 4x4 116	8644701		7482	Flat Face Cowl with Express Body and Transverse Seats	D-9589	—
T207	WC-3	1941	W-215536 to W-215861	W-398-QM-8286	½ T 4x4 116	8644701	8666216	326	Flat Face Cowl with Express Body and Transverse Seats	D-9874	—
T207	WC-4	1941	W-214672 to W-215418	W-398-QM-8286	½ T 4x4 116	8644701		747	Flat Face Cowl with Express Body—Transverse Seats and Winch	D-9589	—
T207	WC-4	1941	W-215862 to W-216056	W-398-QM-8286	½ T 4x4 116	8644701		195	Flat Face Cowl with Express Body—Transverse Seats and Winch	D-9874	—
T207	WC-4	1941	W-217349 to W-221976	W-398-QM-9140	½ T 4x4 116	8666301	8676719	4628	Flat Face Cowl with Express Body—Transverse Seats and Winch	D-9953	—
T207	WC-5	1941	W-001332 to W-001391	W-398-QM-8286	½ T 4x4 116	8644701	8666216	60	Closed Cab with Express Body—Less Seats	D-9589	—
T207	WC-6	1941	W-206490 to W-209867	W-398-QM-8286	½ T 4x4 116	8644701		3378	Reconnaissance	D-9589	—
T207	WC-6	1941	W-2010913 to W-2015119	W-398-QM-8286	½ T 4x4 116	8644701		4207	Reconnaissance	D-9874	—
T207	WC-6	1941	W-2020437 to W-2022216	W-398-QM-9140	½ T 4x4 116	8666301	8676719	1780	Reconnaissance	D-9953	—
T207	WC-7	1941	W-2010209 to W-2010500	W-398-QM-8286	½ T 4x4 116	8644701	8666216	292	Reconnaissance with Winch	D-9589	—
T207	WC-7	1941	W-2015244 to W-2015297	W-398-QM-8286	½ T 4x4 116	8644701		54	Reconnaissance with Winch	D-9874	—
T207	WC-7	1941	W-2022217 to W-2023308	W-398-QM-9140	½ T 4x4 116	8666301	8676719	1092	Reconnaissance with Winch	D-9953	—
T207	WC-8	1941	W-60473 to W-60479	W-398-QM-8038	½ T 4x4 116	8644701	8666216	7	Radio Body	D-9589	—
T207	WC-8	1941	W-605100 to W-605304	W-398-QM-8286	½ T 4x4 116	8644701		205	Radio Body	D-9589	—
T207	WC-8	1941	W-606021 to W-606356	W-398-QM-9140	½ T 4x4 116	8666301	8676719	336	Radio Body	D-9953	—
T207	WC-9	1941	W-71077 to W-71973	W-398-QM-8286	½ T 4x4 123	8644701	8666216	897	Ambulance	D-9589	—
T207	WC-9	1941	W-71975 to W-72249	W-398-QM-8286	½ T 4x4 123	8644701		275	Ambulance	D-9874	—
T207	WC-9	1941	W-72256 to W-73371	W-398-QM-9140	½ T 4x4 123	8666301	8676719	1116	Ambulance	D-9953	—
T207	WC-10	1941	W-209868 to W-209999 W-2010000 to W-2010208	W-398-QM-8286	½ T 4x4 116	8644701	8666216	341	Carry All Body	D-9589	—
T207	WC-10	1941	W-2015120 to W-2015243	W-398-QM-8286	½ T 4x4 116	8644701		124	Carry All Body	D-9874	—

SEE PAGE VI THRU XIX FOR PICTURES OF BODY TYPES

MODEL IDENTIFICATION AND SPECIFICATION CHART

Engineering Symbol	Model Code	Year Built	U. S. Government Registration Nos.	U. S. Government Contract No.	Rate Type Whl Base	Starting Serial No.	Finished Serial No.	No. Built	TYPE BODY	Individual Parts List No.	Technical Manual No.
T207	WC-10	1941	W-2023309 to W-2024486	W-398-QM-9140	½ T 4x4 116	8666301	8676719	1178	Carry All Body	D-9953	—
T207	WC-11	1941	W-215419 to W-215478 W-216057 to W-216349	W-398-QM-8286	½ T 4x4 116	8644701	8666216	353	Panel Body	D-9874	—
T211	WC-12	1941	W-222266 to W-226218 W-003856 to W-004123	W-398-QM-9388	½ T 4x4 116	8676901		4221	Closed Cab Pickup	D-10034	—
T211	WC-12	1941	W-60766	W-398-QM-9388	½ T 4x4 116	8676901		1	Closed Cab—No Body	D-10034	—
T211	WC-12	1941	W-226219 to W-227043 W-231275 to W-232274	W-398-QM-9388	½ T 4x4 116	8676901		1825	Closed Cab Pickup	D-10187	—
T211	WC-13	1941	W-227044 to W-229817	W-398-QM-9388	½ T 4x4 116	8676901		2774	Open Cab Pickup—Bucket Seats	D-10034	—
T211	WC-13	1941	W-229818 to W-230130 W-232375 to W-233206	W-398-QM-9388	½ T 4x4 116	8676901		1245	Open Cab Pickup	D-10187	—
T211	WC-14	1941	W-003856 to W-004123	W-398-QM-9388	½ T 4x4 116	8676901		268	Closed Cab Pickup	D-10034	—
T211	WC-15	1941	W-2024487 to W-2025966 W-2026644 to W-2027937	W-398-QM-9388	½ T 4x4 116	8676901	8694193	2774	Reconnaissance	D-10034	—
T211	WC-15	1941	W-2027938 to W-2029143	W-398-QM-9388	½ T 4x4 116	8676901		1206	Reconnaissance	D-10187	—
T211	WC-16	1941	W-606357 to W-607238	W-398-QM-9388	½ T 4x4 116	8676901		882	Radio Body	D-10034	—
T211	WC-16	1941	W-607239 to W-607383 W-607687 to W-607943	W-398-QM-9388	½ T 4x4 116	8676901		402	Radio Body	D-10187	—
T211	WC-17	1941	W-2025967 to W-2026129 W-2026533 to W-2026643	W-398-QM-9388	½ T 4x4 116	8676901		274	Carry All	D-10034	—
T211	WC-18	1941	W-73372 to W-74241	W-398-QM-9388	½ T 4x4 123	8676901		870	Ambulance	D-10034	—
T211	WC-18	1941	W-74242 to W-74631 W-74733 to W-75027	W-398-QM-9388	½ T 4x4 123	8676901		685	Ambulance	D-10187	—
T211	WC-19	1941	W-230519 to W-230621	W-398-QM-9388	½ T 4x4 116	8676901		103	Panel	D-10034	
T211	WC-20	1941	W-003759 to W-003788	W-398-QM-9388	½ T 4x4 123	8676901		30	Closed Cab—No Body	D-10034	—
T112	WC-36	1941	W-2029256 to W-2029479 W-2050221 to W-2050396	W-398-QM-10595	½ T 4x2 116	81103700		400	Carry All Body	D-10330	10-1154
T112	WC-37	1941	W-233509 to W-233514	W-398-QM-10595	½ T 4x2 116	81103700	81104468	6	Panel Body	D-10330	10-1154
T112	WC-38	1941	W-233570 to W-233823 W-234271 to W-234378	W-398-QM-10595	½ T 4x2 116	81103700		362	Closed Cab Pickup	D-10330	10-1154
T112	WC-39	1941	W-004339	W-398-QM-10595	½ T 4x2 116	81103700		1	Closed Cab—Telephone Installation Body	D-10330	10-1154
T215	WC-21	1941	W-234379 to W-238778 W-240179 to W-242178	W-398-QM-10327	½ T 4x4 116	81500001		6900	Open Cab Pickup Body	D-10252	10-1152
T215	WC-21	1941	None	W-398-QM-DA28	½ T 4x4 116	81500001		500	Open Cab Pickup Body and Transverse Seats	D-10252	10-1152
T215	WC-22	1941	W-238779 to W-240178 W-242179 to W-242678	W-398-QM-10327	½ T 4x4 116	81500001		1900	Open Cab Pickup Body	D-10252	10-1152
T215	WC-23	1941	W-2050397 to W-2051696 W-2052047 to W-2052246	W-398-QM-10327	½ T 4x4 116	81500001		1500	Reconnaissance	D-10252	10-1152
T215	WC-23	1941	None	W-398-QM-DA28	½ T 4x4 116	81500001		700	Reconnaissance	D-10252	10-1152
T215	WC-24	1941	W-2051697 to W-2052046 W-2052247 to W-2052396	W-398-QM-10327	½ T 4x4 116	81500001		500	Reconnaissance with Winch	D-10252	10-1152
T215	WC-25	1941	W-608358 to W-608857 W-608858 to W-609007	W-398-QM-10327	½ T 4x4 116	81500001		650	Radio Body	D-10252	10-1152
T215	WC-26	1941	W-2052397 to W-2053446 W-2053447 to W-2053496	W-398-QM-10327	½ T 4x4 116	81500001		1100	Carry All	D-10252	10-1152
T215	WC-26	1941	None	W-398-QM-DA28	½ T 4x4 116	81500001		300	Carry All	D-10252	10-1152
T215	WC-27	1941	W-75400 to W-77080	W-398-QM-10327	½ T 4x4 123	81500001		1681	Ambulance	D-10252	10-1152
T215	WC-27	1941	None	W-398-QM-DA28	½ T 4x4 123	81500001		260	Ambulance	D-10252	10-1152
T215	WC-40	1941	W-005371 to W-005645	W-398-QM-10327	½ T 4x4 116	81500001		275	Closed Cab Pickup	D-10252	10-1152
T215	WC-41	1941	W-005646 to W-005858 W-005859 to W-005912	W-398-QM-10327	½ T 4x4 123	81500001		267	Closed Cab—No Body	D-10252	10-1152
T118	WF-31	1941	W-353494 to W-353609	W-398-QM-10616	1½ T 4x2 135	81304900		116	Closed Cab	D-10353	10-1156
T118	WF-31	1942		W-398-QM-12572	1½ T 4x2 135	81334245		200	Closed Cab and Chassis	D-10501	10-1534

SEE PAGE VI THRU XIX FOR PICTURES OF BODY TYPES

MODEL IDENTIFICATION AND SPECIFICATION CHART

Engineering Symbol	Model Code	Year Built	U. S. Government Registration Nos.	U. S. Government Contract No.	Rate	Type	Wh'l Base	Starting Serial No.	Finished Serial No.	No. Built	TYPE BODY	Individual Parts List No.	Technical Manual No.
T215	WC-41	1941	W-006868 to W-006906	W-398-QM-11244	½	T 4x4	116	81517648		39	Closed Cab	D-10454	10-1
T215	WC-25	1942	None	DAW-398-QM-125	½	T 4x4	116	81517445		64	Reconnaissance Radio	D-10452	10-1
T215	WC-24	1942	None	DAW-398-QM-86	½	T 4x4	116	81516783		512	Reconnaissance with Winch	D-10453	10-1152
T215	WC-21	1942	None	DAW-398-QM-129	½	T 4x4	116	81517509		352	Open Cab with Express Body	D-10451	10-1
T215	WC-27	1942	None	DAW-398-QM-129	½	T 4x4	123	81517509		35	Ambulance	D-10451	10-1
T215	WC-42	1942	None	W-398-QM-DA28	½	T 4x4	116	81512931		650	Panel Radio	D-10449	10-1
T215	WC-21	1942	W-247219 to W-252218	W-398-QM-11592	½	T 4x4	116	81517694		4923	Weapon Carrier	D-10465	10-1442
T215	WC-25	1942	W-2071355 to W-2072104	W-398-QM-11592	½	T 4x4	116	81517694		750	Reconnaissance Radio	D-10465	10-1442
T215	WC-26	1942	W-2069855 to W-2071354	W-398-QM-11592	½	T 4x4	116	81517694		1500	Carry All	D-10465	10-1
T215	WC-27	1942	W-77341 to W-77840	W-398-QM-11592	½	T 4x4	123	81517694		500	Ambulance	D-10465	10-1
T215	WC-43	1942	W-007539 to W-007908	W-398-QM-11592	½	T 4x4	116	81517694		370	Telephone Installation Body	D-10471	10-1444
T215	WC-41	1942	W-008608 to W-008684	W-398-QM-11592	½	T 4x4	123	81517694		77	Emergency Repair Cab and Chassis	D-10465	10-1442
T215	WC-21	1942	None	DAW-398-QM-210	½	T 4x4	116	81517694		1612	Weapon Carrier	D-10465	10-1
T215	WC-23	1942	None	DAW-398-QM-210	½	T 4x4	116	81517694		437	Reconnaissance	D-10465	10-1442
T215	WC-24	1942	None	DAW-398-QM-210	½	T 4x4	116	81517694		400	Reconnaissance with Winch	D-10465	10-1442
T215	WC-25	1942	None	DAW-398-QM-210	½	T 4x4	116	81517694		166	Reconnaissance Radio	D-10465	10-1
T215	WC-27	1942	None	DAW-398-QM-210	½	T 4x4	123	81517694		103	Ambulance	D-10465	10-1
T112	WC-47	1942	W-244725 to W-245114	W-398-QM-11399	½	T 4x2	116			390	Closed Cab and Express Body	D-10455	10-1378
T112	WC-48	1942	W-2054363 to W-2054736	W-398-QM-11399	½	T 4x2	116	81113001		374	Carry All	D-10455	10-1378
T112	WC-49	1942	W-245115 to W-245122	W-398-QM-11399	½	T 4x2	116			8	Panel Body	D-10455	10-1
T112	WC-50	1942	W-006930	W-398-QM-11399	½	T 4x2	116			1	Cab and Telephone Installation Body	D-10455	10-1378
T118	WF-31	1942	None	W-398-QM-12572	1½	T 4x2	135	81334245		200	Cab and Chassis	D-10501	10-1534
T214	WC-51	1942	W-252293 to W-254792	W-398-QM-11420	¾	T 4x4	98	81529001		2500	Weapon Carrier less Winch	D-10483	10-1
			W-259135 to W-289212	W-398-QM-11422	¾	T 4x4	98	81529001		30078	Weapon Carrier less Winch		
T214	WC-51	1942	291910 to 291992	W-398-QM-13596	¾	T 4x4	98	81534381		608	Weapon Carrier	D-10534	10-1530
			293685 to 294209										
T214	WC-51	1942	2110000 to 2125113	W-374-ORD-2864	¾	T 4x4	98	81601050		15114	Weapon Carrier	D-10583	SNL-
T214	WC-52	1942	W-245845 to W-246394	W-398-QM-11420	¾	T 4x4	98	81529001		550	Weapon Carrier with Winch	D-10483	10-1530
			W-289213 to W-291384	W-398-QM-11422	¾	T 4x4	98	81529001		2172	Weapon Carrier with Winch		
T214	WC-52	1942	291993 to 292508	W-398-QM-13596	¾	T 4x4	98	81534381		516	Weapon Carrier with Winch	D-10534	10-1
T214	WC-52	1942	292509 to 292512	W-398-QM-13596	¾	T 4x4	98	81534381		4	Weapon Carrier with Winch	D-10534	10-1
T214	WC-52	1942	2160419 to 2179292	W-374-ORD-2864	¾	T 4x4	98	81601050		38154	Weapon Carrier with Winch	D-10583	SNL-G502
			2180276 to 2199555										
T214	WC-53	1942	W-2072128 to W-2073327	W-398-QM-11420	¾	T 4x4	114	81529001		1200	Carry All	D-10483	10-1
			W-20163146 to W-20167956	W-398-QM-11422	¾	T 4x4	114	81529001		4811	Carry All		
T214	WC-53	1942	20260793 to 202612157	W-374-ORD-2864	¾	T 4x4	114	81601050		465	Carry All	D-10583	SNL-G502
T214	WC-53	1942	2089952 to 2091083	W-398-QM-13596	¾	T 4x4	114	81534381		1132	Carry All	D-10534	10-1530
T214	WC-53	1942	2089156 to 2089175	DAW-398-QM-505	¾	T 4x4	114	81534381		20	Carry All	D-10534	10-1
T214	WC-53	1942	2089176 to 2089947	DAW-398-QM-521	¾	T 4x4	114	81534381		772	Carry All	D-10534	10-1
T214	WC-54	1942	W-77841 to W-78690	W-398-QM-11420	¾	T 4x4	121	81529001		850	Ambulance	D-10483	10-1530
			W-78691 to W-79999	W-398-QM-11422	¾	T 4x4	121	81529001		9945	Ambulance		
			W-710000 to W-718635	W-398-QM-11422	¾	T 4x4	121	81529001					
T214	WC-54	1942	75068 to 75083	DAW-398-QM-448	¾	T 4x4	121	81534381		16	Ambulance	D-10534	10-
T214	WC-54	1942	718636 to 719045	W-398-QM-13596	¾	T 4x4	121	81534381		410	Ambulance	D-10534	10-1530
T214	WC-54	1942	721000 to 732635	W-374-ORD-2864	¾	T 4x4	121	81601050		11636	Ambulance	D-10583	SNL-G502
T214	WC-55	1942	W-6016072 to W-6021066	W-374-ORD-1316	¾	T 4x4	98	81529001		5380	Gun Motor Carriage	D-10482	SNL-
			W-6022453 to W-6022837										
T214	WC-56	1942	W-20167957 to W-20182608	W-398-QM-11422	¾	T 4x4	98	81529001		14652	Reconnaissance less Winch	D-10483	10-1530
T214	WC-56	1942	2091084 to 2092118	W-398-QM-13596	¾	T 4x4	98	81534381		1035	Command	D-10534	10-1530
T214	WC-57	1942	W-20184953 to W-20185866	W-398-QM-11422	¾	T 4x4	98	81529001		916	Reconnaissance with Winch	D-10483	10-
T214	WC-57	1942	2092119 to 2092618	W-398-QM-13596	¾	T 4x4	98	81534381		500	Command with Winch	D-10534	10-
T214	WC-57	1942	20291158 to 20295751	W-374-ORD-2864	¾	T 4x4	98	81601050		4594	Command with Winch	D-10583	SNL-G50
T214	WC-58	1942	W-20182609 to W-20184952	W-398-QM-11422	¾	T 4x4	98	81529001		2344	Radio	D-10483	10-1530
T214	WC-59	1942	0015366 to 0015914	W-398-QM-13596	¾	T 4x4	121	81534381		549	Telephone Maintenance	D-10534	10-
T214	WC-60	1942	0015915 to 0015986	W-398-QM-13596	¾	T 4x4	121	81534381		72	Emergency Repair Chassis	D-10534	10-
T214	WC-60	1942	0026383 to 0026606	W-374-ORD-2864	¾	T 4x4	121	81601050		224	Emergency Repair Chassis	D-10583	SNL-G502
T223	WC-62	1943	3297503 to 3328846	W-374-ORD-2616	1½	T 6x6	125	82000006		31344	Personnel and Cargo	D-10592	SNL-
T223	WC-63	1943	3328847 to 3342502	W-374-ORD-2616	1½	T 6x6	125	82000006		13656	Personnel and Cargo with Winch	D-10592	SNL-

SEE PAGE VI THRU XIX FOR PICTURES OF BODY TYPES

ALPHABETICAL INDEX

SHOWING

NAMES OF PARTS (NOUN IN CAPS)

SUB-GROUP NUMBER

NUMBER OF PAGE ON WHICH PART IS SPECIFIED FOR EACH MODEL

A	Sub-Group	Page No.
ABSORBER ASSEMBLY—Front Shock	1603	314
ABSORBER ASSEMBLY—Rear Shock	1603	314
ADAPTER—Grease Gun	2311	497
ADAPTER—Main Battery to Radio Switch Cable Housing	0610	162
ADAPTOR—Carburetor	0301	52
ADAPTOR—Carburetor Body Flange	0301	52
ADJUSTER—Front Axle Differential Bearing	1002	217
ADJUSTER—Front Axle Drive Bearing	1003	228
ADJUSTER—Rear Axle Differential Bearing Cone	1103	240
AIR CLEANER—Crankcase Breather Pipe	0107	28-29
AIR CLEANER—Crankcase Ventilator Outlet Pipe	0107	26
AIR CLEANER ASSEMBLY—Carburetor	0301	57
AIR DOME ASSEMBLY—Fuel Pump Top Cover	0302	61
AIR HORN ASSEMBLY—Carburetor	0301	56
AMMETER ASSEMBLY	0605	141
ANGLE—Attendants Seat Leg Attaching	----	444
ANGLE—Body Trunnion	----	361
ANGLE—Linoleum Retainer	----	445
ANGLE—Winch Base	----	451
ANGLE—Winch Front Base	----	449
ANGLE—Winch Rear Base	----	449
ANTI SQUEAK—Fender Front Support	1504	291
ANTI SQUEAK—Fender Rear Support	1504	293
ANTI SQUEAK—Fender to Frame Bracket	1504	293
ANTI SQUEAK—Front Fender to Frame Splash Shield	1702	321
APRON—Body Side Sill	----	361
ARM—Door Check	1805	333-338-412-424
	1807	415
ARM—Front Axle Steering Knuckle	----	227-230
ARM—Generator Brush	0601	109-111-115
ARM—Rear View Mirror Pivot	----	377
ARM—Steering Gear	1403	286
ARM—Windshield Adjusting	1801	328-342-367-368-382-404-420
ARM—Windshield Visor	1801	405
	1807	339
ARM—Windshield Wiper	1801	330-343-369-384-406-422
ARM—Windshield Wiper Control	1801	343-369
ARM AND BRACKET ASSEMBLY—Tail Lamp	0608	158
ARM AND SHAFT ASSEMBLY—Carburetor Throttle	0301	55
ARM AND STUD ASSEMBLY—Tire Carrier	1505	295
ARM ASSEMBLY—Door Check	1805	424
	1807	415
ARM ASSEMBLY—Front Axle Steering	1006	226
ARM ASSEMBLY—Power Take Off Lifting	2001	454
ARM ASSEMBLY—Rear View Mirror	2201	470
ARM ASSEMBLY—Tire Carrier	1505	294
ARM ASSEMBLY—Windshield Side	1801	342
ARM ASSEMBLY—Windshield Wiper	1801	384-406
ARMATURE AND CONTACT ASSEMBLY—Generator Regulator	0601	110-116

A—Continued	Sub-Group	Page No.
ARMATURE ASSEMBLY—Generator	0601	109-111-115
ARMATURE ASSEMBLY—Starting Motor	0602	119-122
ARRESTOR ASSEMBLY—Torque	1601	304
AXLE—Carburetor Float	0301	49
AXLE—Carburetor Float Lever	0301	55
AXLE ASSEMBLY—Front	1000	216
AXLE ASSEMBLY—Rear	1100	238
B		
BACK ASSEMBLY—Auxiliary Seat	1804	353
BACK ASSEMBLY—Horn	0609	160
BACK ASSEMBLY—Lazy	1804	352-353
BACK ASSEMBLY—Seat	1804	332-346-408
BAFFLE—Clutch Cover Plate	0202	42
BAFFLE—Front Axle Drive Pinion Rear Bearing Oil	1003	220
BAFFLE—Rear Axle Drive Pinion Rear Bearing Oil	1104	243
BAFFLE AND PLUG ASSEMBLY—Brake Master Cylinder Cover	1205	258
BAG—Tool	2306	487-488-489
BAG ASSEMBLY—Tool	2306	489
BAIL—Fuel Filter Bowl	0302	65
BAIL ASSEMBLY—Fuel Pump Strainer Bowl	0302	63
BALL	2315	500
BALL—Carburetor Pump Check	0301	56
BALL—Carburetor Pump Cylinder	0301	56
BALL—Carburetor Pump Discharge Check	0301	56
BALL—Carburetor Pump Intake Check	0301	56
BALL—Drag Link	1401	280
BALL—Front Axle Steering Arm	1006	226
BALL—Front Axle Universal Drive	1005	221
BALL—Front Axle Universal Drive Thrust	1005	222
BALL—Power Take-off Pump Ball Check	----	455
BALL—Power Take-off Shifter Shaft Lock	2010	458-459
BALL AND ROLLER ASSEMBLY—Propeller Shaft Universal Joint	0902	211
BALL JOINT	2315	500
BALL JOINT—Accelerator Bell Crank Rod	0303	69
BALL JOINT—Accelerator Shaft to Throttle Control Bell Crank Rod	0303	67
BALL JOINT—Throttle Control Bell Crank Rod	0303	69
BAND—Generator Head	0601	109-111-115
BAND—Starting Motor Head	0602	119-122
BAND AND LINING ASSEMBLY—Hand Brake	1201	250
BAND AND LINING ASSEMBLY—Winch Safety Brake	----	449-451
BAR—Frame Rear Brace	1506	299
BAR AND CHANNEL ASSEMBLY—Driver's Seat Anchor Pivot and Tilt	----	444
BAR ASSEMBLY—Body Back Panel Upper Tie	----	378
BAR ASSEMBLY—Door Vent Window Division	1805	430
BASE ASSEMBLY—Battery	1803	407
BASE ASSEMBLY—Distributor	0603	126-129-131

ALPHABETICAL INDEX—Continued

B—Continued	Sub-Group	Page No.
BASE ASSEMBLY—Dome Lamp	0608	159
BASE ASSEMBLY—Front Shock Absorber Reservoir Tube and Cylinder	1603	316
BASE ASSEMBLY—Rear Shock Absorber Reservoir Tube and Cylinder	1603	316
BATTERY	2309	494
BEARING—Camshaft	0106	18
BEARING—Crankshaft	0102	10
BEARING—Distributor Absorbent Bronze (Upper and Lower)	0603	127
BEARING—Distributor Base Absorbent Bronze	0603	127-129-131
BEARING—Drag Link Ball	1401	280
BEARING—Front Axle Steering Knuckle		227
BEARING—Front Axle Steering Knuckle Thrust		230
BEARING—Front Control Cross Rod		361
BEARING—Generator Commutator End Absorbent Bronze	0601	107
BEARING—Generator Commutator End Ball	0601	107-111-114
BEARING—Generator Drive End Ball	0601	111
BEARING—Generator Drive End Head Ball	0601	108-114
BEARING—Hyatt Roller Pilot	2315	501
BEARING—Power Take-off Control Hand Lever		457
BEARING—Power Take-off Drive Shaft Steady		457
BEARING—Power Take-off Drive Shaft Taper Roller	2010	460-461
BEARING—Power Take-off Idler Gear	2010	460-461
BEARING—Power Take-off Idler Gear Roller	2010	459
BEARING—Power Take-off Reverse Idler Gear	2010	460-461
BEARING—Power Take-off Reverse Idler Roller	2010	459
BEARING—Power Take-off Valve Control Hand Lever		457
BEARING—Starting Motor Absorbent Bronze	0602	121
BEARING—Starting Motor Pinion and Clutch Absorbent	0602	118
BEARING—Sub Frame Hinge Shaft		359
BEARING—Transfer Case Drive Shaft	0802	191
BEARING—Transmission Countershaft	0704	168-173
BEARING—Transmission Drive Pinion	0703	173
BEARING—Transmission Main Drive Pinion	0703	166
BEARING—Transmission Main Shaft	0704	173
BEARING—Transmission Main Shaft Pilot	0704	167
BEARING—Transmission Main Shaft Rear	0704	167
BEARING AND SPACER—Transmission Countershaft	0704	173
BEARING ASSEMBLY—Clutch Release	0203	43
BEARING ASSEMBLY—Front Axle Drive Pinion Front	1003	219
BEARING ASSEMBLY—Front Axle Drive Pinion Inner	1003	229
BEARING ASSEMBLY—Rear Axle Drive Pinion Front	1104	242
BEARING ASSEMBLY—Rear Axle Drive Pinion Inner	1104	243
BELL—Front Axle Universal Drive Ball Outer Race	1005	221
BELL CRANK—Throttle Control	0303	70
BELT—Fan and Generator	0503	98
BEZEL—Instruments	0605	140
BEZEL—Speedometer	2203	472
BEZEL and LENS ASSEMBLY—Dome Lamp	0608	159
Bill of Material Section		511
BINDING	2312	497
BINDING—Folding Top Finish		377
BLADE—Windshield Wiper	1801	330-343-369-384-406-422
BLOCK—Front Axle Differential Pinion Shaft	1002	217
BLOCK—Front Axle Drive Gear Thrust	1003	228
BLOCK—Headlamp Cable and Socket Junction	0607	151
BLOCK—Rear Axle Differential Pinion Shaft	1103	240
BLOCK—Rear Axle Drive Gear Thrust	1104	241
BLOCK—Rear Axle Drive Shaft Bearing Thrust	1102	239
BLOCK—Starting Motor Switch Insulating	0602	120-123
BLOCK—Windshield Frame Pivot	1801	343
BLOCK—Windshield Frame Pivot Clamping	1801	368

B—Continued	Sub-Group	Page No.
BLOCK ASSEMBLY—Chassis Wiring Junction	0606	146
BLOCK ASSEMBLY—Cylinder	0101	8
BOARD—Floor	1802	351-385-407
BOARD—Floor Center	1802	351
BOARD—Floor Side	1802	351
BOARD—Longitudinal Side Seat		442
BOARD ASSEMBLY—Floor	1802	331-344-351-370-385-407-423
BOARD ASSEMBLY—Map		378
BOARD ASSEMBLY—Toe	1802	331-344-370-385-407-423
BODY—Brake Master Cylinder	1205	257
BODY—Brake Wheel Cylinder	1207	259-260
BODY—Carburetor Fuel Bowl Cover Check Valve	0301	49
BODY—Fuel Pump	0302	60
BODY—Fuse	2315	500
BODY—Parking Lamp	0607	152
BODY—Power Take Off Pump		455
BODY—Propeller Shaft Universal Joint	0902	211
BODY—Tail and Signal Lamp	0608	155
BODY—Telephone		365
BODY AND GOVERNOR ASSEMBLY—Carburetor Throttle	0301	49
BODY ASSEMBLY—Blackout Driving Lamp	0608	153
BODY ASSEMBLY—Headlamp Beam Indicator	0607	152
BODY ASSEMBLY—Oil Filter	0107	31
BODY ASSEMBLY—Oil Pump	0107	23
BODY ASSEMBLY—Water Pump	0503	96
BOLT—Auxiliary Battery to Ground Cable Terminal	0610	162
BOLT—Battery Ground Cable Terminal	0610	161
BOLT—Body Hold Down	1807	337-349-355-371-394-414-431
BOLT—Connecting Rod Cap	0104	16
BOLT—Engine to Dash Ground Strap Terminal	2205	478
BOLT—Flywheel	0108	33
BOLT—Round Head Carriage	2304	482
BOLT—Square Head Machine	2304	482
BOLT—Starter Cable Terminal	0610	161
BOLT—Step	2304	482
BOOT—Brake Master Cylinder	1205	257
BOOT—Brake Wheel Cylinder	1207	259-260
BOOT—Litter Wall Bracket		443
BOW—Roof	2310	495-496
BOW—Tarpaulin		361
BOW ASSEMBLY—Top		362
BOWL—Fuel Filter	0302	65
BOWL—Fuel Pump Strainer	0302	63
BOWL ASSEMBLY—Carburetor Fuel	0301	49
BOX—Door Lock Cover		441
BOX—Locker		443
BOX—Power Take-off Cylinder High Pressure Stuffing	2001	454
BOX ASSEMBLY—Glove	1807	338-346-372-394-416-432
BOX ASSEMBLY—Radio Feed Switch	2204	474
BOX ASSEMBLY—Tool		443
BRACE—Body to Rear Fender Front Shield	1702	322
BRACE—Crankcase Breather Pipe	0107	28
BRACE—Fender Front Support	1504	292
BRACE—Fender Rear Support Frame	1504	292
BRACE—Fender to Frame	1504	293

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

B—Continued	Sub-Group	Page No.
BRACE—Frame Rear Crossmember	1506	298-299
BRACE—Generator Mounting Bracket	0601	113
BRACE—Pintle Hook	1506	299
BRACE—Radiator Guard	2103	467
BRACE—Radiator Support Cross	0504	99
BRACE—Tail and Blackout Lamp	....	441
BRACE—Tail Gate Hinge	....	361
BRACE—Tire Carrier	1505	294
	1807	419
BRACE AND RATCHET ASSEMBLY—Cowl Ventilator	1807	339-348-375-400-419-434
BRACE AND STUD ASSEMBLY—Tire Carrier	1807	419
BRACE AND STUD ASSEMBLY—Tire Carrier Support	1505	294
BRACKET—Ammeter Mounting	0605	141
BRACKET—Arm Splint	....	443
BRACKET—Attendants Seat Support	....	444
BRACKET—Battery Cover Hold Down	1803	385
BRACKET—Battery Hold Down	1803	423
BRACKET—Blackout Switch	0608	155
BRACKET—Body	1802	351
BRACKET—Body Hold Down	1807	432
BRACKET—Body Outrigger	1506	299
BRACKET—Body to Frame Anchor	....	362
BRACKET—Booster Brake Supply Tank	1210	270
BRACKET—Brake Hose	1209	268
BRACKET—Brake Pedal	1204	256
BRACKET—Brake Pedal Pull Back Spring Reinforcement	1204	256
BRACKET—Brake Tube to Hose	1209	265
BRACKET—Bumper	2102	464
BRACKET—Bumper Reinforcement	2102	465-468
BRACKET—Bumper Support	2102	465-468
BRACKET—Cab Hold Down	1803	331-344-385-407-423
	1807	371
BRACKET—Carburetor Bowl Cover Float Hinge	0301	49
BRACKET—Clutch Pedal Pull Back Spring	0204	44-45
BRACKET—Clutch Pedal Reinforcement	0204	45
BRACKET—Crankcase Breather Pipe	0107	28-29
BRACKET—Crankcase Ventilator Outlet Pipe	0107	26
BRACKET—Distributor Vacuum Chamber	0603	129-133
BRACKET—Door Check Arm	1805	333-388-412-424
BRACKET—Door Vent Wing	1805	429
BRACKET—Engine Front Support	0110	34
BRACKET—Engine Front Support Trunnion	0110	35
BRACKET—Engine Rear Support	0110	38
BRACKET—Exhaust Pipe	0402	83
BRACKET—Fender Blackout Lamp	1504	292
BRACKET—Fender Front Support	1504	291-292
BRACKET—Fender Rear Support	1504	292
BRACKET—Fender Rear Support Frame	1504	292
BRACKET—Fender to Frame	1504	293
BRACKET—Folding Step	....	442
BRACKET—Folding Top Bow to Body	....	376
BRACKET—Frame Crossmember Rear	1506	299
BRACKET—Front Axle Brake Hose Frame	1209	268
BRACKET—Front Fender Splash Shield Support	1702	321
BRACKET—Front Fender to Frame Splash Shield	1702	321
BRACKET—Front Shock Absorber Anchor	1603	314
BRACKET—Front Shock Absorber Frame	1603	314
BRACKET—Fuel Gauge Mounting	0605	142
BRACKET—Fuel Tank Filler Tube	0304	75
BRACKET—Generator Mounting	0601	106-111-113
BRACKET—Generator Regulator Adjusting	0601	110

B—Continued	Sub-Group	Page No.
BRACKET—Generator Regulator Resistor	0601	110
BRACKET—Hand Brake Adjusting	1201	251
BRACKET—Hood Prop Rod	1704	326
BRACKET—Hood Support	1704	326
BRACKET—Hood Windshield Support	1704	326
BRACKET—Horn	0609	160
BRACKET—Horn Mounting	0609	160
BRACKET—Ignition Coil	0604	134
BRACKET—Leg Splint	....	443
BRACKET—License Lamp	0608	157
BRACKET—License Lamp and License	0608	157
BRACKET—Litter Wall	....	443
BRACKET—Muffler Front	0401	82
BRACKET—Muffler Front Support	0401	82
BRACKET—Muffler Rear	0402	84
BRACKET—Muffler Tail Pipe	0402	84
BRACKET—Muffler Tail Pipe—Front	0402	85
BRACKET—Muffler Tail Pipe—Rear	0402	84
BRACKET—Oil Can	2210	479
BRACKET—Oil Gauge Mounting	0605	143
BRACKET—Partition	....	361
BRACKET—Power Take-off Control Lever (for Emergency Quadrant)	....	457
BRACKET—Power Take-off End Plate and Shifter Lever	2010	460
BRACKET—Power Take-off Valve Control	2001	454
	....	457
BRACKET—Rack Stake Seat Hinge	....	362
BRACKET—Radiator Guard	2103	467
BRACKET—Radiator Shell Support to Fender Shield	0501	91
BRACKET—Radiator Support	0504	99
BRACKET—Radiator Tie Rod	0504	101
	1807	417
BRACKET—Radiator Tie Rod Dash	1807	338-347-372-395-433
BRACKET—Radimeter Mounting	0502	94
BRACKET—Rear Auxiliary Spring Bumper	1601	307
BRACKET—Rear License Lamp	....	379
BRACKET—Rear Shock Absorber Anchor	1603	314
BRACKET—Rear Shock Absorber Left	1603	316
BRACKET—Rear Shock Absorber Right	1603	316
BRACKET—Rear Spring Axle Bumper	1601	309
BRACKET—Rear Spring Torque Link Frame	1602	312
BRACKET—Rear View Mirror	....	377
BRACKET—Rear View Mirror Arm	2201	470
BRACKET—Rear Wheel Splash Guard	....	362
BRACKET—Reflector Mounting	2308	493
BRACKET—Seat Frame to Side Panel	....	377
BRACKET—Seat Rear Hold-down	....	377
BRACKET—Seat Safety Strap Swivel	2310	495-496
BRACKET—Seat Support	1804	408
BRACKET—Side Panel	1807	374
BRACKET—Speedometer Mounting	2203	472
BRACKET—Spring	1503	289
BRACKET—Starting Motor Pedal Rod	0602	120-123
BRACKET—Steering Post	1405	286
BRACKET—Sub Frame Trunnion	....	359
BRACKET—Tail and Signal Lamp	0608	157-158
	....	440
BRACKET—Tail Gate Chain	....	362
BRACKET—Tail Gate Hinge	....	361
BRACKET—Tail Gate Hook	....	361
BRACKET—Tail Lamp	0608	157
	....	379
BRACKET—Tail Lamp and License	0608	158
BRACKET—Thermometer Mounting	0605	143
BRACKET—Throttle Control Cables Dash	0303	69

ALPHABETICAL INDEX—Continued

B—Continued	Sub-Group	Page No.
BRACKET—Throttle Control Wire Tube	0303	70
BRACKET—Tire Carrier Arm Latch Shaft	1505	295
BRACKET—Trailer Connector	0606	146
BRACKET—Trailer Electric Brake Control Switch	0604	138
BRACKET—Transfer Case	0808	192
BRACKET—Transfer Case Mounting	0808	185
BRACKET—Transfer Case Support	0808	189
BRACKET—Winch Shifter Fork		451
BRACKET—Winch Shifter Fork Locating		449-451
BRACKET—Windshield Adjusting Arm Frame	1801	342-368-420
BRACKET—Windshield Adjusting Arm to Pillar	1801	328-367-404
BRACKET—Windshield Hinge	1801	329-367-383-405-421
BRACKET—Windshield Pivot	1801	342-368-369
BRACKET—Windshield Side Arm	1801	342-368
BRACKET—Windshield Stanchion		376
BRACKET—Windshield Toggle	1801	343-368
BRACKET—Windshield Visor	1801	405
	1807	339
BRACKET AND ARM ASSEMBLY—Tail Lamp	0608	158
BRACKET AND BUSHING ASSEMBLY—Clutch Pedal	0204	45
BRACKET AND BUSHING ASSEMBLY—Steering Gear Housing	1403	283
BRACKET AND BUSHING ASSEMBLY—Transfer Case Gearshift Lever	0806	189
BRACKET AND BUSHING ASSEMBLY—Winch Cable Drum Shaft		449-451
BRACKET AND BUSHING ASSEMBLY—Windshield Adjusting Arm Frame	1801	328-367-404
BRACKET AND FRAME ASSEMBLY—Windshield Support	1801	368
BRACKET AND HANDLE ASSEMBLY—Driver's Seat Regulator		444
BRACKET AND HANDLE ASSEMBLY—Seat Regulator	1804	408
BRACKET AND SHAFT ASSEMBLY—Door Ventilator Window Handle	1805	425
BRACKET AND SHAFT ASSEMBLY—Rear Spring Trunnion	1602	312
BRACKET AND SHAFT ASSEMBLY—Transfer Case Control Hand Lever	0806	184
BRACKET AND SHAFT ASSEMBLY—Transfer Case Control Lever	0805	192
BRACKET AND SPACER ASSEMBLY—Rear Shock Absorber Left Frame	1603	316
BRACKET AND SPACER ASSEMBLY—Rear Shock Absorber Right Frame	1603	316
BRACKET AND TUBE ASSEMBLY—Ignition Cable	2205	477
BRACKET AND TUBE ASSEMBLY—Ignition Cable Mounting	0604	139
BRACKET AND TUBE ASSEMBLY—Ignition Coil Cable Mounting	0604	136
BRACKET ASSEMBLY—Accelerator Shaft	0303	67-69
BRACKET ASSEMBLY—Booster Brake Check Valve Mounting	1210	270
BRACKET ASSEMBLY—Booster Brake Operating	1210	270
BRACKET ASSEMBLY—Carburetor Air Shutter	0301	49
BRACKET ASSEMBLY—Carburetor Choke Tube	0301	55
BRACKET ASSEMBLY—Crankcase Breather Pipe	0107	29
BRACKET ASSEMBLY—Engine Rear Support	0110	37
BRACKET ASSEMBLY—Engine Rear Support Frame	0110	36
BRACKET ASSEMBLY—Fender Front Support	1504	292

B—Continued	Sub-Group	Page No.
BRACKET ASSEMBLY—Generator Regulator Contact Stationary	0601	110-116
BRACKET ASSEMBLY—Headlamp	0607	148
BRACKET ASSEMBLY—Headlamp Mounting	0607	148
BRACKET ASSEMBLY—Ignition Coil Mounting	0604	134-139
BRACKET ASSEMBLY—Liquid Container	1701	320
BRACKET ASSEMBLY—Oil Filter	0107	30
BRACKET ASSEMBLY—Rifle	2206	480
BRACKET ASSEMBLY—Tire Carrier	1505	295
BRACKET ASSEMBLY—Windshield Adjusting Arm Frame	1801	342-420
BRACKET ASSEMBLY—Windshield Adjusting Arm to Pillar	1801	367
BRACKET ASSEMBLY—Windshield Arm Frame	1801	382
BRACKET ASSEMBLY—Windshield Arm to Pillar	1801	382
BREAKER ASSEMBLY—Blackout Switch Circuit	0608	154
BRUSH—Starting Motor	0602	118-119-122
BULB	2315	501
BULB—Blackout and Blackout Parking Lamp	2308	492
BULB—Dome Lamp	2308	492
BULB—Head Lamp Auxiliary	2308	492
BULB—Head Lamp Main	2308	492
BULB—Headlight Beam Indicator	2308	492
BULB—Instrument Lamp	2308	492
BULB—Signal Lamp	2308	492
BULB—Spot Light	2308	492
BULB—Tail Lamp	2308	492
BULB—Voltmeter	2308	492
BUMPER—Body Door	1807	395
BUMPER—Cab Side Panel to Running Board	1807	347-395
BUMPER—Cowl Side Panel		337
BUMPER—Door	1805	332-409
	1807	432
BUMPER—Door Check Arm	1807	415
BUMPER—Door Glass	1805	332
BUMPER—Door Glass Inner	1805	333
	1807	395
BUMPER—Drag Link End	1401	281
BUMPER—Folding Step		443
BUMPER—Front Fender Splash Shield Hood	1702	321
BUMPER—Front Shield to Running Board	1702	322
BUMPER—Front Spring Axle	1601	309
BUMPER—Glove Box Door	1807	338-346-372-394-416-432
BUMPER—Hood	1704	324
	2205	477
BUMPER—Litter Pole Inside		443
BUMPER—Map Table Slide Channel	1807	374
BUMPER—Windshield Side Arm	1801	342-368
BUMPER ASSEMBLY	2101	464
BUMPER ASSEMBLY—Hood	2205	477
BUMPER ASSEMBLY—Rear Spring Axle	1601	309
BURR—Liquid Container Bracket Chape Rivet	1701	320
BURR—Liquid Container Bracket Strap to Bracket Rivet	1701	320
BUSHING—Battery to Terminal Box Cable Conduit	0610	161
BUSHING—Brake Pedal	1204	255
BUSHING—Clutch Pedal	0204	45
BUSHING—Clutch Release Fork	0203	43
BUSHING—Clutch Release Fork Flange	0203	43
BUSHING—Connecting Rod	0104	16
BUSHING—Crankshaft (Transmission Drive Pinion)	0102	10
BUSHING—Door Vent Wing	1805	429
BUSHING—Door Vent Wing Pivot	1805	431
BUSHING—Front Axle Housing	1001	216
BUSHING—Front Axle "I" Beam		230

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

B—Continued	Sub-Group	Page No.
BUSHING—Front Axle Steering Knuckle	1006	224
BUSHING—Front Axle Steering Knuckle Flange	1006	225
BUSHING—Front Axle Steering Knuckle King Pin		227
BUSHING—Front Shock Absorber Pivot	1603	316
BUSHING—Front Spring	1601	304
BUSHING—Fuel Tank Drain Plug	0304	72
BUSHING—Fuse	2315	500
BUSHING—Generator Insulating	0601	109-111-115
BUSHING—Headlamp Beam Indicator Socket Cable	0607	152
BUSHING—Horn Insulating	0609	160
BUSHING—Instrument Lamp Socket	0605	140
BUSHING—Manifold Heat Control Valve Shaft	0108	33
BUSHING—Oil Pump Idler Gear	0107	23
BUSHING—Pipe Reducing	2315	501
BUSHING—Piston Pin	0104	16
BUSHING—Power Take-off Drive Shaft	2010	458
BUSHING—Power Take-off Drive Shaft Steady Bearing		457
BUSHING—Power Take-off Pump Body		455
BUSHING—Power Take-off Pump Cover		455
BUSHING—Power Take-off Valve Control Bell		457
BUSHING—Power Take-off Valve Control Bell Crank	2001	454
BUSHING—Rear Shock Absorber Pivot	1603	316
BUSHING—Rear Spring	1601	305
BUSHING—Rear Spring Shackle	1602	311
BUSHING—Spring Front Bracket	1503	289
BUSHING—Starting Motor Terminal Post Insulating	0602	120-123
BUSHING—Steering Gear Column Jacket	1403	284
BUSHING—Steering Gear Housing Bracket	1403	283
BUSHING—Trailer Electric Brake Load Control Switch Insulating	0604	138
BUSHING—Transfer Case Control Declutch Lever	0805	192
BUSHING—Transfer Case Control Hand Lever	0806	184
BUSHING—Transfer Case Control Shift Lever	0805	192
BUSHING—Transfer Case Drive Pinion	0810	191
BUSHING—Transfer Case Gearshift Lever	0806	189
BUSHING—Transfer Case Gearshift Lever Bracket	0806	189
BUSHING—Transfer Case Gearshift Lever Intermediate Lever	0806	189
BUSHING—Transmission Drive Pinion	0102	10
BUSHING—Transmission Reverse Idler Gear	0704	167-173
BUSHING—Transmission Speedometer Drive Pinion	0705	169
BUSHING—Volt Meter Lamp	0605	142
BUSHING—Water Pump Shaft	0503	97
BUSHING—Winch Cable Drum Shaft Bracket		449-451
BUSHING—Winch Worm Housing		449-451
BUSHING AND BALL STUD ASSEMBLY—Rear Spring Torque Link	1602	312
BUSHING AND BRACKET ASSEMBLY—Clutch Pedal	0204	45
BUSHING AND BRACKET ASSEMBLY—Steering Gear Housing	1403	283
BUSHING AND BRACKET ASSEMBLY—Transfer Case Gearshift Lever	0806	189
BUSHING AND BRACKET ASSEMBLY—Winch Cable Drum Shaft		449-451
BUSHING AND BRACKET ASSEMBLY—Windshield Adjusting Arm Frame	1801	328-367-404
BUSHING AND COVER ASSEMBLY—Winch Worm Housing		449-451
BUSHING AND HOUSING ASSEMBLY—Winch Worm		449-451
BUSHING AND IDLER GEAR ASSEMBLY—Oil Pump	0107	23
BUSHING AND IDLER GEAR ASSEMBLY—Transmission Reverse	0704	167
BUSHING AND JACKET ASSEMBLY—Steering Gear Column	1403	284

B—Continued	Sub-Group	Page No.
BUSHING AND LEVER ASSEMBLY—Transfer Case Control Declutch	0805	192
BUSHING AND LEVER ASSEMBLY—Transfer Case Control Hand	0806	184
BUSHING AND LEVER ASSEMBLY—Transfer Case Control Shift	0805	192
BUSHING AND LEVER ASSEMBLY—Transfer Case Gearshift	0806	189
BUSHING AND LEVER ASSEMBLY—Transfer Case Gearshift Intermediate	0806	189
BUSHING AND PLUG ASSEMBLY—Front Spring Shackle	1602	310
BUSHING AND PLUG ASSEMBLY—Rear Spring Shackle	1602	316
BUSHING AND ROLLER ASSEMBLY—Propeller Shaft Universal Joint Cross	0902	208
BUSHING AND SHACKLE ASSEMBLY—Rear Spring	1602	311
BUSHING ASSEMBLY—Oil Pump Idler	0107	23
BUTTON—Accelerator Pedal	0303	68
BUTTON—Door Ventilator Window Handle	1805	425
BUTTON—Front Axle Universal Drive Shaft Thrust	1005	222
BUTTON—Hand Brake Lever Pawl Rod	1201	248
BUTTON—Starting Motor Pedal Rod	0602	120-123
BUTTON AND WIRE ASSEMBLY—Throttle Control	0303	69-71
BUTTON ASSEMBLY—Horn	0609	160
BUTTON ASSEMBLY—Propeller Shaft Universal Joint Centering	0902	211

C

C-WASHER—Brake Shoe Anchor Bolt	1203	233
CABLE—Generator Regulator Ground	0601	112
CABLE—High Tension Secondary	2313	498
CABLE—Horn Button	0610	161
CABLE—Ignition Coil Feed	0604	135-139
CABLE—Ignition Coil Primary	0604	136-139
CABLE—Ignition Coil Secondary	0604	136-139
CABLE—Ignition Coil Spark Plug	0604	137
CABLE—Low Tension Primary	2313	498
CABLE—Spark Plug	0604	139
CABLE—Truck Wiring	2313	498
CABLE AND CONDUIT ASSEMBLY—Battery to Terminal Box	0610	161
CABLE AND HOUSING ASSEMBLY—Speedometer	2203	472
CABLE AND SOCKET ASSEMBLY—Blackout Lamp	0608	154
CABLE AND SOCKET ASSEMBLY—Headlamp	0607	150-151
CABLE AND SOCKET ASSEMBLY—Parking Lamp	0607	152
CABLE AND SWITCH ASSEMBLY—Ignition Coil Lock	0604	135
CABLE AND YOKE ASSEMBLY—Hand Brake	1201	249
CABLE ASSEMBLY—Ammeter to Volt Meter	0605	141
CABLE ASSEMBLY—Auxiliary Battery to Ground	0610	162
CABLE ASSEMBLY—Battery Ground	0610	161
CABLE ASSEMBLY—Battery to Starter	0610	161
CABLE ASSEMBLY—Battery to Terminal Box	0610	161
CABLE ASSEMBLY—Blackout Driving Lamp	0608	153
CABLE ASSEMBLY—Blackout Driving Lamp Ground	0608	153
CABLE ASSEMBLY—Dome Lamp Switch Feed	0606	144
CABLE ASSEMBLY—Ground	0610	162
CABLE ASSEMBLY—Head Lamp	0607	150
CABLE ASSEMBLY—Horn Button	0609	160
CABLE ASSEMBLY—Horn Feed	0609	160
CABLE ASSEMBLY—Ignition Coil Lock Switch	0604	135
CABLE ASSEMBLY—Ignition Coil to Filter and Starter	0604	135
CABLE ASSEMBLY—Main Battery to Radio Switch	0610	162
CABLE ASSEMBLY—Radio Switch to Auxiliary Battery	0610	162
CABLE ASSEMBLY—Starter	0610	161
CABLE ASSEMBLY—Starting Motor	0610	162

ALPHABETICAL INDEX—Continued

C—Continued	Sub-Group	Page No.
CABLE ASSEMBLY—Tail and Signal Lamp Extension	0606	146
CABLE ASSEMBLY—Tail Lamp	0608	159
CABLE ASSEMBLY—Volt Meter Lamp	0605	142
CABLE ASSEMBLY—Volt Meter Switch to Ground	0605	142
CABLE ASSEMBLY—Volt Meter Switch to Meter	0605	142
CABLE ASSEMBLY—Winch	1905	452
CAGE—Front Axle Universal Drive Ball	1005	221
CAGE—Power Take-off Pump Ball Check		455
CAGE AND CUP ASSEMBLY—Rear Axle Drive Pinion Outer Bearing	1104	243
CAGE AND CUP ASSEMBLY—Transfer Case Drive Pinion Bearing	0802	188
CAGE AND ROLLER ASSEMBLY—Steering Gear Bearing	1403	285
CAGE ASSEMBLY—Front Axle Drive Pinion Outer Bearing	1003	229
CAM—Brake Shoe Adjusting Pin	1203	254
CAM ASSEMBLY—Distributor	0603	128-132
CAM ASSEMBLY—Distributor Drive Shaft	0603	129
CAMSHAFT ASSEMBLY	0106	18
CAP—Crankcase Breather Pipe	0107	28
CAP—Crankshaft Bearing	0102	11
CAP—Fastener Eyelet	2315	500
CAP—Front Axle Differential Case	1002	217
CAP—Front Axle Steering Knuckle Flange Upper and Lower Bearing	1006	225
CAP—Fuel Pump Diaphragm Push Rod Spring	0302	62
CAP—Fuel Pump Rocker Arm Spring	0302	61
CAP—Fuel Tank Filler	0304	73-74
CAP—Oil Pressure Relief Valve	0107	24
CAP—Propeller Shaft Spline Yoke	0901	210
CAP—Radiator Filler	0501	94
CAP—Rear Axle Differential Case	1103	239
CAP—Rear Axle Housing Vent	1101	238
CAP—Spotlight Bulb	2204	473
CAP—Steering Gear Housing	1403	283
CAP—Trailer Connector Terminal	0606	147
CAP—Transfer Case Driven Shaft Rear Bearing	0803	188
CAP—Transfer Case Idler Shaft Rear	0804	188
CAP—Transfer Case Main Shaft Front	0802	188
CAP—Transfer Case Vent Nipple	0801	188
CAP—Transmission Gearshift Lever	0706	170
CAP—Transmission Gearshift Lever Ball	0706	173
CAP—Wheel Hub	1302	275
CAP—Wheel Hub Cap Grease	1302	275
CAP—Windshield Frame Pivot	1801	343
CAP AND CARRIER ASSEMBLY—Front Axle Drive Pinion	1003	218
CAP AND CARRIER ASSEMBLY—Rear Axle Drive Pinion	1104	242
CAP ASSEMBLY—Distributor	0603	126-129
		130
CAP ASSEMBLY—Radiator Filler	0501	94
CAP ASSEMBLY—Radiator Overflow Tank Filler	0501	102
CAP ASSEMBLY—Transfer Case Idler Shaft Front	0804	188
CAP ASSEMBLY—Windshield Frame	1801	368
CAP ASSEMBLY—Windshield Side Arm Pivot	1801	342-368
CARBURETOR ASSEMBLY	0301	52
CARRIER—Transfer Case Declutch Shaft	0805	188
CARRIER AND AXLE HOUSING TUBE ASSEMBLY—Rear Axle Differential	1103	239
CARRIER AND CAP ASSEMBLY—Front Axle Drive Pinion	1003	218
CARRIER AND CAP ASSEMBLY—Rear Axle Drive Pinion	1104	242
CARRIER AND DIFFERENTIAL ASSEMBLY—Front Axle	1002	217

C—Continued	Sub-Group	Page No.
CARRIER AND DIFFERENTIAL ASSEMBLY—Rear Axle	1103	239
CARRIER AND PLATE ASSEMBLY—Spare Tire		376
CARTRIDGE—Oil Filter	0107	31
CASE—Map		378
CASE—Transmission	0701	166-173
CASE AND COVER ASSEMBLY—Transfer	0801	178-188
CASE ASSEMBLY—Front Axle Differential	1002	217
CASE ASSEMBLY—Rear Axle Differential	1103	239
CASE ASSEMBLY—Transfer	0800	178-188-191
CASING—Tail Lamp Cable	0608	159
CATCH—Cowl Hood Lock	1807	347
CATCH—Cowl Hood Prop	1807	347
CATCH—Dash Hood Lock	1807	417
CATCH—Dash Hood Lock Latch		337
	1807	417
CATCH—Hood Lock	1704	325
	1807	372-395-433
CATCH—Hood Prop	1704	326
	1807	372-395
CATCH—Hood Windshield	1704	326
CATCH—Tail Gate Chain		362
CATCH AND PLATE—Tail Gate Staff	1807	355
CENTRALIZER—Manifold Fuel	0108	32
CHAIN—Chain Case Timing	0106	19
CHAIN—Power Take-off Stop	2001	454
CHAIN—Tailgate Adjusting and Spreader		361
CHAIN—Tailgate Hinge Pin Retaining		361
CHAIN AND COVER ASSEMBLY—Lazy Back Seat	1804	353
CHAIN AND COVER ASSEMBLY—Tail Gate	1807	354
CHAIN AND HOOK ASSEMBLY—Tailgate		362
CHAIN AND PIN ASSEMBLY—Tailgate Hinge		361
CHAIN ASSEMBLY—Tail Gate	1807	373-396
CHAIR—Radio Operator's	1804	408
CHAMBER ASSEMBLY—Distributor Vacuum	0603	133
CHANNEL—Door Glass Rear Run	1805	332-387-424
CHANNEL—Front Door Glass Lower	1805	411
CHANNEL—Spare Tire Lock		440
CHANNEL—Spare Tire Support		441
CHANNEL AND BAR ASSEMBLY—Driver's Seat Anchor Pivot and Tilt		444
CHANNEL ASSEMBLY—Door Glass Front Run	1805	332-387-424
CHANNEL ASSEMBLY—Door Glass Lower	1805	332-387-424
CHANNEL ASSEMBLY—Front Door Glass Front Run	1805	411
CHANNEL ASSEMBLY—Front Door Glass Rear	1805	411
CHANNEL ASSEMBLY—Map Board Guide		378
CHANNEL ASSEMBLY—Map Table	1807	418
CHANNEL ASSEMBLY—Map Table Slide	1807	348-374-399-434
CHANNEL ASSEMBLY—Side Window Glass Lower	1805	388
CHECK ASSEMBLY—Door		441
CHECK ASSEMBLY—Lift Gate	1807	397
CHOKE CONTROL	0303	71
CLAMP—Battery Hold-down	1803	371-385
CLAMP—Blackout Lamp Mounting	0608	153
CLAMP—Booster Brake Hose	1210	270
CLAMP—Booster Brake Supply Tank Hose	1210	270
CLAMP—Carburetor Air Shutter Bracket Wire	0301	49
CLAMP—Crankcase Breather Pipe	0107	28
CLAMP—Distributor Breaker Plate Bearing	0603	127-131
CLAMP—Distributor Filter Screw	0603	126

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

C—Continued	Sub-Group	Page No.
CLAMP—Distributor Terminal Screw	0603	126-129-130
CLAMP—Exhaust Pipe Bracket	0402	83
CLAMP—Fuel Tank Filler Tube Hose	0304	73
CLAMP—Generator Regulator Terminal Screw	0601	106
CLAMP—Headlamp Cable and Socket Junction Block Terminal	0607	151
CLAMP—Hose	2315	500
CLAMP—Ignition Lock Switch Terminal Screw	0604	139
CLAMP—Muffler Tail Pipe	0402	85
CLAMP—Oil Filter	0107	30
CLAMP—Propeller Shaft Universal Joint Bearing	0902	209
CLAMP—Propeller Shaft Universal Joint Bushing	0902	209
CLAMP—Propeller Shaft Universal Joint Dust Cover	0902	212
CLAMP—Radiator Inlet and Outlet Hose	0505	101
CLAMP—Signal Lamp Switch Terminal	0608	157
CLAMP—Steering Gear Column Jacket	1403	284
CLAMP—Steering Post Bracket	1405	286
CLAMP—Steering Post Bracket Inner	1405	286
CLAMP—Steering Tie Rod End	1402	282
CLAMP—Tail and Signal Lamp Mounting	0608	155
CLAMP—Throttle Control Cables Dash Bracket	0303	69
CLAMP—Trailer Electric Brake Control Switch	0604	138
CLAMP—Volt Meter Mounting	0605	141
CLAMP—Water Pump By-pass Hose	0503	97
CLAMP ASSEMBLY—Battery	1803	407
CLAMP ASSEMBLY—Heater Defroster	2204	473
CLAMP ASSEMBLY—Ignition Coil Mounting	0604	134-139
CLAMP ASSEMBLY—Ignition Coil Spark Plug Cable Shield	0604	137
CLEVIS—Adjustable Rod End	2315	500
CLEVIS—Power Take-off Piston Rod	2001	454
CLEVIS—Side Control Rod	----	361
CLIP—Accelerator Shaft to Throttle Control Bell Crank	0303	68
CLIP—Blackout Driving Lamp Bulb Retainer Ring	0608	153
CLIP—Booster Brake Supply Tank Hose	1210	270
CLIP—Brake Front Hose to Steering Knuckle	1209	266
CLIP—Brake Hose Spring Clip	1209	266
CLIP—Brake Tee on Front Axle to Wheel Cylinder Tube	1209	269
CLIP—Brake Tube	1209	267-268-269
CLIP—Brake Wheel Cylinder Tube	1209	267
CLIP—Carburetor to Distributor Vacuum Control Tube	0301	56
CLIP—Closed Type	2315	500
CLIP—Distributor Breaker Arm Spring	0603	131
CLIP—Distributor Breaker Plate Arm Spring	0603	127-129
CLIP—Door Garnish Moulding	1807	415
CLIP—Door Glass Run	1805	336-392-409-428
CLIP—Door Lower Weatherstrip	1805	337-393-414-430
CLIP—Door Weatherstrip	1807	415
CLIP—Front Axle Brake Tube	1209	268
CLIP—Front Rear Axle Brake Tube	1209	268
CLIP—Front Spring	1601	306
CLIP—Fuel Pump Rocker Arm Link Pin	0302	61
CLIP—Generator to Regulator Cable	0601	106
	2205	477
CLIP—Hand Brake Band Anchor	1201	250
CLIP—Hand Brake Cable to Frame	1201	249
CLIP—Head Lamp Cable	0607	151
CLIP—Hood Prop Rod	1704	326
CLIP—Ignition Lock Switch Cable Mounting	0604	139
CLIP—Instrument Panel	1807	399-417-433
CLIP—Instrument Panel Wiper Tube	1807	348
CLIP—Instrument Panel Wiring	1807	339-348-374
CLIP—Lift Gate Weatherstrip	1807	397
CLIP—Radiator Overflow Tank Inlet Tube	0501	102
CLIP—Rear Axle Brake Tube	1209	268
CLIP—Rear Rear Axle Brake Tube	1209	268
CLIP—Rear Spring	1601	307
CLIP—Roof Center Bow to Lazy Back	2310	496
CLIP—Seat Back Cushion Cover	1804	386
CLIP—Seat Cushion Cover	1804	346-386-408
CLIP—Seat Side Arm Cover	1804	408
CLIP—Side Window Glass Run	1805	392
CLIP—Starter Cable Mounting	0610	162
CLIP—Starting Motor Pedal Rod Pin	0602	120-123
CLIP—Steering Post Bracket	1405	286
CLIP—Tailgate Hinge Pin Lock	....	361
CLIP—Tailgate Weatherstrip	1807	397
CLIP—Throttle Control Wire Tube Bracket	0303	70
CLIP—Wheel Hub Cap Spring	1302	275
CLIP—Window Garnish Moulding	1807	398
CLIP—Window Lift-up Panel Moulding	1807	398
CLIP—Windshield	1801	328
CLIP—Windshield Frame	1801	367-404-420
CLIP—Windshield Frame Joint	1801	382
CLIP—Windshield Frame Tube	1801	342-368
CLIP—Windshield Side Arm	1801	342
CLIP—Windshield Wiper	1801	369-406
CLIP—Windshield Wiper Tube	1801	343-384-422
CLIP—Windshield Wiper Tube on Frame	1801	369
CLIP—Windshield Wiper Tube on Pivot Bracket	1801	369
CLIP—Windshield Wiper Tube Support Frame	1801	369
CLIP ASSEMBLY—Headlamp Cable and Socket	0607	152
CLUTCH—Transfer Case Declutch Shaft Sliding	0805	188
CLUTCH—Winch Sliding	....	449-451
CLUTCH AND PINION ASSEMBLY—Starting Motor	0602	118-121
COIL AND FRAME—Generator Regulator Circuit Breaker	0601	110
COIL AND FRAME—Generator Regulator Current Regulator	0601	110
COIL ASSEMBLY—Generator Field	0601	107-111-113
COIL ASSEMBLY—Generator Regulator Circuit Breaker	0601	110
COIL ASSEMBLY—Generator Regulator Current Regulator	0601	110
COIL ASSEMBLY—Generator Regulator Voltage Regulator	0601	110
COIL ASSEMBLY—Ignition	0604	134-139
COIL ASSEMBLY—Starting Motor Field	0602	118-121
COLLAR—Carburetor Vacuum Pump	0301	49
COLLAR—Clutch Pedal Adjusting	0204	44
COLLAR—Distributor Drive Shaft	0603	128-129-132
COLLAR—Starting Motor Pinion and Clutch Shift	0602	118-121
COLLAR—Steering Gear Jacket	1403	285
COLLAR—Winch to Power Take-off Propeller Shaft	2010	461
COLLAR ASSEMBLY—Winch Universal Drive Shaft	1901	452
CONDENSER—Battery Terminal	2205	477
CONDENSER—Distributor Breaker Plate	0603	127-129-131
CONDENSER—Generator Regulator	0601	112
CONDENSER—Radio	2204	474
CONDENSER—Radio Interference	0601	111
	0605	141

ALPHABETICAL INDEX—Continued

C—Continued	Sub-Group	Page No.
CONDENSER—Roof Ventilator Fan Motor Radio Interference	2204	474
CONDENSER—Starting Motor Radio Interference	0602	121
CONDENSER ASSEMBLY—Ignition Lock Switch Interference	0605	141
CONDENSER ASSEMBLY—Ignition Lock Switch Radio Interference	0604	139
CONDENSER ASSEMBLY—Radio Interference	0605	141
CONDENSER ASSEMBLY—Starter	2205	478
CONDENSER ASSEMBLY—Starting Motor	0602	118
CONDUIT AND CABLE ASSEMBLY—Battery to Terminal Box	0610	161
CONE—Front Axle Differential Bearing	1002	217
CONE—Front Axle Drive Bearing	1003	228
CONE—Front Axle Drive Pinion Bearing	1003	219
CONE—Front Axle Drive Pinion Outer Bearing	1003	229
CONE—Front Axle Steering Knuckle Flange Upper and Lower Bearing	1006	225
CONE—Power Take-off Drive Shaft Bearing	2010	461
CONE—Rear Axle Differential Bearing	1103	240
CONE—Rear Axle Drive Pinion Front Bearing	1104	242
CONE—Rear Axle Drive Pinion Outer Bearing	1104	243
CONE—Rear Axle Drive Pinion Rear Bearing	1104	242
CONE—Rear Axle Drive Shaft Bearing	1102	239
CONE—Transfer Case Declutch Shaft Bearing	0805	188
CONE—Transfer Case Drive Gear Shaft Bearing	0802	179
CONE—Transfer Case Drive Pinion Bearing	0802	188
CONE—Transfer Case Driven Gear Shaft Bearing	0803	180-188
CONE—Transfer Case Driven Shaft Bearing	0803	191
CONE—Transfer Case Idler Gear Bearing	0803	191
CONE—Transfer Case Idler Gear Shaft Bearing	0804	181-188
CONE—Transfer Case Main Shaft Bearing	0802	188
CONE—Wheel Bearing	1301	272-273
CONE AND ROLLER—Power Take-off Taper Roller Bearing	2010	459
CONE AND ROLLER—Rear Spring Trunnion Bearing	1602	312
CONE AND ROLLER—Winch Worm Thrust Bearing		449-451
CONNECTION—Brake Wheel Cylinder Inlet	1207	259-260
	1209	268
CONNECTION—Inverted Flared Tube	2315	500
CONNECTION—Power Take-off High Pressure		455
CONNECTION—Wheel Cylinder Inlet	1209	268
CONNECTOR—Battery to Terminal Box Cable	0610	161
CONNECTOR—Blackout Lamp Socket and Cable	0606	154
CONNECTOR—Brake Wheel Cylinder Inlet	1209	268
CONNECTOR—Distributor Filter	0603	126
CONNECTOR—Generator Regulator Terminal	0601	110
CONNECTOR—Master Cylinder Brake Tube	1209	268
CONNECTOR—Oil Filter to Engine Tube	0107	31
CONNECTOR—Oil Suction Pipe	0107	24
CONNECTOR—Starting Motor Field Coil	0602	119-121
CONNECTOR—Tail Lamp to Trailer "Y"	0604	138
CONNECTOR—Truck Wiring Cable	2313	499
CONNECTOR ASSEMBLY—Head Lamp	0607	150
CONNECTOR ASSEMBLY—Starting Motor Brush Hand	0602	122
CONNECTOR ASSEMBLY—Trailer	0606	146
CONTACT—Head Lamp Beam Indicator Socket Cable	0607	152
CONTACT—Head Lamp Cable Terminal Plug	0607	151
CONTACT—Horn Button Cable	0609	161
CONTACT—Instrument Lamp Socket Cable	0605	141
CONTACT—Starting Motor Switch	1602	120-123
CONTACT—Voltmeter Lamp	0605	142
CONTACT AND ARMATURE ASSEMBLY—Generator Regulator	0601	110-116
CONTACT ASSEMBLY—Tail Lamp Cable	0608	158
CONTROL—Door Lock Remote	1805	391-428
CONTROL ASSEMBLY—Door Remote	1805	409

C—Continued	Sub-Group	Page No.
CORE ASSEMBLY—Radiator	0501	94
CORK—Front Axle Drive Pinion Outer Bearing Seal Retainer	1003	229
CORK—Rear Axle Drive Pinion Outer Bearing Seal Retainer	1104	243
COTTER—Attendant's Seat Yoke		444
COTTER—Sub Frame Body Hinge Shaft		359
COUNTERSHAFT—Transmission	0704	168-173
COUPLING—"Y" Windshield Wiper	1801	369
COVER—Battery	1803	331-371
COVER—Body to Rear Fender Front Shield Frame	1702	322
COVER—Brake Master Cylinder	1205	257
COVER—Chassis Wiring Junction Block	0606	146
COVER—Clutch	0202	42
COVER—Curtain Latch Handle Spring		376
COVER—Door Upper Wedge	1805	429
COVER—Door Upper Wedge Plate	1805	337
COVER—Door Wedge	1805	393-410
COVER—Drag Link Ball Dust	1401	280
COVER—Drag Link Dust	1401	280
COVER—Floor Transmission	1802	385
COVER—Floor Transmission Cover Center Floor Panel	1802	423
COVER—Floor Transmission Cover Panel	1802	423
COVER—Front Axle Housing	1001	216
COVER—Front Axle Steering Knuckle Tie Rod End Dust		227-230
COVER—Front Fender Grille Crank Hole	1701	320
COVER—Front Side Compartment	1807	354
COVER—Fuel Pump Bottom	0302	61
COVER—Fuel Tank Filler Tube Hole	0304	73-74
COVER—Generator Commutator End Cap	0601	108-111
		114
COVER—Generator Commutator Oil Wick	0601	107
COVER—Generator Regulator	0601	110
COVER—Headlamp Cable Grommet	0607	151
COVER—Longitudinal Side Seat		442
COVER—Oil Pump	0107	23
COVER—Power Take-off	2010	462
COVER—Power Take-off Cylinder Trunnion Port Hole	2001	454
COVER—Power Take-off Pump		455
COVER—Propeller Shaft Universal Joint Bushing Lock Plate	0902	209
COVER—Propeller Shaft Universal Joint Cross Bushing Lock Plate	0902	211
COVER—Propeller Shaft Universal Joint Grease	0902	211
COVER—Rear Axle Housing	1101	238
COVER—Rear Spring Rear	1601	309
COVER—Rear Spring Trunnion Bearing Housing	1602	313
COVER—Seat Back	1804	371
COVER—Seat Cushion	1804	332-346-371-386-408
COVER—Seat Cushion Clip	1804	386
COVER—Seat Side Arm	1804	346-408
COVER—Seat Wheel Housing Arm Rest	1804	371
COVER—Side Curtain Latch Spring	2310	496
COVER—Side Panel Fuel Tank Hole	1807	434
COVER—Steering Gear Jacket Oil Hole	1403	285
COVER—Steering Tie Rod End Dust	1402	281
COVER—Step Release Lock		443
COVER—Tailgate Chain		362
COVER—Tail Lamp Cable Connector	0608	158
COVER—Transfer Case Declutch Shaft Carrier	0805	188
COVER—Transfer Case Driven Shaft Rear Bearing	0803	188
COVER—Transfer Case Gear Shifter	0806	189
COVER—Transfer Case Idler Gear Shaft	0804	191
COVER—Transfer Case Idler Shaft Rear	0804	188
COVER—Transfer Case Main Shaft Front	0802	188

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

C—Continued	Sub-Group	Page No.
COVER—Valve Spring	0105	17
COVER—Wheel Brake Drum Inspection Hole	1302	274
COVER AND BUSHING ASSEMBLY—Winch Worm Housing	....	449-451
COVER AND CASE ASSEMBLY—Transfer	0801	178-188
COVER AND CHAIN ASSEMBLY—Lazy Back Seat	1804	353
COVER AND CHAIN ASSEMBLY—Tailgate	1807	354
COVER AND HOOK ASSEMBLY—Tailgate	....	378
COVER AND OIL SEAL ASSEMBLY—Front Axle Drive Pinion Outer Bearing	1003	228
COVER AND OIL SEAL ASSEMBLY—Rear Axle Drive Pinion Outer Bearing	1104	243
COVER AND PRESSURE PLATE ASSEMBLY—Clutch	0202	42
COVER AND SPRING ASSEMBLY—Seat Back	1804	346-408
COVER ASSEMBLY—Auxiliary Seat Back Cushion	1804	387
COVER ASSEMBLY—Auxiliary Seat Cushion	1804	386-387
COVER ASSEMBLY—Battery	1803	344-385-407
COVER ASSEMBLY—Carburetor Fuel Bowl	0301	49
COVER ASSEMBLY—Center Seat Back Cushion	1804	387
COVER ASSEMBLY—Center Seat Cushion	1804	386
COVER ASSEMBLY—Chain Case	0106	19
COVER ASSEMBLY—Door Arm Rest	1807	341
COVER ASSEMBLY—Driver's Compartment	1807	349
COVER ASSEMBLY—Driver's Seat Back Cushion	1804	387
COVER ASSEMBLY—Driver's Seat Cushion	1804	386
COVER ASSEMBLY—Front Floor Transmission	1802	345
COVER ASSEMBLY—Front Spring Front	1601	308
COVER ASSEMBLY—Front Spring Rear	1601	308
COVER ASSEMBLY—Fuel Pump Top	0302	60
COVER ASSEMBLY—License Lamp	0608	157
COVER ASSEMBLY—Oil Filter	0107	31
COVER ASSEMBLY—Propeller Shaft Universal Joint Dust	0902	212
COVER ASSEMBLY—Rear Seat Back Cushion	1804	387
COVER ASSEMBLY—Rear Spring Front	1601	308
COVER ASSEMBLY—Rear Spring Rear	1601	308
COVER ASSEMBLY—Seat Back	1804	332-346 371-408
COVER ASSEMBLY—Seat Cushion	1804	346-386-408
COVER ASSEMBLY—Trailer Connector	0606	146
COVER ASSEMBLY—Transfer Case Idler Shaft Front	0804	188
COWL	1807	347-372-417-337
CRANK—Power Take-off Valve Control Bell	2001	454-457
CRANK ASSEMBLY—Starting	2306	487-488-489
CRANKSHAFT ASSEMBLY	0102	10
CROSS—Propeller Shaft Universal Joint	0902	211
CROSS AND SEAL ASSEMBLY—Propeller Shaft Universal Joint	0902	208
CROSS ASSEMBLY—Propeller Shaft Universal Joint	0902	208
CROSS PIECE—Windshield Frame Upper	1801	342
CROSS PIECE ASSEMBLY—Windshield Frame	1801	368
CROSSBAR AND SUPPORT ASSEMBLY—License Lamps and License Bracket	0608	157
CROSSMEMBER—Frame Intermediate	1506	298-300
CROSSMEMBER—Frame Rear	1506	300
CROSSMEMBER—Frame Transfer Case	1506	296
CROSSMEMBER—Frame Trunnion Bracket	1506	300
CROSSMEMBER—Fuel Tank Support	1506	298
CROSSMEMBER—Sub Frame Front	....	359
CROSSMEMBER—Sub Frame Rear	....	359
CROSSMEMBER ASSEMBLY—Frame	1506	297-298
CROSSMEMBER ASSEMBLY—Frame Front Support	1506	296
CROSSMEMBER ASSEMBLY—Frame Intermediate	1506	298
CROSSMEMBER ASSEMBLY—Frame Rear	1506	298-300
CUP—Brake Master Cylinder Piston	1205	258-261-262
CUP—Brake Wheel Cylinder Piston	1207	261-262
CUP—Front Axle Differential Bearing	1002	217
CUP—Front Axle Drive Bearing	1003	228
CUP—Front Axle Drive Pinion Bearing	1003	219
CUP—Front Axle Drive Pinion Outer Bearing	1003	229
CUP—Front Axle Steering Knuckle Flange Bearing	1006	225
CUP—Grease	2311	497
CUP—Hand Brake Lever Pawl Rod to Spring	1201	248
CUP—Hinge Lid Drive Oil	2311	497
CUP—Power Take-off Drive Shaft Bearing	2010	461
CUP—Power Take-off Taper Roller Bearing	2010	459
CUP—Rear Axle Differential Bearing	1103	240
CUP—Rear Axle Drive Pinion Front Bearing	1104	242
CUP—Rear Axle Drive Pinion Outer Bearing	1104	243
CUP—Rear Axle Drive Pinion Rear Bearing	1104	242
CUP—Rear Axle Drive Shaft Bearing	1102	239
CUP—Rear Spring Trunnion Bearing	1602	312
CUP—Steering Gear Lower Bearing	1403	285
CUP—Steering Gear Upper Bearing	1403	285
CUP—Transfer Case Declutch Shaft Bearing	0805	188
CUP—Transfer Case Drive Gear Shaft Bearing	0802	179
CUP—Transfer Case Drive Pinion Bearing	0802	188
CUP—Transfer Case Driven Gear Shaft Bearing	0803	180-181-188
CUP—Transfer Case Driven Shaft Bearing	0803	191
CUP—Transfer Case Idler Gear Bearing	0803	191
CUP—Transfer Case Idler Gear Shaft Bearing	0804	181-188
CUP—Transfer Case Main Shaft Bearing	0802	188
CUP—Wheel Bearing	1301	272-273
CUP—Winch Worm Thrust Bearing	....	449-451
CUP AND CAGE ASSEMBLY—Rear Axle Drive Pinion Outer Bearing	1104	243
CUP AND CAGE ASSEMBLY—Transfer Case Drive Pinion Bearing	0802	188
CUP AND NUT ASSEMBLY—Fuel Filter Retainer	0302	65
CUP AND STUD ASSEMBLY—Rear Spring Trunnion Bearing Housing	1602	312
CURTAIN	....	362
CURTAIN—Roof Paulin End	2310	495-496
CURTAIN—Side	....	376-377
CURTAIN—Side Front	2310	496
CURTAIN ASSEMBLY—Folding Top Back	....	377
CURTAIN ASSEMBLY—Side	....	376
CURTAIN ASSEMBLY—Side Rear	2310	496
CUSHION—Seat	1804	346-371
CUSHION AND SEAT ASSEMBLY	1804	371
CUSHION ASSEMBLY—Auxiliary Seat	1804	386
CUSHION ASSEMBLY—Auxiliary Seat Back	1804	387
CUSHION ASSEMBLY—Center Seat	1804	386
CUSHION ASSEMBLY—Center Seat Back	1804	387
CUSHION ASSEMBLY—Driver's Seat	1804	386
CUSHION ASSEMBLY—Driver's Seat Back	1804	387
CUSHION ASSEMBLY—Rear Seat	1804	386
CUSHION ASSEMBLY—Seat	1804	332-346-371-408
CUSHION ASSEMBLY—Seat Back	1804	371-387
CYLINDER—Door Lock	1805	335-390-413-427
	1807	415
CYLINDER—Tail Gate Lock	1805	371-391
CYLINDER—Tire Carrier Lock	1505	295
CYLINDER AND KEY—Door Lock	1805	335-390-413-427
	1807	415

ALPHABETICAL INDEX—Continued

C—Continued	Sub-Group	Page No.
CYLINDER AND KEY—Ignition Coil Lock	0604	135
CYLINDER AND KEY—Tire Carrier Lock	1505	295
CYLINDER ASSEMBLY—Booster Brake Master	1210	270
CYLINDER ASSEMBLY—Booster Brake Operating	1210	270
CYLINDER ASSEMBLY—Brake Master	1205	257
CYLINDER ASSEMBLY—Brake Wheel	1207	259-260
CYLINDER ASSEMBLY—Door Lock	1805	335-390-427
CYLINDER ASSEMBLY—Front Axle Brake Wheel	...	227
CYLINDER ASSEMBLY—Ignition Coil Lock	0604	135
CYLINDER ASSEMBLY—Ignition Lock	0604	139
CYLINDER ASSEMBLY—Master	1205	257
CYLINDER ASSEMBLY—Power Take-off	2001	454

D

DECK—Folding Top	2310	496
DEFLECTOR—Radiator Side Air	0504	100
DEFLECTOR AND LID ASSEMBLY—Cowl Ventilator	1807	374
DEFLECTOR ASSEMBLY—Front Fender Grille Air	1701	320
DEFLECTOR ASSEMBLY—Radiator Support Air	0504	100
DIAL—Ammeter and Fuel Gauge	0605	140
DIAL—Ammeter Gauge	0605	141
DIAL—Fuel Gauge Glass	0605	142
DIAL—Heat Indicator and Oil Gauge	0605	140
DIAL—Oil Gauge	0605	143
DIAL—Radimeter Glass	0502	95
DIAL—Speedometer Face	2203	472
DIAL—Thermometer Glass	0605	143
DIAPHRAGM ASSEMBLY—Fuel Pump	0302	61
DIAPHRAHM ASSEMBLY—Horn	0609	160
DIFFERENTIAL AND CARRIER ASSEMBLY—Front Axle	1002	217
DIFFERENTIAL AND CARRIER ASSEMBLY—Rear Axle	1103	239
DIFFERENTIAL ASSEMBLY—Front Axle	1002	217
DIFFERENTIAL ASSEMBLY—Rear Axle	1103	239
DISC—Carburetor Fuel Bowl Cover Check Valve	0301	49
DISC—Front Shock Absorber Rebound Valve Spring	1603	316
DISC—Rear Shock Absorber Rebound Valve Spring	1603	316
DISC ASSEMBLY—Clutch	0201	42
DISTRIBUTOR ASSEMBLY	0603	126-129-130
DOOR—Glove Box	1807	338-346-347-372-394-416-432
DOOR—Parking Lamp	0607	152
DOOR—Spotlight	2204	473
DOOR AND LENS—Rear Compartment Lamp	....	378
DOOR ASSEMBLY	1805	388-441
DOOR ASSEMBLY—Blackout Driving Lamp	0608	153
DOOR ASSEMBLY—Blackout Lamp	0608	153
DOOR ASSEMBLY—Glove Box	1807	338-372
DOOR ASSEMBLY—Headlamp	0607	149
DOOR ASSEMBLY—Tail and Signal Lamp	0608	156
DOOR ASSEMBLY—Tool Box	....	362
DOVETAIL—Door	1805	411
DOWEL—Cylinder Block Clutch Housing	0101	8
DOWEL—Rear Axle Differential and Carrier	1103	239
DOWEL—Rear Spring Shim	1601	305
DOWEL—Starting Motor Frame Through Screw	0602	119
DRAIN COCK	2315	500
DRAIN COCK—Cylinder Block Water Jacket	0101	8
DRAIN COCK—Radiator Core	0501	94
DRIVE ASSEMBLY—Front Axle Universal	1005	220

D—Continued	Sub-Group	Page No.
DRIVER—Carburetor Throttle Lever	0301	49
DRIVER AND LEVER ASSEMBLY—Carburetor Throttle	0301	49
DRUM—Hand Brake	1201	250
DRUM—Transmission Hand Brake	1201	173
DRUM—Winch Cable	....	449-45
DRUM—Winch Safety Brake	....	449-451
DRUM AND HUB ASSEMBLY—Wheel Brake	1302	273
DRUM AND YOKE ASSEMBLY—Hand Brake	1201	250
DRUM ASSEMBLY—Wheel Brake	1302	274
DUST COVER—Transmission Gear Shift Lever	0706	170
DUST COVER—Transmission Gear Shift Lever Ball	0706	173
DUST SEAL—Clutch Housing Pan	0207	46
DUST SEAL AND PLATE ASSEMBLY—Clutch Housing	0207	46

E

ELBOW—Booster Brake Hose	1210	270
ELBOW—Booster Brake Manifold to Check Valve Tube	1210	270
ELBOW—Booster Brake Supply Tank	1210	270
ELBOW—Cylinder Water Outlet	0101	9
ELBOW—Distributor Shield Cover	0603	130
ELBOW—Inverted Flared Tube	2315	500
ELBOW—Pipe	2315	500
ELBOW—Power Take-off Cylinder Filler	2001	454
ELBOW—Street	2315	500
ELBOW—Water Pump By-Pass	0503	97
ELEMENT—Carburetor Air Cleaner	0301	57
ELEMENT—Fuel Filter	0302	65
END—Brake Master Cylinder Piston Push Rod	1205	258
END—Top Binding	2310	496
END—Transmission Gear Shift Reverse Rail	0706	171
END ASSEMBLY—Front Axle Steering Knuckle Tie Rod	....	227
END ASSEMBLY—Steering Tie Rod	1402	282
ENGINE ASSEMBLY	0100	7
EQUALIZER—Starting Motor Field Coil	0602	119
ESCUTCHEON—Door Regulator and Remote Control Handle	1805	334
ESCUTCHEON—Door Remote Control and Window Regulator Handle	1805	389
ESCUTCHEON—Door Remote Control Handle	1805	334-389-413-414
ESCUTCHEON—Door Window	1805	389
ESCUTCHEON—Door Window Regulator Handle	1805	334-41 426
ESCUTCHEON—Outside Release Handle	....	443
ESCUTCHEON—Side Window Regulator Handle	1805	389
EXPANDER—Brake Wheel Cylinder Piston Cup	1207	262
EXTENSION—Brake Pedal Pull Back Spring	1204	256
EXTENSION—Driver's Compartment Floor Mat	....	445
EXTENSION AND SIDE PANEL ASSEMBLY—Front	1807	348
EXTENSION ASSEMBLY—Chassis Wiring	0606	145
EXTENSION ASSEMBLY—Floor Mat	1802	423
EYE BOLT—Bumper	2102	465
EYE BOLT—Power Take-off	2010	459
EYE BOLT—Safety Strap	....	377
EYE BOLT—Seat Safety Strap to Cowl Eye	2310	495-496
EYE BOLT AND NUT ASSEMBLY—Clutch Release	0203	43
EYE BOLT AND PIN—Power Take-off	2010	460
EYE BOLT AND PIN—Power Take-off Shifter Shaft	2010	461
EYE BOLT AND ROD ASSEMBLY—Front Shock Absorber Link	1603	314
EYE BOLT AND ROD ASSEMBLY—Rear Shock Absorber Link	1603	314
EYE BOLT ASSEMBLY—Rear Shock Absorber Link Rod	1603	314
EYELET—Curtain Fastener	2315	500

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

F	Sub-Group	Page No.
FACING—Clutch Disc	0201	42
FAN—Generator Arm Ventilating	0601	115
FAN ASSEMBLY	0503	98
FAN ASSEMBLY—Roof Ventilator	2204	474
FASTENER—Belt Rail Trim Panel	1807	435
FASTENER—Curtain	2315	500
FASTENER—Dash Liner	1807	338-347-373-398-433
FASTENER—Dash Panel Liner	1807	417
FASTENER—Door Trim Panel	1807	339-400-416
FASTENER—Double Button	2315	500
FASTENER—Map Case Lid	----	378
FASTENER—Quarter Trim Panel	1807	435
FASTENER—Rear Belt Rail Trim Panel	1807	340
FASTENER—Rear Quarter Trim Panel	1807	341
FELT—Clutch Release Fork Flange	0203	43
FELT—Front Axle Steering Knuckle Flange Joint Oil Seal	1006	226
FELT—Front Axle Steering Knuckle Flange Oil Seal	1006	226
FELT—Rear Door Dovetail	1805	411
FENDER ASSEMBLY	1701	318
FERRULE—Tail Lamp Cable Connector	0608	158
FERRULE AND WASHER—Blackout Lamp Socket and Cable	0608	154
FILLER—Door Glass Frame	1805	333-388-412
FILLER—Door Window Glass Frame	1805	425
FILLER—Fender to Body	1701	318
FILLER—Floor Board	1802	385
FILLER—Front Fender Splash Shield to Lower Flange	1702	321
FILLER—Fuel Tank Support	0304	73
FILLER—Side Window Glass Frame	1805	389
FILLER—Windshield Glass	1801	342
FILTER—Blackout Lamp	0608	154
FILTER—Distributor Terminal Screw Primary Cable	0603	129
FILTER—Tail Lamp Blackout Lens	0608	155
FILTER—Tail Lamp Blackout Stop Light Lens	0608	155
FILTER ASSEMBLY—Distributor	0603	126
FILTER ASSEMBLY—Fuel	0302	64
FILTER ASSEMBLY—Generator Field Terminal	0601	106
FILTER ASSEMBLY—Generator Regulator Field Terminal	0601	111-112
	2205	478
FILTER ASSEMBLY—Oil	0107	30
FILTER ASSEMBLY—Radio Interference	2204	474
	2205	478
FITTING—Crankcase Ventilator Tube to Cylinder Block	0107	27
FITTING—Power Take-off Cylinder Low Pressure	2001	454
FITTING—Power Take-off Universal Joint Zerk	----	457
FITTING—Propeller Shaft Universal Joint Cross Lubricant	0902	209-211
FITTING—Sub Frame Body Hinge Zerk	----	359
FLANGE—Front Axle Universal Drive	1005	223
FLANGE—Hand Brake Drum	1201	250
FLANGE—Pintle Hook Support	1502	289
FLANGE—Power Take-off High Pressure	----	455
FLANGE—Propeller Shaft Companion (Axle End) (Transmission End)	0901	210
FLANGE—Propeller Shaft Companion (Drive Pinion All Axles) (Pillow Block) (Transfer Case Brake Drum) (Transfer Case From Transmission) (Transfer Case to Front Axle) (Transfer Case to Front Rear Axle)	0901	207

F—Continued	Sub-Group	Page No.
FLANGE—Propeller Shaft Companion (Front and Rear Axle End) (Transmission Case End) (Transfer End)	0901	206
FLANGE—Transmission Mainshaft	0901	173
FLANGE ASSEMBLY—Carburetor Body	0301	52
FLANGE ASSEMBLY—Clutch Release Fork	0203	43
FLANGE ASSEMBLY—Front Axle Steering Knuckle	1006	224
FLOAT AND HINGE ASSEMBLY—Carburetor	0301	49
FLOAT ASSEMBLY—Carburetor	0301	55
FLUID—Hydraulic Brake	2301	482
FLYWHEEL AND RING GEAR ASSEMBLY	0108	33
FORK—Clutch Release	0203	43
FORK—Power Take-off Shift	2010	459-460-461
FORK—Power Take-off Shifter Shaft	2010	458
FORK—Transfer Case Declutch Shaft Sliding Clutch Shift	0805	186
FORK—Transfer Case Gear Shifter	0806	189
FORK—Transfer Case Shift	0805	191
	0806	184-189
FORK—Transmission Gear Shift	0706	171
FORK—Transmission Gear Shift Reverse Shift	0706	171
FORK—Winch Shifter	----	449-451
FORK AND RAIL ASSEMBLY—Transmission Gear Shift Low and Reverse	0706	173
FRAME—Auxiliary Seat	1804	385
FRAME—Door Glass	1805	333-388-412
FRAME—Door Ventilator Wing Glass	1805	425
FRAME—Door Window Glass	1805	425
FRAME—Folding Top Back Window	----	377
FRAME—Side Window Glass	1805	389
FRAME—Top Rear Window Glass	2310	496
FRAME AND BRACKET ASSEMBLY—Windshield Support	1801	368
FRAME AND COIL—Generator Regulator Circuit Breaker	0601	110
FRAME AND COIL—Generator Regulator Current Regulator	0601	110
FRAME AND GLASS ASSEMBLY—Windshield	----	376
FRAME ASSEMBLY	1506	296-297
FRAME ASSEMBLY—Folding Top	----	376
	2310	496
FRAME ASSEMBLY—Side Curtain	----	377
FRAME ASSEMBLY—Windshield	1801	328-342-368-382-404-420
FRONT ASSEMBLY—Body	----	376

G

GARNISH—Door Glass	----	442
GASKET—Ammeter Gauge Dial	0605	141
GASKET—Annular	2315	500
GASKET—Blackout Lamp Door	0608	153
GASKET—Blackout Lamp Mounting	0608	153
GASKET—Bleeder Hose	2306	487-488
GASKET—Brake Hose to Front Wheel Cylinder	1209	266
GASKET—Brake Master Cylinder Cover Screw	1205	257
GASKET—Brake Master Cylinder Cover to Body	1205	257
GASKET—Brake Support Oil Slinger	1203	253
GASKET—Brake Wheel Cylinder Bracket Hose	1207	260
GASKET—Brake Wheel Cylinder Inlet Connection	1207	259-261
GASKET—Brake Wheel Cylinder Inlet Connection Bolt	1207	260-261
GASKET—Carburetor Air Cleaner	0301	57
GASKET—Carburetor Body Flange	0301	52
GASKET—Carburetor Body to Air Horn	0301	52

ALPHABETICAL INDEX—Continued

G—Continued	Sub-Group	Page No.
GASKET—Carburetor Bowl to Cover	0301	49
GASKET—Carburetor Flange Adaptor	0301	52
GASKET—Carburetor Flange to Governor	0301	52
GASKET—Carburetor Flange to Manifold	0301	49-52
GASKET—Carburetor Float Needle Seat	0301	52
GASKET—Carburetor Fuel Bowl to Intake	0301	49
GASKET—Carburetor Main Metering Jet	0301	52
GASKET—Carburetor Step Up Jet	0301	52
GASKET—Carburetor Step Up Piston	0301	52
GASKET—Carburetor Throttle Body to Intake	0301	49
GASKET—Carburetor Throttle Lever and Driver	0301	49
GASKET—Chain Case Cover	0106	19
GASKET—Chain Case Cover Oil Seal	0106	19
GASKET—Chain Case Cover Plate	0106	19
GASKET—Chassis Wiring Junction Block Insulator and Block Mounting	0606	146
GASKET—Crankcase Breather Pipe Air Cleaner	0107	29
GASKET—Crankcase Ventilator Outlet Pipe	0107	26
GASKET—Crankcase Ventilator Outlet Pipe Air Cleaner	0107	26
GASKET—Crankcase Ventilator Tube to Cylinder Block Fitting	0107	27
GASKET—Crankcase Ventilator Tube to Cylinder Block Fitting Screw	0107	27
GASKET—Crankshaft Rear Bearing Cap	0102	11
GASKET—Crankshaft Rear Bearing Oil Seal Retainer	0102	11
GASKET—Cylinder Head	0101	9
GASKET—Cylinder Water Outlet Elbow	0101	9
GASKET—Distributor Vacuum Chamber	0603	129
GASKET—Distributor Vacuum Chamber Plug	0603	133
GASKET—Dome Lamp	....	440
GASKET—Exhaust Pipe Flange	0402	83
GASKET—Front Axle Differential and Axle Housing Tube	1002	228
GASKET—Front Axle Drive Pinion Carrier	1003	219
GASKET—Front Axle Housing Cover	1001	216
GASKET—Front Axle Steering Knuckle Flange Lower Bearing Cap	1006	225
GASKET—Front Axle Steering Knuckle Flange Oil Seal	1006	226
GASKET—Front Axle Universal Drive Flange	1005	223
GASKET—Fuel Filter Bowl	0302	65
GASKET—Fuel Filter Element and Bowl Stud Nut	0302	65
GASKET—Fuel Gauge Glass Dial	0605	142
GASKET—Fuel Pump Bottom Cover	0302	61
GASKET—Fuel Pump Diaphragm Oil Seal	0302	62
GASKET—Fuel Pump Diaphragm Push Rod	0302	62
GASKET—Fuel Pump Mounting Flange	0302	60
GASKET—Fuel Pump Strainer Bowl	0302	63
GASKET—Fuel Pump Top Cover Air Dome	0302	61
GASKET—Fuel Pump Top Cover Valve Plug	0302	60
GASKET—Fuel Tank Filler Cap	0304	73-74
GASKET—Fuel Tank Filler Tube	0304	73
GASKET—Fuel Tank Fuel Gauge	0304	72
GASKET—Generator Commutator End	0601	108-114
GASKET—Generator Commutator End Cap Cover	0601	111
GASKET—Generator Commutator End Oil Retaining	0601	108
GASKET—Generator Drive End Head Ball Bearing Retainer	0601	114
GASKET—Generator Regulator Cover Mounting	0601	110
GASKET—Generator Regulator Terminal Slot	0601	110
GASKET—Hand Brake Support	1201	249
GASKET—Head Lamp Lens	0607	149
GASKET—Head Lamp Reflector	0607	150
GASKET—Heat Indicator and Oil Gauge	0605	140
GASKET—Horn	0609	160
GASKET—Ignition Coil Mounting	0604	134
GASKET—Instruments Bezel	0605	140
GASKET—Instruments Housing	0605	140
GASKET—Intake to Exhaust Manifold	0108	32

G—Continued	Sub-Group	Page No.
GASKET—Manifold	0108	32
GASKET—Oil Filter Cartridge	0107	31
GASKET—Oil Filter Cover	0107	31
GASKET—Oil Filter Cover Screw	0107	31
GASKET—Oil Filter Drain Plug	0107	31
GASKET—Oil Gauge Dial	0605	143
GASKET—Oil Pan Drain Plug	0107	25
GASKET—Oil Pan Front Oil Seal Plate	0107	25
GASKET—Oil Pressure Relief Valve Cap	0107	24
GASKET—Oil Pump Cover	0107	23
GASKET—Oil Pump to Cylinder Block	0107	22
GASKET—Parking Lamp Lens	0607	152
GASKET—Power Take-off	2010	460
GASKET—Power Take-off Cover	2010	462
GASKET—Power Take-off Cylinder Head	2001	454
GASKET—Power Take-off Cylinder Trunnion Port Hole Cover	2001	454
GASKET—Power Take-off End Plate	2010	459-46 461
GASKET—Power Take-off Pump Ball Check	...	455
GASKET—Power Take-off Pump Ball Check Plug	....	455
GASKET—Power Take-off Pump Body	....	455
GASKET—Power Take-off Pump Port Hole Flange	....	455
GASKET—Power Take-off to Transmission	2010	459-461-462
GASKET—Propeller Shaft Universal Joint Cross Grease Plug	0902	209
GASKET—Propeller Shaft Universal Joint Grease Cover	0902	211
GASKET—Radimeter Glass Dial	0502	95
GASKET—Rear Axle Differential and Carrier Housing Tube	1103	239
GASKET—Rear Axle Drive Pinion Carrier	1104	242
GASKET—Rear Axle Drive Shaft	1102	238
GASKET—Rear Axle Drive Shaft Oil Seal Retainer	1102	239
GASKET—Rear Axle Housing Cover	1101	238
GASKET—Rear Spring Trunnion Bearing Housing Cover	1602	313
GASKET—Round Closed Type	2315	500
GASKET—Shock Absorber Upper	1603	316
GASKET—Spark Plug	2314	499
GASKET—Spotlight Lens	2204	473
GASKET—Steering Gear Housing Bracket	1403	283
GASKET—Tail and Signal Lamp Lens	0608	156
GASKET—Tail and Signal Lamp Socket Mounting	0608	155
GASKET—Tail Lamp Lens	0608	155
GASKET—Tail Lamp License Lamp	0608	156
GASKET—Thermometer Glass Dial	0605	143
GASKET—Thermostat	0502	94
GASKET—Transfer Case Control Housing	0806	186
GASKET—Transfer Case Cover	0801	178-186
GASKET—Transfer Case Declutch Shaft Carrier Cover	0805	188
GASKET—Transfer Case Drive Gear Bearing Retainer	0802	179
GASKET—Transfer Case Drive Pinion Bearing Cage	0802	188
GASKET—Transfer Case Drive Pinion Rear Bearing Retainer	0802	188
GASKET—Transfer Case Drive Shaft Front Bearing Retainer	0802	191
GASKET—Transfer Case Driven Gear Bearing Retainer	0803	180-181
GASKET—Transfer Case Driven Shaft Bearing Retainer	0803	191
GASKET—Transfer Case Driven Shaft Rear Bearing Cover	0803	188
GASKET—Transfer Case Gear Shifter Cover	0806	189
GASKET—Transfer Case Idler Gear Bearing Retainer	0804	181-183
GASKET—Transfer Case Idler Gear Shaft Cover	0804	191
GASKET—Transfer Case Idler Shaft Front Cover	0804	188
GASKET—Transfer Case Idler Shaft Rear Cover	0804	188
GASKET—Transfer Case Main Shaft Front Cover	0802	188
GASKET—Transmission Drive Pinion Bearing Retainer	0703	173
GASKET—Transmission Gear Shift Lever Housing	0706	169-173

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

G—Continued	Sub-Group	Page No.
GASKET—Transmission Main Drive Pinion Bearing Retainer	0703	167
GASKET—Transmission Main Shaft Rear Bearing Retainer	0704	168
GASKET—Transmission Rear Bearing Retainer	0704	173
GASKET—Valve Cover	0105	17
GASKET—Valve Cover Screw	0105	17
GASKET—Valve Cover Stud	0105	17
GASKET—Water Pump Body Cover Plate	0503	96
GASKET—Water Pump By-Pass Elbow	0503	97
GASKET—Water Pump to Cylinder Block	0503	95
GASKET—Wheel Bearing Retainer	1301	273
GASKET—Winch Worm Housing Bearing Retainer	----	449-451
GASKET—Winch Worm Housing Cover	----	449-451
GATE ASSEMBLY—Lift	1807	397
GATE ASSEMBLY—Tail	1807	354-362-373-378-395
GAUGE—Fuel (On Instrument Panel)	0605	142
GAUGE—Fuel Tank Fuel (on Tank)	0304	72
GAUGE ASSEMBLY—Oil	0605	143
GAUGE ASSEMBLY—Tire	2306	488-489
GEAR—Camshaft (Sprocket)	0106	18
GEAR—Crankshaft	0106	19
GEAR—Flywheel Ring	0108	33
GEAR—Front Axle Differential	1002	217
GEAR—Front Axle Drive	1003	218
GEAR—Oil Pump Distributor Drive	0107	23
GEAR—Oil Pump Drive	0107	23
GEAR—Power Take-off Drive Shaft	2010	458
GEAR—Power Take-off Idler	2010	459-460-461
GEAR—Power Take-off Pump	----	455
GEAR—Power Take-off Reverse Idler	2010	459-460-461
GEAR—Power Take-off Sliding	2010	459-460-461
GEAR—Rear Axle Differential Side	1103	240
GEAR—Rear Axle Drive	1104	241
GEAR—Transfer Case Drive	0802	179-191
GEAR—Transfer Case Driven	0803	180-188
GEAR—Transfer Case Driven Shaft Clutch	0803	191
GEAR—Transfer Case Driven Shaft Two-Speed Clutch	0803	191
GEAR—Transfer Case Idler	0804	181-188-191
GEAR—Transfer Case Low Speed	0802	188
GEAR—Transfer Case Sliding	0802	188
GEAR—Transfer Case Speedometer Drive	----	191
GEAR—Transmission	0704	167
GEAR—Transmission Clutch	0704	173
GEAR—Transmission Countershaft	0704	167-173
GEAR—Transmission Drive	0703	173
GEAR—Transmission Low and Second	0704	167
GEAR—Transmission Main Drive	0703	166
GEAR—Transmission Main Drive (or Pinion)	0703	166
GEAR—Transmission Shaft Second Speed	0704	173
GEAR—Transmission Sliding (Low and Reverse)	0704	173
GEAR—Transmission Speedometer Drive	0705	169-173
GEAR—Transmission Third and Direct	0704	167
GEAR—Winch Worm	----	449-451
GEAR AND BUSHING ASSEMBLY—Oil Pump Idler	0107	23
GEAR AND BUSHING ASSEMBLY—Transmission Reverse Idler	0704	167
GEAR AND FLYWHEEL ASSEMBLY—Ring	0108	33
GEAR AND PINION—Front Axle Drive	1003	218
GEAR AND SHAFT ASSEMBLY—Oil Pump Drive	0107	23
GEAR AND SLEEVE ASSEMBLY—Transmission Clutch	0704	173

G—Continued	Sub-Group	Page No.
GEAR AND SPROCKET SHAFT ASSEMBLY—Windshield Regulator	1801	405
GEAR ASSEMBLY—Oil Pump Drive	0107	23
GEAR ASSEMBLY—Oil Pump Idler	0107	23
GEAR ASSEMBLY—Steering	1403	282
GEAR ASSEMBLY—Transfer Case Idler	0804	191
GEAR ASSEMBLY—Transmission Countershaft	0704	167
GEAR ASSEMBLY—Transmission Reverse Idler	0704	173
GENERATOR ASSEMBLY	0601	106-111-112
GLAND—Power Take-off Cylinder Head Packing	2001	454
GLASS—Cab Rear Window	1809	341
GLASS—Door	1809	401-419-435
	----	442
GLASS—Door Vent Wing	1809	----
GLASS—Folding Top Back Window	----	377
GLASS—Front Door	1809	341
GLASS—Lift Gate	1809	401
GLASS—Side Window	1809	401
GLASS—Windshield	1807	435
	1809	341-401-419
GLASS AND FRAME ASSEMBLY—Windshield	----	376
GOVERNOR AND BODY ASSEMBLY — Carburetor Throttle	0301	49
GOVERNOR AND SHAFT ASSEMBLY—Distributor	0603	127
GOVERNOR AND SHAFT ASSEMBLY—Distributor Drive	0603	127-129-132
GRILLE—Ventilating	----	440
GRILLE ASSEMBLY—Cab Back Window	1805	333
GRILLE ASSEMBLY—Roof Ventilator Fan Regulator	2204	474
GRIP—Spotlight Reflector Spring	2204	473
GROMMET	2315	500
GROMMET—Blackout Driving Lamp Cable Metal	0608	153
GROMMET—Fuel Tank Tube	0304	77
GROMMET—Head Lamp Cable	0607	151
GROMMET—Rear Shock Absorber to Link Rod and Eye Bolt	1603	315
GROUND STRAP—Battery Support to Splash Shield	2205	475-478
GROUND STRAP—Battery to Body	2205	475
GROUND STRAP—Body Cross Sill to Frame	2205	475
GROUND STRAP—Body to Bumper	2205	475
GROUND STRAP—Body to Bumperette	2205	478
GROUND STRAP—Body to Cab	2205	475
GROUND STRAP—Control	2205	475
GROUND STRAP—Control Cables to Dash	2205	475
GROUND STRAP—Engine	2205	475
GROUND STRAP—Engine to Dash	2205	475-478
GROUND STRAP—Engine to Frame	2205	475-478
GROUND STRAP—Engine to Frame Side Rail	2205	475
GROUND STRAP—Engine to Right Side Rail	2205	478
GROUND STRAP—Front Fender Splash Shield to Frame	2205	475-478
GROUND STRAP—Front Fender to Frame	2205	475
GROUND STRAP—Hood	2205	475-478
GROUND STRAP—Steering Column and Coil to Dash	2205	475-478
GROUND STRAP—Steering Column to Dash	2205	475
GROUND STRAP—Steering Column to Instrument Panel	2205	475-478
GUARD—Generator Drive End Flat Oil	0601	111
GUARD—Generator Drive End Head Felt	0601	108
GUARD—Headlamp	2103	467
GUARD—Rear Wheel Splash	----	362
GUARD—Tail and Blackout Lamp	----	441
GUARD—Winch Cable	2102	465
GUARD ASSEMBLY—Radiator	2103	467
GUIDE—Brake Shoe	1203	255

ALPHABETICAL INDEX—Continued

G—Continued	Sub-Group	Page No.
GUIDE—Side Control Rod	----	361
GUIDE—Sub-Frame Body	----	359
GUIDE—Valve	0105	17
GUIDE—Winch Cable	----	449
	1905	451-452
GUIDE AND HOUSING—Throttle Control	0303	69
GUIDE AND HOUSING ASSEMBLY—Choke Control	0303	71
GUIDE AND SEAL ASSEMBLY—Shock Absorber Piston Rod	1603	316
GUN—Grease	2306	487-488
GUN—Oil	2306	487-488
GUN—Zerk Grease	2311	497
GUN—Zerk Oil	2311	497
GUSSET—Bumper	2101	464
GUSSET—Frame Intermediate Crossmember	1506	298-300
GUSSET—Frame Transfer Case Crossmember	1506	297
GUSSET—Frame Trunnion Bracket Crossmember	1506	300

H

HAMMER	2306	487-488
HANDLE—Curtain Latch	----	376
HANDLE—Disc Wheel Wrench Socket	2306	487-488
HANDLE—Door	1805	412
	----	441
HANDLE—Door Outside	1805	333-389-426
	1807	415
HANDLE—Door Remote Control	1805	334-389-413-426
HANDLE—Door Ventilator Window	1805	425
HANDLE—Door Window Regulator	1805	389-412
HANDLE—Jack	2306	487-488
HANDLE—Map Board Lift	----	378
HANDLE—Map Table	1807	374
HANDLE—Rear Folding Step Release	----	442
HANDLE—Side Window Regulator	1805	389
HANDLE—Socket	2306	489
HANDLE—Spark Plug Wrench	2306	487
HANDLE—Windshield	1801	368
HANDLE—Windsield Clamp	1801	342-368
HANDLE—Windshield Pull-to	1801	328-342-367-382-404-420
HANDLE—Windshield Regulator	1801	329-383-405
HANDLE AND BRACKET ASSEMBLY—Drivers Seat Regulator	----	444
HANDLE AND BRACKET ASSEMBLY—Seat Regulator	1804	408
	----	444
HANDLE ASSEMBLY—Door Outside	1805	333-389-426
HANDLE ASSEMBLY—Door Remote Control	1805	389-426
HANDLE ASSEMBLY—Door Window Regulator	1805	333-389-412-426
HANDLE ASSEMBLY—Hood Lock	1704	325
HANDLE ASSEMBLY—Side Window Regulator	1805	389
HANDLE ASSEMBLY—Tail Gate	1807	373-396
	----	379
HANDLE ASSEMBLY—Tool and Locker Box	----	443
HANGER—Folding Step	----	442
HANGER—Rear Spring	1503	289
HANGER—Running Board	1504	290
HANGER AND PLATE ASSEMBLY—Battery Support	1803	371
HANGER AND SUPPORT ASSEMBLY—Battery	1803	385
HANGER ASSEMBLY—Litter Strap	----	443

H—Continued	Sub-Group	Page No.
HANGER ASSEMBLY—Spring	1503	289
HANGER ASSEMBLY—Tire Carrier	1505	294
HASP—Map Case Lid	----	378
HASP—Seat Cushion Lock	1804	332
HASP—Tool Box Door Latch	----	362
HEAD—Cylinder	0101	9
HEAD—Fuel Filter	0302	65
HEAD—Power Take-off Cylinder	2001	454
HEAD—Power Take-off Piston	2001	454
HEAD ASSEMBLY—Generator Drive End	0601	108-111
		114
HEADLAMP ASSEMBLY	0607	148
HINGE—Battery Cover	1803	371-385
HINGE—Body Half Rear Door	----	441
HINGE—Cowl Ventilator	1807	339-399
HINGE—Cowl Ventilator Lid	1807	348-374-419-432
HINGE—Curtain	----	376
HINGE—Glove Box Door	1807	338-347-372-394-416-439
HINGE—Hood Side	1704	324
HINGE—Hood Upper	1704	324
HINGE—Lift Gate	1807	397
HINGE—Rod Rear Folding Step	----	442
HINGE—Seat	----	362
HINGE—Seat Back	1804	332
HINGE—Seat Pan Right to Seat Riser	1804	346
HINGE—Side Curtain	----	377
HINGE—Side Front Curtain	2310	496
HINGE—Side Rear Curtain	2310	496
HINGE—Sub-Frame Body	----	359
HINGE—Tail Gate	1807	354-396
	----	361-369
		378
HINGE—Windshield	1801	367-381-405-421
HINGE—Windshield Body Half	1801	329
HINGE—Windshield Half	1801	328
HINGE AND FLOAT ASSEMBLY—Carburetor	0301	49
HINGE ASSEMBLY—Accelerator	0303	68
HINGE ASSEMBLY—Battery Cover	1803	385
HINGE ASSEMBLY—Door	1805	334-391-413-421
	1807	415
HINGE ASSEMBLY—Glove Box Door	1807	338-394-416-437
HINGE ASSEMBLY—Map Case Lid	----	378
HINGE ASSEMBLY—Tail Gate	----	378
	1807	396
HINGE ASSEMBLY—Tool Box Door	----	362
HOLDER—Fuse	2315	500
HOLDER—Light Switch Fuse	0606	144
HOLDER—Starting Motor Brush	0602	119
HOOD—Voltmeter Lamp	0605	142
HOOD AND UNIT ASSEMBLY—Blackout Driving Lamp Sealed Beam	2308	492
HOOD HALF ASSEMBLY	1704	324
HOOK—Front Rack Connection	----	362
HOOK—Litter Strap	----	443
HOOK—Tail Gate	----	361
HOOK—Tail Gate Chain	----	378
HOOK—Tail Gate Hinge Pin Retaining Chain	----	361
HOOK—Tarpaulin	----	362
HOOK—Tow	1501	288
HOOK AND CHAIN ASSEMBLY—Tail Gate	----	362

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

H—Continued	Sub-Group	Page No.
HOOK AND COVER ASSEMBLY—Tail Gate	----	378
HOOK ASSEMBLY—Pintle	1502	289
HOOK ASSEMBLY—Tail Gate	----	361
HORN ASSEMBLY	0609	160
HOSE—Booster Brake	1210	270
HOSE—Booster Brake Check Valve to Supply Tank	1210	270
HOSE—Booster Brake Control Valve to Cylinder	1210	270
HOSE—Booster Brake Supply Tank	1210	270
HOSE—Booster Brake Tee Tube to Control Valve	1210	270
HOSE—Booster Brake Tee Tube to Cylinder	1210	270
HOSE—Booster Brake Tee Tube to Supply	1210	270
HOSE—Brake	1209	263-264-265-266-267
HOSE—Fuel Tank Filler Tube	0304	73
HOSE—Fuel Tank Filler Vent Tube	0304	79
HOSE—Fuel Tank to Fuel Filter Flexible	0304	78-79
HOSE—Fuel Tank to Fuel Filter Tube Flexible	0304	76
HOSE—Fuel Tank to Fuel Pump Flexible	0304	75
HOSE—Fuel Tank to Fuel Pump Tube Flexible	0304	77
HOSE—Fuel Tank Vent Tube	0304	74-75
HOSE—Radiator	0505	101
HOSE—Radiator Inlet	0505	101
HOSE—Radiator Outlet	0505	101
HOSE—Water Pump By-Pass	0503	97
HOSE ASSEMBLY—Bleeder	2306	487-488
HOSE ASSEMBLY—Brake	1209	265-266-268
HOSE ASSEMBLY—Engine to Oil Filter	0107	31
HOSE ASSEMBLY—Engine to Oil Gauge	0107	25
HOSE ASSEMBLY—Frame to Front Axle	1209	268
HOSE ASSEMBLY—Front Axle to Wheel Cylinder	1209	268
HOSE ASSEMBLY—Fuel Filter to Pump	0302	64
HOSE ASSEMBLY—Oil Filter to Engine	0107	31
HOUSING—Blackout Lamp	0608	153
HOUSING—Front Spring Axle Bumper	1601	309
HOUSING—Fuel Tank Filler Tube	0304	77
HOUSING—Power Take-off	2010	459-460-461
HOUSING—Power Take-off Gear	2010	458
HOUSING—Rear Spring Axle Bumper	1601	309
HOUSING—Speedometer Cable	2203	472
HOUSING—Tire Carrier Lock	1505	295
HOUSING—Transfer Case Control	0806	186
HOUSING—Transmission Gear Shift Lever	0706	169-173
HOUSING—Winch Safety Brake	----	449-451
HOUSING AND BUSHING—Winch Worm	----	449-451
HOUSING AND CABLE ASSEMBLY—Speedometer	2203	472
HOUSING AND GUIDE ASSEMBLY—Choke Control	0303	71
HOUSING AND GUIDE ASSEMBLY—Throttle Control	0303	69
HOUSING ASSEMBLY—Clutch	0207	46
HOUSING ASSEMBLY—Front Axle	1001	216
HOUSING ASSEMBLY—Instrument Lamp Socket	0605	140
HOUSING ASSEMBLY—Instruments	0605	140
HOUSING ASSEMBLY—Rear Axle	1101	238
HOUSING ASSEMBLY—Roof Ventilator	2204	474
HOUSING ASSEMBLY—Side Panel Battery	1807	374
HOUSING ASSEMBLY—Starting Motor Pinion and Clutch	0602	118-121
HOUSING ASSEMBLY—Steering Gear	1403	283
HOUSING ASSEMBLY—Tail and Signal Lamp	0608	156
HUB—Camshaft Sprocket	0106	18
HUB—Fan Pulley	0503	98
HUB AND BRAKE DRUM ASSEMBLY—Wheel	1302	273
HUB ASSEMBLY—Wheel	1302	274

I	Sub-Group	Page No.
"I" BEAM—Front Axle	----	227-230
IDLE JET ASSEMBLY—Carburetor	0301	49
IMPELLER—Water Pump Shaft	0503	96
IMPELLER AND SHAFT ASSEMBLY—Water Pump	0503	96
INDICATOR—Distributor Lock Plate	0603	126
INDICATOR—Oil Level	0107	26
INDICATOR ASSEMBLY—Headlamp Beam	0607	152
INSULATION—Generator Field Coil Terminal Post	0601	113
INSULATION—Generator Field Connection	0601	109-111
INSULATION—Generator Insulation Field Connection	0601	115
INSULATION—Generator Post Bottom	0601	115
INSULATION—Generator Regulator	0601	110-116
INSULATION—Generator Terminal Post Bottom	0601	109-111
INSULATION—Generator Terminal Post Top	0601	109-111
INSULATION—Starting Motor Field Coil Connection	0602	119-121
INSULATION—Starting Motor Terminal Post	0602	120-123
INSULATOR—Carburetor	0301	56
INSULATOR—Chassis Wiring Junction Block	0606	146
INSULATOR—Exhaust Pipe Floor	1802	351
	1807	417
INSULATOR—Generator Regulator Terminal Slot	0601	110
INSULATOR—Head Lamp Cable Terminal Plug	0607	151
INSULATOR—Horn Button Cable	0609	160
INSULATOR—Steering Post Bracket	1405	286
INSULATOR—Tail Lamp Cable	0608	159
INSULATOR—Tail Lamp Cable Contact	0608	158
INSULATOR—Tail Lamp Cable Contact Retainer	0608	158
INSULATOR—Tail Lamp Connector	0608	159
INSULATOR—Transfer Case Bracket	0808	192
INSULATOR—Transfer Case Mounting Bracket	0808	185
INSULATOR—Transfer Case Support Bracket Support	0808	189
INSULATOR ASSEMBLY—Dash	----	376
INSULATOR ASSEMBLY—Engine Front Support	0110	34
INSULATOR ASSEMBLY—Engine Rear Support	0110	36
INTAKE ASSEMBLY—Carburetor Air	0301	49
INTERLOCK—Transfer Case Gearshift Hand Lever	0806	189
IRON—Longitudinal Folding Seat	----	443
IRON—Tire	2306	487-488

J

JACK ASSEMBLY	2306	487-488-489
JACKET AND BUSHING ASSEMBLY—Steering Gear Column	1403	284
JAW—Crankshaft Starting	0102	10
JET—Carburetor Accelerator	0301	49
JET—Carburetor Main	0301	49
JET—Carburetor Main Metering	0301	53
JET—Carburetor Pump	0301	53
JET—Carburetor Step-up	0301	53
JET ASSEMBLY—Carburetor Discharge	0301	49
JOINT—Ball	2315	500
JOINT ASSEMBLY—Power Take-off Universal	----	457
JOINT ASSEMBLY—Power Take-off Universal Slip	----	457
JOINT ASSEMBLY—Winch Universal Drive	1901	452

K

KEY—Door Lock Cylinder	1805	335-390-413-414-427
	1807	415
KEY—Door Ventilator Window Handle	1805	425
KEY—Fan Pulley	0503	98
KEY—Front Control Cross Rod	----	361
KEY—Ignition Coil Lock Cylinder	0604	135

ALPHABETICAL INDEX—Continued

K—Continued	Sub-Group	Page No.
KEY—Ignition Lock Cylinder	0604	139
KEY—Power Take-off	----	457
KEY—Power Take-off Drive Shaft	2010	459
KEY—Power Take-off Drive Shaft Gear	2010	458
KEY—Power Take-off Pump Drive Shaft	----	455
KEY—Power Take-off Pump Valve	----	455
KEY—Rear Axle Drive Shaft	1102	238
KEY—Tail Gate Lock Cylinder	1805	371-391
KEY—Tire Carrier Lock Cylinder	1505	295
KEY—Transfer Case Control Shift Lever Shaft	0806	186
KEY—Winch Sliding Clutch	----	449-451
KEY—Winch Worm	----	449-451
KEY—Winch Worm Gear Cable Drum Shaft	----	451
KEY—Woodruff	2305	486
KEY AND CYLINDER ASSEMBLY—Door Lock	1805	335-390-413-427
	1807	415
KEY AND CYLINDER ASSEMBLY—Ignition Coil Lock	0604	135
KEY AND CYLINDER ASSEMBLY—Tire Carrier Lock	1505	295
KITS		
Brake Master Cylinder Repair	0205	259-536
Brake Shoe Adjusting Repair	1203	252-536
Brake Shoe Lining	1202	536
Brake Wheel Cylinder Service	1207	262-536
Camshaft Bearing	0106	18-520
Carburetor Gasket	0301	49-523
Carburetor Governor Repair	0301	49-524
Carburetor Repair	0301	49-522
Chain Case Cover Oil Seal and Gasket	0106	19-520
Clutch Cover Overhaul Repair	0202	42-521
Clutch Facing and Rivet	0201	42-521
Connecting Rod Bearing	0104	16-520
Crankshaft Bearing	0102	11-515
Crankshaft Rear Bearing Oil Seal	0102	11-514
Distributor Weight Spring	0603	128-129-132
Distributor Repair	0603	125-129-529
Drag Link Repair	1401	281-537
Drag Link Dust Cover Service	1401	281-537
Door Lock Cylinder and Key Service	1805	335-413-427
Engine Gasket	0100	7-514
Front Axle Differential Gear Repair	1002	217-533
Front Axle Drive Gear, Pinion and Lock Repair	1003	218-533
Front Axle Drive Pinion Bearing Spacer	1003	220-534
Front Axle Gasket	1001	216-533
Front Axle Steering Knuckle Flange Gasket and Shim	1006	224-534
Front Axle Universal Drive Ball	1005	221-534
Front Axle Universal Drive Thrust Ball	1005	221-534
Front Spring Bushing	1602	311-538
Front Spring Shackle and Bushing	1602	311-538
Fuel Pump Diaphragm	0302	60-523
Fuel Pump External Repair	0302	60-524
Fuel Pump Repair	0302	60-523
Generator Current Regulator Unit Repair	0601	110-116-527
Generator Field Coil Repair	0601	110-116-527
Generator Regulator Circuit Breaker Unit Repair	0601	110-116-527
Generator Repair	0601	110-116-526
Generator Voltage Regulator Unit Repair	0601	110-527
Governor Repair	0305	80-524
Hand Brake Band Lining	1201	250-536
Hand Brake Lining	1201	251-536

K—Continued	Sub-Group	Page No.
KITS—Continued		
Hand Brake Pawl Rod and Sector	1201	248-536
Horn Button and Cable Repair	0609	160-529
Ignition and Door Lock Cylinder and Keys	0604	135
Ignition Cable	0604	137-529
Manifold Gasket	0108	32-521
MoPar Compression Piston Ring	0103	12-13-518
MoPar Oil Master Piston Ring	0103	12-13-516-517
MoPar Oil Saver Piston Ring	0103	12-13-516-517
MoPar Regular Coated Piston Ring	0103	12-13-519
MoPar Water Pump Assembly	0503	95-525
MoPar Water Pump Shaft and Bearing	0503	96-525
Oil Pan Gasket	0107	25-520
Oil Pressure Relief Valve Spring	0107	24-520
Oil Pump Repair	0107	23-520
Piston Expander	0103	519
Propeller Shaft Universal Joint Service	0902	209-532
Rear Axle Differential Gear Repair	1103	240-535
Rear Axle Drive Gear and Pinion Matched	1104	241
Rear Axle Drive Pinion Bearing Spacer	1104	242-535
Rear Axle Drive Shaft Oil Seal and Gasket	1102	239-535
Rear Axle Gasket	1101	238-535
Rear Axle Ring Gear, Pinion and Lock Repair	1104	241-535
Service Brake Lining Kit	1201	251-536
Shock Absorber External Repair	1603	315-539
Shock Absorber Internal Repair	1603	315-539
Starter Motor Field Coil Repair	0602	118-121-528
Starter Motor Repair	0602	118-121-528
Steering Gear Oil Seal Gasket Repair	1403	285-538
Steering Tie Rod End	1402	282-537
Transfer Case Adjusting Shim	0802	179-192-531
Transfer Case Gasket	0801	178-192-531
Transfer Case Oil Seal	0802	179-192-531
Transmission Case Gasket	0701	166-530
Transmission Hand Brake Band Lining	1201	250-536
Transmission Small Parts	0704	169-173-530
Valve Grind Gasket	0100	7-514
Valve Spring Cover	0105	17-520
Water Pump Repair	0503	97-525
Water Pump Seal	0503	97-525
Weapon Carrier Body Conversion	2206	479
Winch Gasket and Oil Seal	1901	449-451-540
Winch Universal Drive Joint Repair	1901	452-540
Windshield Wiper Arm	1801	540
Windshield Wiper Arm Adapter	1801	343-369-384-422-540
Windshield Wiper Arm Mounting Nut	1801	343-369-384-422-540
Windshield Wiper Motor Repair	1801	330-343-369-384-406-422-539-540
KNOB—Blackout Switch	0608	155
KNOB—Instruments Lamp Switch Control	0606	144

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

K—Continued	Sub-Group	Page No.
KNOB—Light Switch Control	0606	144
KNOB—Tail Lamp Switch Control	0608	157
KNOB—Trailer Electric Brake Load Control Switch	0604	138
KNOB—Transmission Gear Shift Lever	0706	170-173
KNOB—Winch Shifter Fork	....	449-451
KNOB—Windshield Wiper Control	1801	330-343-
		369-384-
		406-422
KNOB ASSEMBLY—Blackout Driving Lamp Switch Control	0608	153
KNUCKLE—Front Axle Steering	....	227-230
KNUCKLE ASSEMBLY—Front Axle Steering	1006	224
L		
L-BOLT—Driver's Seat Locking	....	444
LACING—Cowl Hood	....	337
	1807	347-372-
		395-433
LACING—Cowl Hood Protector	1807	417
LACING—Radiator Shell	0501	93
LAMINATION ASSEMBLY—Horn Mounting Bracket	0609	160
LAMP—Blackout	0608	153
LAMP ASSEMBLY—Blackout Driving	0608	153
LAMP ASSEMBLY—Dome	0608	159
	....	440
LAMP ASSEMBLY—License	0608	157
LAMP ASSEMBLY—Parking	0607	152
LAMP ASSEMBLY—Rear Compartment	....	378
LAMP ASSEMBLY—Rear License	....	379
LAMP ASSEMBLY—Tail	....	379
LAMP ASSEMBLY—Tail and Signal	0608	155-156
LATCH—Curtain	....	376
LATCH—Pintle Hook	1502	289
LATCH—Seat	....	362
LATCH—Tire Carrier Arm	1505	295
LATCH—Tool Box Door	....	362
LATCH ASSEMBLY—Seat	1804	345
	....	362
LATCH ASSEMBLY—Side Curtain	2310	496
LEAD—Distributor Breaker Plate	0603	131
LEAD—Generator Post Terminal	0601	109
LEAD—Generator Regulator Current Regulator to Voltage Regulator	0601	110
LEAD—Generator Regulator Voltage Regulator to Base	0601	110
LEAD ASSEMBLY—Distributor Breaker Plate (Terminal or Ground)	0603	127
LEAD ASSEMBLY—Generator Field Coil	0601	107-111
LEAD ASSEMBLY—Generator Field Coil Control	0601	113
LEAD ASSEMBLY—Generator Terminal Post	0601	111
LEAF—Front Spring	1601	306
LEAF—Rear Auxiliary Spring	1601	307
LEAF—Rear Spring	1601	306
LEG—Attendants Seat—Rear	....	444
LENS—Blackout Lamp	0608	154
LENS—Dome Lamp	....	440
LENS—Headlamp	0607	149
LENS—Parking Lamp	0607	152
LENS—Speedometer	2203	472
LENS—Spotlight	2204	473
LENS—Tail and Signal Lamp	0608	156
LENS—Tail Lamp	0608	155
LENS—Tail Lamp Blackout Stop Light	0608	155
LENS—Tail Lamp License Lamp	0608	156
LENS—Tail Lamp Stop Light	0608	155
LENS AND BEZEL ASSEMBLY—Dome Lamp	0608	159
LENS AND DOOR—Rear Compartment Lamp	....	378

L—Continued	Sub-Group	Page No.
LEVER—Accelerator Shaft to Pedal	0303	69
LEVER—Carburetor Air Shutter	0301	49
LEVER—Clutch Pedal Operating Shaft	0204	45
LEVER—Clutch Pedal Shaft	0204	45
LEVER—Clutch Release	0203	42
LEVER—Front Control Arm	....	361
LEVER—Front Control Hand	....	361
LEVER—Fuel Pump Priming	0302	61
LEVER—Hand Brake Cam	1201	249
LEVER—Power Take-off Control	2010	461
LEVER—Power Take-off Control Hand	....	457
LEVER—Power Take-off Shifter	2010	460
LEVER—Power Take-off Valve Control	2001	454
LEVER—Power Take-off Valve Control Hand	....	457
LEVER—Transfer Case Control First and Reverse Lock	0806	186
LEVER—Transfer Case Control Hand	0806	186
LEVER—Transfer Case Declutch Shifter Shaft	0805	188
LEVER—Transfer Case Declutch Upper	0805	189
LEVER—Transfer Case Gearshift Hand	0806	189
LEVER—Transmission Gearshift	0706	170-173
LEVER—Winch Power Take-off	2010	459
LEVER AND BUSHING ASSEMBLY—Transfer Case Control Declutch	0805	192
LEVER AND BUSHING ASSEMBLY—Transfer Case Control Hand	0806	184
LEVER AND BUSHING ASSEMBLY—Transfer Case Control Shift	0805	192
LEVER AND BUSHING ASSEMBLY—Transfer Case Gearshift	0806	189
LEVER AND BUSHING ASSEMBLY—Transfer Case Gearshift Intermediate	0806	189
LEVER AND DRIVER ASSEMBLY—Carburetor Throttle	0301	49
LEVER AND LEVER SHAFT ASSEMBLY—Transfer Case Gearshift	0805	189
LEVER AND SHAFT ASSEMBLY—Carburetor Choke Control	0301	55
LEVER AND SHAFT ASSEMBLY—Transfer Case Control Shift	0806	186
LEVER AND SHAFT ASSEMBLY—Transfer Case Gearshift Lever	0805	189
	0806	189
LEVER ASSEMBLY—Booster Brake Control Valve Operating	1210	270
LEVER ASSEMBLY—Booster Brake Cylinder Operating	1210	270
LEVER ASSEMBLY—Carburetor Throttle	0301	55
LEVER ASSEMBLY—Hand Brake	1201	248
LEVER ASSEMBLY—Ignition Coil Switch	0604	135
LEVER ASSEMBLY—Throttle Control Hand	0303	71
LEVER ASSEMBLY—Trailer Electric Brake Control Switch	0604	138
LEVER ASSEMBLY—Transfer Case Control Hand	0806	184
LID AND CHAIN—Tool and Locker Box	....	443
LID AND DEFLECTOR ASSEMBLY—Cowl Ventilator	1807	348-374
LID ASSEMBLY—Cowl Ventilator	1807	339-390-
		418-434
LID ASSEMBLY—Map Case	1807	374-378
LINER ASSEMBLY—Dash	1807	338-347-
		373-398-
		417-433
LINES—Brake	1209	263-264-
		265-266-
		267
LINING—Brake Shoe	2317	502
LINING—Fuel Tank Support	0304	73
LINING—Hand Brake	2317	502
LINING—Wheel Brake Shoe	2317	502
LINING—Winch Brake Shoe	....	451

ALPHABETICAL INDEX—Continued

L—Continued	Sub-Group	Page No.
LINING AND BAND ASSEMBLY—Hand Brake	1201	250
LINING AND BAND ASSEMBLY—Winch Safety Brake	....	449-451
LINING AND SHOE ASSEMBLY—Wheel Brake	1202	251
LINING AND SHOE ASSEMBLY—Winch Brake	....	449-451
LINK—Booster Brake Control Valve Operating Lever	1210	270
LINK—Booster Brake Control Valve Support Operating	1210	270
LINK—Carburetor Pump Connector	0301	55
LINK—Carburetor Pump Operating	0301	55
LINK—Fuel Pump Rocker Arm	0302	61
LINK—Hand Brake Spacer	1201	249
LINK—Power Take-off Valve Control	2001	454-457
LINK—Winch Brake Shoe	....	449-451
LINK—Windshield Clamp	1801	342-368
LINK AND LOCK ASSEMBLY—Door	1805	335-391-409-428
LINK ASSEMBLY—Drag	1401	280
LINK ASSEMBLY—Power Take-off Lifting	2001	454
LINK ASSEMBLY—Rear Spring Torque	1602	312
LINOLEUM	....	445
LOCATER—Headlamp Mounting Bolt	0607	148
LOCK—Door	1805	409-441
LOCK—Front Axle Differential Bearing Adjuster	1002	218
LOCK—Front Axle Drive Bearing Adjuster	1003	228
LOCK—Front Axle Drive Pinion Inner Bearing	1003	229
LOCK—Front Axle Drive Pinion Outer Bearing Adjusting Nut	1003	229
LOCK—Front Axle Steering Knuckle King Pin Set Screw	....	227
LOCK—Front Axle Universal Drive Thrust Ball Pin	1005	222
LOCK—Front Spring Shackle Bolt	1602	311
LOCK—Hand Brake Spacer Link Stud	1201	249
LOCK—Propeller Shaft Universal Joint Bushing Clamp	0902	209
LOCK—Rear Axle Differential Bearing Cone Adjuster	1103	240
LOCK—Rear Axle Drive Gear Bolt Nut	1104	241
LOCK—Rear Axle Drive Pinion Inner Bearing	1104	243
LOCK—Rear Axle Drive Pinion Outer Bearing Adjustment Nut	1104	243
LOCK—Rear Spring Trunnion Bearing Adjusting Nut	1602	312
LOCK—Valve Spring Retainer	0105	17
LOCK—Wheel Bearing	1301	272
LOCK—Wheel Bearing Adjusting Nut and Pin	1301	273
LOCK AND LINK ASSEMBLY—Door	1805	335-391-409-428
LOCK ASSEMBLY—Blackout Switch Service Light	0608	155
LOCK ASSEMBLY—Door	1805	409
LOCK ASSEMBLY—Folding Step	....	443
LOCK ASSEMBLY—Lift Gate	1807	397
LOCK ASSEMBLY—Tail Gate	1807	373-378
LOCK CONTROL ASSEMBLY—Lift and Tail Gate	1807	397
LOCK WASHER—Ammeter Terminal	0605	141
LOCK WASHER—Beam Control Switch Terminal	0606	144
LOCK WASHER—Blackout Driving Lamp Switch Terminal Screw	0608	153
LOCK WASHER—Blackout Switch Terminal	0608	155
LOCK WASHER—Body Hold-down	1807	394
LOCK WASHER—Connecting Rod Cap Bolt	0104	16
LOCK WASHER—Crankshaft Rear Bearing Oil Seal Retainer	0102	11
LOCK WASHER—Crankshaft Starting Jaw	0102	10
LOCK WASHER—Door Remote Control	1805	391
LOCK WASHER—Door Window Regulator	1805	336
LOCK WASHER—External Shakeproof	2304	482
LOCK WASHER—External Tooth Countersunk	2304	482
LOCK WASHER—Front Control Arm Lever Bolt	....	361
LOCK WASHER—Front Door Lock Remote Control	1805	428
LOCK WASHER—Front Spring Rear Bolt	1601	304
LOCK WASHER—Fuel Gauge Terminal	0605	142
LOCK WASHER—Fuel Tank Fuel Gauge Mounting (on Tank)	0304	72
LOCK WASHER—Ignition Coil Lock Switch Mounting	0604	135
LOCK WASHER—Ignition Lock Switch Mounting Nut	0604	139
LOCK WASHER—Ignition Lock Switch Terminal Screw	0604	139
LOCK WASHER—Instrument Lamp Switch	0606	144
LOCK WASHER—Internal and External Tooth	2304	482
LOCK WASHER—Internal Shakeproof	2304	482
LOCK WASHER—Pintle Hook	1502	289
LOCK WASHER—Rear Axle Drive Pinion Outer Bearing Adjustment Nut	1104	243
LOCK WASHER—Standard	2304	482
LOCK WASHER—Steering Gear Arm	1403	286
LOCK WASHER—Steering Gear Housing Bracket	1403	284
LOCK WASHER—Sub-Frame Hinge to Body Bolt	....	359
LOCK WASHER—Sub-Frame Trunnion Bracket Bolt	....	359
LOCK WASHER AND HEXAGON HEAD SCREW—Internal Tooth	2304	486
LOCK WASHER AND NUT—Front Axle Steering Knuckle Tie Rod End Clamp Bolt	....	227
LOCK WASHER AND ROUND SLOTTED HEAD SCREW—Internal and External Tooth	2304	486
LOCK WASHER AND SCREW—Door Hinge	1805	334-390-413-427
	1807	415
LOCK WASHER AND SCREW—Power Take-off Drive Shaft Oil Retainer Plate	2010	459
LOCK WASHER AND SCREW—Transmission Cover Draft Pad	1807	373
LOCK WASHER AND SCREW—Water Pump	0503	96
LOCKNUT—Battery to Terminal Box Cable Conduit	0610	161
LOCKPLATE—Transmission Reverse Idler Gear Shaft	0704	169-173
LOCKSPRING—Headlamp Lens	0607	149
LOCKWIRE—Brake Master Cylinder Piston Stop	1205	258
LOCKWIRE—Drag Link End Plug	1401	281
LOCKWIRE—Front Axle Differential Case	1002	228
LOCKWIRE—Front Axle Drive Bearing Adjuster	1003	228
LOCKWIRE—Hand Brake Band Anchor Clip	1201	250
LOCKWIRE—Horn Button Retainer Plate	0609	160
LOCKWIRE—Oil Strainer	0107	24
LOCKWIRE—Rear Axle Differential Case	1103	240
LOCKWIRE—Transfer Case Control First and Reverse Lock Lever Screw	0806	186
LOCKWIRE—Transfer Case Shift Fork Screw	0806	184-185
LOCKWIRE—Transmission Gear Shift Fork	0706	171
LOCKWIRE—Winch Universal Drive Joint Set Screw	1901	452
LOCKWIRE—Winch Universal Drive Shaft Collar Set Screw	1901	452
LOOP—Floor Strap	....	443
LOOP—Floor Strap Bottom	....	443
LOOP—Folding Top Stay Strap	....	377
LOOP—Footman	2315	500
LOOP—Rack Connection	....	362
LOOP—Safety Strap Connection	....	362
LOOP—Tailgate Chain Retaining	....	361
LOOP—Top Rear Hold-down Strap	....	376
LOUVRE—Blackout Lamp	0608	154
LUG—Head Lamp Reflector Stop	0607	150

M

MANIFOLD ASSEMBLY—Intake and Exhaust	0108	32
MAT—Driver's Compartment Floor	....	445
MAT—Floor	1802	370-381-407-427
	....	379
MAT—Front Compartment Floor	1802	370

ALPHABETICAL INDEX—Continued

M—Continued	Sub-Group	Page No.
MAT—Front Floor	1802	331
MAT—Fuel Tank Filler Pipe Cover	----	379
MAT—Rear Compartment Floor	1802	370
MAT ASSEMBLY—Floor	1802	344-370-385-407-423
	----	379
MATERIAL—Roof Deck	2312	497
MATERIAL—Top	2312	497
MATERIAL—Upholstering	2312	497
METERING VALVE ASSEMBLY—Crankcase Ventilator	0107	27
MIRROR ASSEMBLY—Rear View	2201	470
MOTOR—Roof Ventilator Fan	2204	474
MOTOR—Windshield Wiper	1801	330-343-369-384-406-422
MOTOR ASSEMBLY—Starting	0602	121
MOTOR ASSEMBLY—Windshield Wiper	1801	330-384-406
MOULDING—Cab Back Window Garnish	1805	335
MOULDING—Cab Roof Drip	1807	338
MOULDING—Cowl to Roof	1807	419
MOULDING—Cowl to Roof Panel	1807	338-398-433
MOULDING—Door Garnish	1807	415
MOULDING—Front Fender Center Grille	1701	319
MOULDING—Front Fender Grille	1701	319-320
MOULDING—Front Pillar Drip	----	377
MOULDING—Inside	----	440
MOULDING—Inside Trim	----	440
MOULDING—Linoleum Seal	----	445
MOULDING—Radiator Shell Center	0501	92
MOULDING—Radiator Shell Side	0501	92
MOULDING—Roof Drip	1807	398-419-433
MOULDING—Side Drip	----	440
MOULDING—Side Panel Outside Cab	----	440
MOULDING—Window Garnish	1807	398
MOULDING—Window Lift Up Panel	1807	398
MOULDING—Windshield Center Piece	1801	329-367-383-405-421
MUFFLER ASSEMBLY	0401	82

N

NAME PLATE—Radiator Upper Shell	0501	93
NEEDLE AND SEAT ASSEMBLY—Carburetor Float	0301	55
NIPPLE—Booster Brake Check Valve to Tee Tube	1210	270
NIPPLE—Booster Brake Hose	1210	270
NIPPLE—Brake Master Cylinder Outlet	1205	257
NIPPLE—Fuel Pump to Carburetor Tube (Pump End)	0302	63
NIPPLE—Grease	2311	497
NIPPLE—Ignition Coil Secondary Cable	0604	136-139
NIPPLE—Ignition Coil Spark Plug Cable	0604	137
NIPPLE—Oil Pump Pipe	0107	24
NIPPLE—Oil Suction Pipe	0107	24
NIPPLE—Pipe	2315	500
NIPPLE—Transfer Case Breather	0801	191
NIPPLE—Transfer Case Vent	0801	178-188
NIPPLE—Windshield Wiper Tube	1801	344-369-384-406-422
NIPPLE—Windshield Wiper Tube Coupling	1801	330
NIPPLE ASSEMBLY—Transfer Case Vent	0801	188
NOZZLE—Heater Defroster	2204	473
NUT—Anchor	2304	482
NUT—Auxiliary Battery to Ground Cable Terminal Bolt	0610	162
NUT—Battery Ground Cable Terminal Bolt	0610	161
NUT—Battery Tray Support Screw	1803	345
NUT—Blackout Switch Mounting	0608	154
NUT—Blind	2304	482
NUT—Brake Hose	1209	268
NUT—Brake Hose Union	1209	266
NUT—Brake Support to Rear Axle Housing	1203	252
NUT—Cab Back Window	1805	333
NUT—Carburetor Air Shutter Bracket Wire Clamp Screw	0301	49
NUT—Carburetor Air Shutter Shaft	0301	49
NUT—Carburetor Choke Tube Clamp	0301	54
NUT—Check	2304	482
NUT—Clutch Release Lever Eyebolt	0203	43
NUT—Connecting Rod Cap Bolt	0104	16
NUT—Cowl to Roof Panel Moulding Clinch On	1807	338
NUT—Crankshaft Bearing Cap Screw	0102	11
NUT—Crankshaft Bearing Cap Stud	0102	11
NUT—Cylinder Head Stud	0101	9
NUT—Door Vent Wing Pivot Screw	1805	431
NUT—Engine Front Support Plate Bolt	0110	34
NUT—Engine Rear Support Bracket Clinch	0110	37
NUT—Exhaust Manifold Stud	0108	33
NUT—Flared Tube	2304	482
NUT—Floor Board	1802	370
NUT—Floor Transmission Cover Center Floor Panel	1802	423
NUT—Floor Transmission Cover Panel	1802	423
NUT—Flywheel Bolt	0108	33
NUT—Frame Crossmember, to Engine Front Support Plate Clinch	1506	297
NUT—Frame Crossmember to Radiator Support Bracket Clinch	1506	297
NUT—Frame Intermediate Crossmember Clinch	1506	299
NUT—Front Axle Drive Gear Bolt Lock	1003	218
NUT—Front Axle Drive Gear Thrust Screw Check	1003	218
NUT—Front Axle Drive Pinion Front Bearing Retainer	1003	219
NUT—Front Axle Drive Pinion Outer Bearing Adjusting	1003	229
NUT—Front Axle Housing Cover Stud	1001	216
NUT—Front Axle Steering Arm Ball	1006	226
NUT—Front Axle Steering Knuckle Arm	----	230
NUT—Front Axle Steering Knuckle Stop Screw	1006	2[illegible]
NUT—Front Control Arm Lever Bolt	----	3[illegible]
NUT—Front Control Hand Lever Bolt	----	361
NUT—Front Control Hand Lever Clevis Bolt	----	361
NUT—Front Fender Grille Dust Shield Clinch	1701	319
NUT—Front Spring Plate Stud	1601	307
NUT—Fuel Filter Element and Bowl Stud	0302	65
NUT—Fuel Pump Diaphragm Protector	0302	62
NUT—Fuel Pump Strainer Bowl Bail Screw	0302	63
NUT—Fuel Tank Support Strap End	0304	73
NUT—Generator Armature Terminal Post	0601	111
NUT—Generator Field Coil Armature Terminal Post	0601	107
NUT—Generator Pulley Mounting	0601	106
NUT—Generator Regulator Adjusting	0601	110-116
NUT—Hand Brake Adjusting	1201	251
NUT—Hexagon	2304	483
NUT—Hexagon Slotted	2304	483
NUT—Ignition Coil Lock Switch Mounting	0604	135
NUT—Ignition Lock Switch Mounting	0604	139-144
NUT—Instrument Panel Clinch-on	1807	433
NUT—Inverted Flared Tube	2304	483
NUT—Light Switch Mounting	0606	144
NUT—Manifold Attaching Stud	0108	32
NUT—Pintle Hook	1502	289
NUT—Power Take-off Shifter Shaft Packing	2010	458
NUT—Power Take-off Valve Control Rod Yoke Lock	----	457
NUT—Propeller Shaft Companion Flange	0901	207-210

ALPHABETICAL INDEX—Continued

N—Continued	Sub-Group	Page No.
NUT—Radiator Guard Support to Core Support Clinch	0501	91
NUT—Radiator Guard Support to Shell and Hood Lock Catch Clinch	0501	91
NUT—Radiator Support to Core Clinch	0504	99
NUT—Radiator Support to Fender Brace Clinch	0504	99
NUT—Radiator Support to Fender Support Clinch	0504	99
NUT—Radimeter Gland	0502	95
NUT—Radio Switch to Auxiliary Battery Cable Terminal Bolt	0610	162
NUT—Rear Axle Drive Gear Thrust Screw Check	1104	241
NUT—Rear Axle Drive Pinion Carrier Bolt	1104	242
NUT—Rear Axle Drive Pinion Front Bearing Retainer	1104	242
NUT—Rear Axle Drive Pinion Outer Bearing Adjustment	1104	243
NUT—Rear Axle Drive Shaft	1102	238
NUT—Rear Axle Drive Shaft Screw	1102	238
NUT—Rear Spring Center Bolt	1601	305
NUT—Rear Spring Clip Plate	1601	307
NUT—Rear Spring Trunnion Bearing Adjusting	1602	312
NUT—Roof Drip Moulding Clinch-on	1807	398
NUT—Self Locking	2304	482
NUT—Shock Absorber Piston	1603	316
NUT—Side Control Rod Clevis Lock	----	361
NUT—Sleeve	2304	483
NUT—Spark Plug Terminal	2314	499
NUT—Square	2304	483
NUT—Stamped	2304	483
NUT—Starter Cable Terminal Bolt	0610	161
NUT—Starting Motor Shift Yoke Pivot	0602	123
NUT—Starting Motor Shift Yoke Pivot Screw	0602	120
NUT—Steering Gear Arm	1403	286
NUT—Steering Gear Housing Bracket	1403	283
NUT—Steering Gear Housing Bracket Adjusting Stud	1403	284
NUT—Steering Gear Housing Nut Screw	1403	283
NUT—Steering Gear Shaft Adjusting	1403	285
NUT—Steering Tie Rod End Ball	1402	281
NUT—Steering Tie Rod End Lock	1402	281
NUT—Steering Tie Rod End Pin	1402	281
NUT—Steering Wheel	1404	286
NUT—Sub Frame Body Hinge to Body Bolt	----	359
NUT—Sub Frame Trunnion Bracket Bolt	----	359
NUT—Tail Gate Clinch-on	1807	354
NUT—Tail Lamp Switch Mounting	0608	157
NUT—Tee	2304	483
NUT—Thermometer Gland	0605	143
NUT—Tire Carrier Adjusting	1505	294
NUT—Tire Carrier Arm Clamp Bolt	1505	294
NUT—Tire Carrier Arm Stud	1505	295
NUT—Tire Carrier Bracket Stud	1505	295
NUT—Tire Carrier Locking Plate Stud	1505	294
NUT—Transfer Case Drive Pinion Rear Bearing Retainer	0802	188
NUT—Transfer Case Drive Pinion Retainer	0810	191
NUT—Transfer Case Gear Shifter Shaft Packing	0806	189
NUT—Transfer Case Idler Gear Retainer Shaft	0804	191
NUT—Transfer Case Idler Shaft Rear Cover	0804	188
NUT—Transmission Drive Pinion Bearing Lock	0703	173
NUT—Transmission Gear Shift Reverse Stop Plunger Spring Check	0706	170
NUT—Transmission Mainshaft Flange	0901	173
NUT—Transmission Speedometer Drive Pinion Bushing Retaining	0705	169
NUT—Tri Slot	2304	483
NUT—Wheel Bearing Adjusting	1301	272-273
NUT—Wheel Hub and Brake Drum	1302	273
NUT—Wheel Hub Stud	1302	275
NUT—Wheel Hub Stud Cap	1302	275
NUT—Wheel Side Ring Bolt	1301	272
NUT—Windshield Adjusting Arm	1801	342-367-368-382-404-420
NUT—Windshield Adjusting Arm Lock	1801	328
NUT—Windshield Handle Cap	1801	367
NUT—Windshield Handle Screw	1801	368
NUT—Windshield Handle Wing	1801	368
NUT—Windshield Pull-to Handle	1801	342
NUT—Windshield Pull-to Handle Cap	1801	329-342-383-405-421
NUT—Windshield Side Arm Pivot Wing	1801	342
NUT—Windshield Stanchion Wing	----	376
NUT—Windshield Wiper Arm	1801	343-406-422
NUT—Windshield Wiper Arm Mounting	1801	330-343-369-384-406-422
NUT—Windshield Wiper Tube	1801	344
NUT—Wing	2304	483
NUT AND CUP ASSEMBLY—Fuel Filter Retainer	0302	65
NUT AND EYEBOLT ASSEMBLY—Clutch Release	0203	43
NUT AND LOCKWASHER—Front Axle Steering Knuckle Tie Rod End Clamp Bolt	----	227
NUT AND PIN ASSEMBLY—Wheel Bearing Adjusting	1301	272-273
NUT AND SLEEVE ASSEMBLY	2315	500
NUT ASSEMBLY—Rear Spring Trunnion Bearing Adjusting	1602	312
NUT ASSEMBLY—Steering Gear Housing	1403	283

O

OIL GUARD—Generator Commutator	0601	108
OIL SEAL—Crankshaft Rear Bearing	0102	11
OIL SEAL—Front Axle Drive Pinion Outer Bearing	1003	228
OIL SEAL—Power Take-off Drive Shaft	2010	459-460-461
OIL SEAL—Power Take-off Shifter Shaft	2010	459-460-461
OIL SEAL—Propeller Shaft Spline Yoke	0901	205
OIL SEAL—Rear Axle Drive Pinion Outer Bearing	1104	243
OIL SEAL—Steering Gear Shaft	1403	285
OIL SEAL—Transfer Case Declutch Shaft Bearing	0805	188
OIL SEAL—Transfer Case Declutch Shifter Shaft	0805	188
OIL SEAL—Transfer Case Drive Pinion	0810	191
OIL SEAL—Transfer Case Drive Pinion Rear Bearing Retainer	0802	188
OIL SEAL—Transmission Speedometer Drive Pinion	0705	169
OIL SEAL—Wheel Bearing	1301	272-273
OIL SEAL AND COVER ASSEMBLY—Front Axle Drive Pinion Outer Bearing	1003	228
OIL SEAL AND COVER ASSEMBLY—Rear Axle Drive Pinion Outer Bearing	1104	243
OIL SEAL ASSEMBLY—Front Axle Drive Pinion Bearing	1003	220
OIL SEAL ASSEMBLY—Front Axle Steering Knuckle Flange	1006	226
OIL SEAL ASSEMBLY—Front Axle Universal Drive Shaft	1005	223
OIL SEAL ASSEMBLY—Rear Axle Drive Pinion Bearing	1104	243
OIL SEAL ASSEMBLY—Rear Axle Drive Shaft Inside Bearing	1102	239
OIL SEAL ASSEMBLY—Rear Spring Trunnion Bearing Housing	1602	313
OIL SEAL ASSEMBLY—Transfer Case Drive Gear Bearing	0802	179
OIL SEAL ASSEMBLY—Transfer Case Driven Gear Bearing	0803	181

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

O—Continued	Sub-Group	Page No.
OIL SEAL ASSEMBLY—Transfer Case Driven Gear Shaft Bearing	0803	188
OIL SEAL ASSEMBLY—Transfer Case Idler Gear Bearing	0804	182
OIL SEAL ASSEMBLY—Transfer Case Main Shaft Front Cover	0802	188
OIL SEAL ASSEMBLY—Transfer Case Shift Rail	0805	191
	0806	184-189
OIL SEAL ASSEMBLY—Transmission Mainshaft Rear Bearing	0704	173
OIL SEAL ASSEMBLY—Transmission Rear Bearing	0704	168
OIL SEAL ASSEMBLY—Wheel Bearing	1301	273
OIL SEAL ASSEMBLY—Winch Worm Shaft	----	449-451
OIL STRAINER—Floato Type	0101	8
OIL WICK—Generator Commutator	0601	107
OILER—Distributor Base	0603	127-131
OILER—Generator Drive End Head	0601	114
OILER—Starting Motor Commutator End	0602	122
OILER—Starting Motor Commutator End Plate	0602	119
ORNAMENT—Radiator Shell Upper	0501	93
P		
PACKAGE—Door Lock Cylinder and Key Service	1805	335
		413-427
Fuse	2308	492
Ignition and Door Lock Cylinder and Key	0604	135
PACKING—Power Take-off Cylinder Head	2001	454
PACKING—Power Take-off Drive Shaft	2010	458
PACKING—Power Take-off High Pressure Connection	----	455
PACKING—Power Take-off Pump Drive Shaft	----	455
PACKING—Power Take-off Pump Valve	----	455
PACKING—Power Take-off Shifter Shaft	2010	458
PACKING—Transfer Case Gear Shifter Shaft	0806	189
PAD—Body Bolt Filler Block	1807	337
PAD—Body Hold Down	1807	414-432
PAD—Body Hold Down Bolt	1807	371-432
PAD—Body Hold Down Filler Block	1807	349
PAD—Body to Frame	1807	394
PAD—Bottom Longitudinal Side Seat Cotton	----	442
PAD—Brake Pedal Draft	1204	257
PAD—Clutch and Brake Draft	1807	339-347-
		373-398-
		417-433
PAD—Clutch Pedal Draft	0204	45
PAD—Drag Link Dust Cover	1401	280
PAD—Floor Transmission	1807	373
PAD—Front Axle Drive Gear Thrust Screw	1003	218
PAD—Front Floor Transmission Cover Draft	1807	398
PAD—Head Lamp Mounting Bracket	0607	149
PAD—Hood Windshield Support Bracket	1704	326
PAD—License Lamp Bracket	0608	157
PAD—Longitudinal Side Seat Cotton	----	443
PAD—Longitudinal Side Seat Jute	----	442
PAD—Parking Lamp Mounting	0607	152
PAD—Rear Axle Drive Gear Thrust Screw	1104	241
PAD—Starting Motor Commutator End Plate Felt	0602	119-122
PAD—Transmission Cover Draft	----	345
	1807	347-373
PAD—Windshield Pivot Bracket	1801	342
PAD—Windshield Side Arm Bracket	1801	342-368
PAN—Clutch Housing	0207	46
PAN ASSEMBLY—Engine Dust	1702	322
PAN ASSEMBLY—Oil	0107	25
PANEL—Belt Roll Trim	1807	435
PANEL—Body Back	----	378
PANEL—Body Rear Lower	1807	418

P—Continued	Sub-Group	Page No.
PANEL—Body Side	1807	354-374-
		399-418
PANEL—Cab Side	1807	339-418
PANEL—Cowl Trim	1807	339-349-
		375-400-
		416-435
	----	376
PANEL—Cross Sill	1807	434
PANEL—Dash Clutch Housing Cover	1807	347-372-
		395-433
PANEL—Door Header Lock Pillar Trim	1807	401
PANEL—Door Hinge	1807	401
PANEL—Door Hinge Pillar Trim	1807	401
PANEL—Door Trim	1807	339-400-
		416-435
PANEL—Floor Transmission Cover	1802	423
PANEL—Floor Transmission Cover Center Floor	1802	423
PANEL—Headlining	----	441
PANEL—Hinge Pillar Trim	1807	340-417-
		435
PANEL—Instrument	1807	339-348-
		374-399-
		417-433
PANEL—Locker Box End	----	443
PANEL—Lower Under Door Side	----	441
PANEL—Outside Roof	----	440
PANEL—Rear Belt Rail Trim	1807	340
PANEL—Rear Quarter Trim	1807	340
PANEL—Rear Roof Center	1807	416
PANEL—Roof	1807	399
PANEL—Roof Deck	1807	399-417
PANEL—Roof Front Compartment	1807	418
PANEL—Roof Headlining	1807	401
PANEL—Roof Headlining Trim	1807	340-400-
		416-435
PANEL—Roof Rear	1807	418
PANEL—Side Lining	----	441
PANEL—Under Body Upper	1807	348
PANEL—Windshield Header	1807	348
	----	376
PANEL AND EXTENSION ASSEMBLY—Front Side	1807	348
PANEL ASSEMBLY—Body Rear	1807	339
PANEL ASSEMBLY—Body Side	1807	399-418
PANEL ASSEMBLY—Center Floor	1802	345-385
PANEL ASSEMBLY—Cowl Trim	1807	375-400
	----	376
PANEL ASSEMBLY—Dash	1807	417
PANEL ASSEMBLY—Dash Clutch Housing	1807	433
PANEL ASSEMBLY—Dash Clutch Housing Cover	1807	372
PANEL ASSEMBLY—Front	1807	354
PANEL ASSEMBLY—Front Fender Grille	1701	320
PANEL ASSEMBLY—Front Side	1807	399
PANEL ASSEMBLY—Instrument	1807	339-348-
		399
PANEL ASSEMBLY—Main Outside	----	440
PANEL ASSEMBLY—Rear	1807	374
PANEL ASSEMBLY—Shelf	----	378
PANEL ASSEMBLY—Side	1807	434
PANEL ASSEMBLY—Windshield Header	----	376
PANEL ASSEMBLY—Windshield Visor	1801	405
	1807	339
PAULIN—Roof	2310	495-496
PAWL—Hand Brake Lever	1201	248
PEDAL—Accelerator	0303	68
PEDAL—Booster Brake	1210	270
PEDAL ASSEMBLY—Brake	1204	255
PEDAL ASSEMBLY—Clutch	0204	44-45

ALPHABETICAL INDEX—Continued

P—Continued	Sub-Group	Page No.
PILOT—Front Axle Steering Knuckle King	----	230
PILOT—Front Axle Universal Drive	1005	222
PIN—Attendant's Seat Yoke	----	444
PIN—Auxiliary Seat Attaching	1804	386
PIN—Auxiliary Seat Support Spring Toggle	1804	353
PIN—Booster Brake Control Valve Operating Lever	1210	270
PIN—Booster Brake Control Valve Piston	1210	270
PIN—Booster Brake Control Valve Piston Pin Yoke	1210	270
PIN—Booster Brake Control Valve Support Operating Link to Pedal	1210	270
PIN—Booster Brake Cylinder Operating Lever to Cylinder	1210	270
PIN—Booster Brake Operating Cylinder Pivot	1210	270
PIN—Booster Brake Operating Lever to Link	1210	270
PIN—Brake Master Cylinder Piston Push Rod End	1205	258
PIN—Brake Shoe Adjusting	1203	254
PIN—Carburetor Air Intake Locating	0301	49
PIN—Carburetor Float Lever	0301	55
PIN—Carburetor Throttle Lever Hub	0301	49
PIN—Chain Case Cover Plate Dowel	0106	21
PIN—Clevis	2305	486
PIN—Clutch Release Lever	0203	42
PIN—Cotter	2305	486
PIN—Distributor Cap Hold-down Spring Hinge	0603	126-130
PIN—Door Hinge	1805	335-390-413-427
	1807	415
PIN—Door Remote Control and Window Regulator Handle	1805	389
PIN—Door Remote Control Handle	1805	334-389-413-426
PIN—Door Window Escutcheon	1805	389
PIN—Door Window Regulator Handle	1805	334-413-426
PIN—Front Axle Drive Gear Thrust Block	1003	228
PIN—Front Axle Drive Pinion Inner Bearing Trunnion Socket Bearing	1002	229
PIN—Front Axle Steering Knuckle King	----	227-230
PIN—Front Axle Steering Knuckle Pivot Lock	----	230
PIN—Front Axle Universal Drive Pivot	1005	222
PIN—Front Axle Universal Drive Thrust Ball	1005	222
PIN—Front Axle Universal Drive Trunnion Socket Bearing	1005	223
PIN—Front Shock Absorber to Link Rod and Eye Bolt	1603	314
PIN—Fuel Pump Rocker Arm	0302	61
PIN—Fuel Pump Rocker Arm Link	0302	61
PIN—Generator Frame Dowel	0601	107-111
PIN—Groove	2305	486
PIN—Ground Dowel	2305	486
PIN—Hand Brake Cable Clevis	1201	249
PIN—Hand Brake Cam Lever Clevis	1201	249
PIN—Hand Brake Lever Pawl Rod to Button	1201	248
PIN—Hand Brake Rod Clevis	1201	249
PIN—Lazy Back Seat Hinge	1804	353
PIN—Lift Gate Hinge	1807	397
PIN—Longitudinal Seat Hinge	1804	353
PIN—Partition Bracket	----	361
PIN—Pintle Hook	1502	289
PIN—Pintle Hook Latch	1502	289
PIN—Pintle Hook Latch Roller	1502	289
PIN—Power Take-off Eye Bolt Cotter	2010	459
PIN—Power Take-off Piston Rod Clevis	2001	454
PIN—Power Take-off Pump Cover Dowel	----	455
PIN—Power Take-off Shear	2010	461-462
PIN—Power Take-off Shifter Lever Clevis	2010	461
PIN—Power Take-off Shifter Shaft Fork Taper	2010	458
PIN—Power Take-off Valve Control Rod Yoke	----	457
PIN—Power Take-off Valve Control Rod Yoke Cotter	----	457
PIN—Propeller Shaft Universal Joint	0902	211
PIN—Rear Axle Differential Bearing Cone Adjuster Lock	1103	240

P—Continued	Sub-Group	Page No.
PIN—Rear Axle Drive Gear Thrust Block	1104	241
PIN—Rear Shock Absorber to Link Rod and Eye Bolt	1603	314
PIN—Rear View Mirror Arm Hinge	2201	470
PIN—Seat Back Hinge	1804	332
PIN—Seat Support to Bracket	1804	408
PIN—Side Window Regulator Handle	1805	389
PIN—Starting Motor Frame Dowel	0602	122
PIN—Starting Motor Pedal Rod	0602	120
PIN—Starting Motor Pedal Rod to Shift Yoke	0602	123
PIN—Steering Tie Rod End	1402	281
PIN—Straight	2305	486
PIN—Tail Gate Hinge	----	361
	1807	396
PIN—Tail Gate Hook	----	361
PIN—Tail Gate Hook Cotter	----	361
PIN—Tail Gate Hook Side Rod Connecting	----	361
PIN—Tail Gate Pivot	----	361
PIN—Taper	2305	486
PIN—Transfer Case Gear Shift Hand Lever Interlock	0806	189
PIN—Transfer Case Gear Shift Lever Rod Yoke End Clevis	0806	189
PIN—Transmission Gear Shift Lever Guide	0706	170-173
PIN—Transmission Gear Shift Rail Interlock	0706	171
PIN—Winch Brake Shoe Link	----	449-451
PIN—Winch Shifter Fork Pivot	----	449-451
PIN—Winch Universal Drive Shaft Shear	1901	452
PIN—Windshield Hinge	1801	329-367-383-405-421
PIN—Windshield Regulator Tape	1801	329-383
PIN—Windshield Regulator Tape Clip	1801	405
PIN AND CHAIN ASSEMBLY—Tail Gate Hinge	----	361
PIN AND EYE BOLT—Power Take-off	2010	460
PIN AND EYE BOLT—Power Take-off Shifter Shaft	2010	461
PIN AND NUT ASSEMBLY—Wheel Bearing Adjusting	1301	272-273
PIN ASSEMBLY	0103	14
PINION—Front Axle Differential	1002	217
PINION—Front Axle Drive	1003	218
PINION—Rear Axle Differential	1103	240
PINION—Rear Axle Drive	1104	241
PINION—Transfer Case Drive	0802	188
	0810	191
PINION—Transmission Drive	0703	173
PINION—Transmission Main Drive (or Gear)	0703	166
PINION—Transmission Speedometer Drive	0705	169-173
PINION AND CLUTCH ASSEMBLY—Starting Motor	0602	118-121
PINION AND GEAR—Front Axle Drive	1003	218
PIPE—Brake	1209	263-264-265-266-267
PIPE—Crankcase Breather	0107	28
PIPE—Muffler Tail	0402	84
PIPE—Oil Pump Outlet	0107	24
PIPE—Oil Pump Suction	0101	8
PIPE—Oil Suction	0107	24
PIPE—Power Take-off Cylinder Low Pressure	2001	454
PIPE ASSEMBLY—Crankcase Breather	0107	28-29
PIPE ASSEMBLY—Crankcase Ventilator Outlet	0107	26
PIPE ASSEMBLY—Exhaust	0402	83
PIPE ASSEMBLY—Oil Suction	0107	24
PISTON—Accelerator Pump	0301	49
PISTON—Brake Master Cylinder	1205	258
PISTON—Brake Wheel Cylinder	1207	261
PISTON—Shock Absorber	1603	316
PISTON AND PIN ASSEMBLY	0103	14
PISTON AND ROD—Carburetor Vacuum Pump	0301	49
PISTON ASSEMBLY	0103	14
PIVOT—Booster Brake Operating Cylinder	1210	270

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

P—Continued	Sub-Group	Page No.
PIVOT—Door Vent Wing Upper and Lower	1805	431
PIVOT—Windshield Frame	1801	343-368
PLAIN WASHER	2304	483
PLAIN WASHER—Engine Front Support Plate Bolt	0110	34
PLAIN WASHER—Floor Mat	1802	344-370-423
PLAIN WASHER—Front Fender Grille to Fender	1701	319
PLAIN WASHER—Front Fender Splash Shield to Fender	1702	321
PLAIN WASHER—Radiator Shell to Fender Grille Screw	0501	90
PLAIN WASHER—Steering Gear	1403	282
PLAIN WASHER—Steering Post Bracket	1405	286
PLAIN WASHER—Transmission Cover Draft Pad	1807	347
PLAIN WASHER—Windshield Adjusting Arm	1801	382
PLATE—Body Hold Down	1807	394
PLATE—Body Hold Down Bolt	1803	385-407
	1807	414
PLATE—Body to Frame Guide	1807	432
PLATE—Cab Body to Frame Guide	1803	331
PLATE—Cab Hold Down Bracket	1807	371
PLATE—Camshaft Sprocket Thrust	0106	18
PLATE—Carburetor Air Shutter	0301	49
PLATE—Caution	2202	471
PLATE—Chain Case Cover	0106	19
PLATE—Clutch Pressure	0202	42
PLATE—Cowl Rear View Mirror Arm Tapping	2201	471
PLATE—Curtain Fastener	2315	500
PLATE—Distributor Lock	0603	126-129-130
PLATE—Door Bumper Screw Tapping	1805	332
PLATE—Door Bumper Tapping	1805	409
	1807	395-432
PLATE—Door Check Arm Tapping	1807	415
PLATE—Door Inside Panel Cover	1807	415
PLATE—Door Lock Striker	1805	336-410
PLATE—Door Lower Sill	1805	411
PLATE—Door Sill Striker	----	442
PLATE—Door Vent Wing Upper Lock	1805	431
PLATE—Door Wedge	1805	410-411
PLATE—Engine Front Support	0110	34
PLATE—Fender Rear Support	1504	293
PLATE—Floor	1802	370-385
PLATE—Floor Board	1802	331-344-370
PLATE—Floor Board Booster Cylinder Cover	1802	385
PLATE—Floor Board Gear Shift Lockout Housing Cut-out Cover	1801	384
PLATE—Floor Board Seat Anchor	1802	385
PLATE—Floor Frame Kickup Cover	1802	385
PLATE—Floor Scuff	1802	385-407-423
PLATE—Floor Transmission Cover Center Floor Panel Floor	1802	423
PLATE—Floor Transmission Cover Panel Floor	1802	423
PLATE—Folding Step	----	442
PLATE—Front Spring Clip	1601	306
PLATE—Fuel Gauge Inspection	----	445
PLATE—Fuel Gauge Inspection Hole Cover	----	378
PLATE—Gearshift Lockout Housing Cutout Cover	1802	370
PLATE—Headlamp Mounting Socket	0607	149
PLATE—Hood Lock	1704	325
PLATE—Hood Name (Dodge)	1704	325
PLATE—Horn Button Retainer	0609	160
PLATE—Horn Mounting Bracket Lamination	0609	160
PLATE—Identification	2202	471
PLATE—Instruments Back	0605	140
PLATE—Instruments Face	0605	140
PLATE—Manifold Heat Control Valve	0108	33
PLATE—Oil Pan Front Oil Seal	0107	25

P—Continued	Sub-Group	Page No.
PLATE—Power Take-off Drive Shaft Oil Retainer	2010	459-461
PLATE—Power Take-off End	2010	459-460
PLATE—Power Take-off Pump Gear Wear	----	455
PLATE—Power Take-off Pump Port Hole Cover	----	455
PLATE—Power Take-off Shifter Lever End	2010	461
PLATE—Propeller Shaft Universal Joint Bushing Lock	0902	209
PLATE—Propeller Shaft Universal Joint Cross Bushing Lock	0902	211
PLATE—Rear Spring Clip	1601	307
PLATE—Rear View Mirror Arm Locking	2201	470
PLATE—Roof Paulin End Curtain Fastener	2310	496
PLATE—Scuff	1807	418
PLATE—Serial Number	2202	471
PLATE—Shock Absorber Piston Intake Valve	1603	316
PLATE—Shock Absorber Rebound Valve Back	1603	316
PLATE—Speedometer Face	2203	472
PLATE—Spotlight Reflector Pressure	2204	473
PLATE—Tail Gate Lock Face	1807	373
PLATE—Tail Gate Lock Striker	----	378
PLATE—Tire Carrier Clamping	1505	294
PLATE—Tire Carrier Locking	1505	294
PLATE—Trailer Electric Brake Load Control Switch Face	0604	138
PLATE—Transmission Gear Shift Housing	0706	169
PLATE—Transmission Gear Shift Lever Ball Friction	0706	170-173
PLATE—Transmission Reverse Idler Gear Shaft Lock	0704	173
PLATE—Transmission Synchronizer Shifting	0704	173
PLATE—Water Pump Cover	0503	96
PLATE—Windshield Frame Joint Tapping	1801	328-382-420
PLATE—Windshield Frame Tapping	1801	367-404
PLATE—Windshield Handle Striker	1801	367
PLATE—Windshield Header Cover	1807	372
PLATE—Windshield Header Panel	1801	421
PLATE—Windshield Header Panel Cover	1801	329-383-415
PLATE—Windshield Pull-to Handle Striker	1801	329-383-405-421
PLATE AND CARRIER ASSEMBLY—Spare Tire	----	376
PLATE AND CATCH—Tail Gate Staff	1807	355
PLATE AND COVER ASSEMBLY—Clutch Pressure	0202	42
PLATE AND DUST SEAL ASSEMBLY—Clutch Housing	0207	46
PLATE AND HANGER ASSEMBLY—Battery Support	1803	371
PLATE AND ROD ASSEMBLY—Carburetor Step-up Piston	0301	56
PLATE AND VALVE SHAFT ASSEMBLY—Manifold Heat Control	0108	33
PLATE ASSEMBLY—Distributor Breaker	0603	127-129-131
PLATE ASSEMBLY—Distributor Breaker Sub (Upper Plate)	0603	127-131
PLATE ASSEMBLY—Generator Commutator	0601	114
PLATE ASSEMBLY—Generator Commutator End	0601	107-111-114
PLATE ASSEMBLY—Manifold Heat Control	0108	33
PLATE ASSEMBLY—Spare Tire Carrier	----	376
PLATE ASSEMBLY—Starting Motor Commutator End	0602	119-122
PLIERS	2306	487-488
PLUG—Battery Drain Tube Hole Button	1807	355
PLUG—Battery Ground Wire Hole Button	1807	355
PLUG—Blackout Lamp Socket and Cable Terminal	0608	154
PLUG—Body Side Panel	1807	399
PLUG—Body Side Panel Hole	1807	374-399
PLUG—Button	2315	500
PLUG—Carburetor Fuel Bowl Lower	0301	49
PLUG—Carburetor Idle and Pump Discharge Rivet Passage	0301	53
PLUG—Carburetor Idle Hole Rivet Passage	0301	53
PLUG—Carburetor Main Metering Rivet Passage	0301	53

ALPHABETICAL INDEX—Continued

P—Continued	Sub-Group	Page No.
PLUG—Carburetor Pump Check Passage	0301	53
PLUG—Carburetor Pump Jet Rivet Passage	0301	53
PLUG—Carburetor Step-up Jet Rivet Passage	0301	53
PLUG—Clutch Housing Hole	0207	46
PLUG—Clutch Housing Screw Hole	0207	46
PLUG—Countersunk Headless Square Hole Pipe	2315	500
PLUG—Cylinder Head Timing Hole	0101	9
PLUG—Distributor Base Terminal	0603	129
PLUG—Distributor Base Terminal Slot	0603	127-131
PLUG—Distributor Cap Rubber	0603	126-129-130
PLUG—Distributor Terminal Slot	0603	126
PLUG—Distributor Vacuum Chamber	0603	129-133
PLUG—Drag Link End	1401	281
PLUG—Expansion	2315	501
PLUG—Front Axle Drive Pinion Carrier	1003	219
PLUG—Front Axle Housing Trunnion Socket Grease	1001	216
PLUG—Front Axle Steering Knuckle King Pin Oil Seal	----	227
PLUG—Front Spring Shackle Bushing	1602	311
PLUG—Fuel Pump Top Cover Valve	0302	60
PLUG—Headless Pipe	2315	501
PLUG—Hexagon Head Pipe	2315	501
PLUG—Horn Button Cable Contact	0609	161
PLUG—Instrument Panel Voltage Hole	1807	348
PLUG—Oil Filter Drain	0107	31
PLUG—Oil Pan Drain	0107	25
PLUG—Power Take-off Cylinder Filler	2001	454
PLUG—Power Take-off Drive Shaft Welch	2010	458
PLUG—Power Take-off Gear Housing Pipe Plug	2010	458
PLUG—Power Take-off Pump Ball Check	----	455
PLUG—Power Take-off Shaft Plunger Pipe	2010	460
PLUG—Power Take-off Shift Plunger Pipe	2010	459
PLUG—Power Take-off Shifter Shaft Lock Ball Spring	2010	458
PLUG—Propeller Shaft Universal Joint Cross Grease	0902	209
PLUG—Rear Axle Differential and Carrier Housing Tube	1103	239
PLUG—Rear Axle Drive Pinion Carrier	1104	242
PLUG—Rear Axle Drive Shaft Bearing Oil Hole	1102	239
PLUG—Rear Axle Housing Drain	1101	238
PLUG—Rear Spring Shackle Bushing Upper and Lower	1602	316
PLUG—Side Front Compartment Battery Lead Wire Hole Button	1807	355
PLUG—Square Head Pipe	2315	501
PLUG—Steering Gear Housing Oil Filler	1403	283
PLUG—Tail Lamp Cable	0608	159
PLUG—Trailer Electric Brake Control Terminal	0604	138
PLUG—Transfer Case Declutch Shaft Carrier Cover Oil	0805	188
PLUG—Transfer Case Drain	0801	178
PLUG—Transfer Case Filler	0801	178-188-191
PLUG—Transmission Case Brake Hole	0701	166
PLUG—Transmission Case Drain	0701	166-173
PLUG—Transmission Case Filler	0701	166
PLUG—Transmission Gear Shift Reverse Stop Plunger Spring	0706	170
PLUG—Transmission Speedometer Drive Pinion Hole Plug	0705	169
PLUG—Truck Wiring Terminal	2313	499
PLUG—Winch Worm Housing Vented	----	449-451
PLUG—Windshield Wiper	1801	406
PLUG—Windshield Wiper Hole	1801	330
PLUG AND BAFFLE ASSEMBLY—Brake Master Cylinder Cover	1205	258
PLUG AND BUSHING ASSEMBLY—Front Spring Shackle	1602	310
PLUG AND BUSHING ASSEMBLY—Rear Spring Shackle	1602	316
PLUG AND BUSHING ASSEMBLY—Rear Spring Shackle Lower Left and Right	1602	316

P—Continued	Sub-Group	Page No.
PLUG AND TUBE ASSEMBLY—Carburetor Idle Orifice	0301	56
PLUG ASSEMBLY—Spark	2314	499
PLUNGER—Distributor Cap Contact Spring	0603	129-130
PLUNGER—Distributor Contact Spring	0603	126
PLUNGER—Front Axle Universal Drive	1005	229
PLUNGER—Oil Pressure Relief Valve	0107	24
PLUNGER—Power Take-off Shift Shaft Lock	2010	460
PLUNGER—Transfer Case Gear Shifter Lock Ball	0806	189
PLUNGER—Transmission Gear Shift Rail Interlock	0706	171
PLUNGER AND ROD ASSEMBLY—Carburetor Pump	0301	55
POINTER—Speedometer	2203	472
POLE—Roof Ridge	2310	495-496
POLE PIECE—Generator	0601	107-111-113
POLE PIECE—Starting Motor	0602	119-122
POST—Generator Terminal	0601	109-111-115
POST—Starting Motor Terminal	0602	120-123
PROJECTOR ASSEMBLY—Horn	0609	160
PROP ASSEMBLY—Lazy Back	1804	353
PROTECTOR—Brake Wheel Cylinder	1207	261
PROTECTOR—Cowl Hood	----	337
	1807	347-433
PROTECTOR—Fuel Pump Diaphragm	0302	62
PROTECTOR—Hood Corner	1704	324
PULLEY—Fan	0503	98
PULLEY—Generator	0601	106-111-112
PUMP—Tire	2306	487-488-489
PUMP ASSEMBLY—Fuel	0302	60
PUMP ASSEMBLY—Oil	0107	22
PUMP ASSEMBLY—Power Take-off	----	455
PUMP ASSEMBLY—Tire	2306	489
PUSH ROD—Fuel Pump Diaphragm	0302	62

R

RACE—Front Axle Drive Pinion Inner Bearing	1003	229
RACE—Front Axle Universal Drive Ball Inner	1005	221
RACE—Rear Axle Drive Pinion Inner Bearing	1104	243
RACK—Equipment	----	419
RACK ASSEMBLY—Front	----	362
RACK ASSEMBLY—Side	----	362
RADIMETER ASSEMBLY	0502	95
RAIL—Grab	----	377
RAIL—Transfer Case Clutch Shift	0805	191
RAIL—Transfer Case Shift	0806	184-189
RAIL—Transfer Case Two Speed Shift	0805	191
RAIL—Transmission Gear Shift First and Second	0706	170
RAIL—Transmission Gear Shift Reverse	0706	171
RAIL—Transmission Gear Shift Reverse Fork	0706	171
RAIL—Transmission Gear Shift Third and Direct	0706	171
RAIL AND FORK ASSEMBLY—Transmission Gear Shift Low and Reverse	0706	173
RAIL AND FORK ASSEMBLY—Transmission Gear Shift Second and Direct	0706	173
RATCHET AND BRACE ASSEMBLY—Cowl Ventelator	1807	339-348-375-400-419-434
REFLECTOR	----	440
REFLECTOR—Head Lamp	0607	150
REFLECTOR—Parking Lamp	0607	152
REFLECTOR—Spotlight	2204	473
REFLECTOR ASSEMBLY	2308	493
REGULATOR ASSEMBLY—Door Window	1805	336-392-409-428

ALPHABETICAL INDEX—Continued

R—Continued	Sub-Group	Page No.
REGULATOR ASSEMBLY—Generator	0601	106-111-112
REGULATOR ASSEMBLY—Seat	1804	408
REGULATOR ASSEMBLY—Side Window	1805	392
REGULATOR ASSEMBLY—Windshield	1801	329-383-405
REINFORCEMENT—Bumper	2102	465
REINFORCEMENT—Chain Case Cover	0106	19
REINFORCEMENT—Door	1805	427
REINFORCEMENT—Door Lock Cylinder	1805	390
	1807	415
REINFORCEMENT—Engine Front Support	0110	34
REINFORCEMENT—Engine Rear Support Frame	0110	37
REINFORCEMENT—Frame Cross	1506	296
REINFORCEMENT—Frame Rear Axle Bumper	1506	299
REINFORCEMENT—Frame Rear Brace Bar	1506	299
REINFORCEMENT—Frame Rear Crossmember	1506	300
REINFORCEMENT—Frame Trunnion Bracket Crossmember	1506	300
REINFORCEMENT—Gun Pedestal Floor	2207	479
REINFORCEMENT—Headlamp	0607	149
REINFORCEMENT—Hood Windshield Catch	1704	326
REINFORCEMENT—Hood Windshield Catch Rest	1704	326
REINFORCEMENT—Liquid Container Bracket to Fender Lower Support	1701	320
REINFORCEMENT—Liquid Container Bracket to Fender Upper Support	1701	320
REINFORCEMENT—Rear Axle Bumper	1506	299
REINFORCEMENT—Seat Support Riser	1804	346
REINFORCEMENT—Transfer Case Support Bracket	0808	189
REINFORCEMENT—Windshield	1801	342
REINFORCEMENT ASSEMBLY—Radiator Shell	0501	90
REMOTE CONTROL—Door	1805	335-409
REMOTE CONTROL—Door Lock	1805	428
RESISTOR—Fuel Gauge	0605	142
RESISTOR—Generator Regulator	0601	106
RESISTOR—Generator Regulator Carbon	0601	110
RESISTOR ASSEMBLY—Fuel Gauge Volt	0605	142
REST—Hood Windshield Catch	1704	326
REST ASSEMBLY—Door Arm	1807	341
REST ASSEMBLY—Seat Wheel Housing Arm	1804	371
RETAINER—Brake Pedal Pad	1807	373-433
RETAINER—Brake Shoe Anchor Bolt Oil Washer	1203	254
RETAINER—Brake Shoe Guide Rod Spring	1203	255
RETAINER—Carburetor Air Shutter Valve Spring	0301	49
RETAINER—Carburetor Float Lever Pin	0301	55
RETAINER—Carburetor Pump Spring	0301	56
RETAINER—Carburetor Vacuum Spring	0301	49
RETAINER—Clutch and Brake Pedal Draft Pad	1807	373-398
RETAINER—Clutch Pedal Draft Pad	0204	45
RETAINER—Clutch Pedal Pad	1807	373-433
RETAINER—Distributor Drive Shaft Oil (in Cylinder Block)	0603	129
RETAINER—Distributor Oil	0603	128-132
RETAINER—Door Body Header Trim Panel	1807	401
RETAINER—Door Header Panel	1807	340
RETAINER—Door Lock Cylinder	1805	335-390-414-427
	1807	415
RETAINER—Door Vent Wing Weatherstrip	1805	429
RETAINER—Draft Pad	1807	347
RETAINER—Drag Link Dust Cover	1401	280
RETAINER—Engine Rear Support Insulator	0110	36
RETAINER—Front Axle Drive Pinion Inner Bearing	1003	229
RETAINER—Front Axle Steering Knuckle Flange Joint Oil Seal Felt	1006	226
RETAINER—Front Axle Universal Drive Shaft	1005	222
RETAINER—Front Brake Shoe Anchor Bolt Oil Washer	----	227
RETAINER—Front Door Header Trim Panel	1807	435

R—Continued	Sub-Group	Page No.
RETAINER—Fuel Pump Diaphragm Oil Seal Gasket	0302	62
RETAINER—Generator Commutator End Ball Bearing	0601	107
RETAINER—Generator Commutator End Felt Washer	0601	114
RETAINER—Generator Drive End Ball Bearing	0601	111
RETAINER—Generator Drive End Felt Washer	0601	114
RETAINER—Generator Drive End Head Ball Bearing	0601	114
RETAINER—Generator Drive End Head Felt Washer	0601	108
RETAINER—Generator End Head Ball Bearing	0601	108
RETAINER—Generator End Head Felt Washer	0601	108
RETAINER—Head Lamp Cable Terminal Plug	0607	151
RETAINER—Head Lamp Lens	0607	149
RETAINER—Head Lamp Reflector Tension Spring	0607	150
RETAINER—Map Case Lid Fastener	----	378
RETAINER—Oil Pump Drive Gear	0107	23
RETAINER—Power Take-off Drive Shaft Packing	2010	458
RETAINER—Propeller Shaft Spline Yoke Oil Seal (Front) (Intermediate) (Rear)	0901	205
RETAINER—Propeller Shaft Universal Joint Cross Dust Washer	0902	211
RETAINER—Propeller Shaft Universal Joint Cross Roller Bushing	0902	208
RETAINER—Propeller Shaft Universal Joint Cross Washer	0902	208
RETAINER—Rear Axle Drive Pinion Inner Bearing	1104	243
RETAINER—Rear Shock Absorber to Link Rod and Eye Bolt	1603	315
RETAINER—Roof Headlining Trim Panel	1807	340-400-416-435
RETAINER—Roof Panel	1807	399
RETAINER—Running Board Nut	1703	323
RETAINER—Shock Absorber Gasket	1603	316
RETAINER—Side Front Curtain Hinge	2310	496
RETAINER—Steering Gear Shaft Oil Seal	1403	285
RETAINER—Tail and Signal Lamp Lens	0608	157
RETAINER—Tail Gate Lock Cylinder	1805	371
RETAINER—Tail Lamp Blackout Lens and Shield	0608	156
RETAINER—Tail Lamp Cable Connector	0608	158
RETAINER—Tail Lamp Contact Insulator	0608	158
RETAINER—Tail Lamp Lens Blackout Shield	0608	155
RETAINER—Tail Lamp License Lamp	0608	156
RETAINER—Transfer Case Declutch Shifter Shaft Oil Seal	0805	188
RETAINER—Transfer Case Drive Gear Shaft Bearing	0802	179
RETAINER—Transfer Case Drive Pinion Bearing	0802	188
RETAINER—Transfer Case Driven Gear Bearing	0803	180
RETAINER—Transfer Case Driven Gear Shaft Bearing	0803	180
RETAINER—Transfer Case Idler Gear Bearing	0804	181
RETAINER—Transfer Case Idler Gear Shaft Bearing	0804	182
RETAINER—Transfer Case Shift Rail Felt Washer	0806	184
RETAINER—Transmission Drive Pinion Bearing	0703	173
RETAINER—Transmission Gear Shift Rail	0706	173
RETAINER—Transmission Gear Shift Reverse Stop Plunger Spring	0706	170
RETAINER—Transmission Main Drive Pinion Bearing	0703	166
RETAINER—Transmission Main Shaft Rear Bearing	1201	251
RETAINER—Transmission Rear Bearing	0704	173
RETAINER—Valve Spring	0105	17
RETAINER—Winch Worm	----	449
RETAINER—Winch Worm Housing Bearing	----	451
RETAINER ASSEMBLY—Battery	1803	407
RETAINER ASSEMBLY—Crankshaft Rear Bearing Oil Seal	0102	11
RETAINER ASSEMBLY—Floor Board Radio Base	1802	385
RETAINER ASSEMBLY—Front Axle Steering Knuckle Flange Oil Seal	1006	226
RETAINER ASSEMBLY—Generator Ball Bearing	0601	114
RETAINER ASSEMBLY—Parking Lamp Reflector	0607	152
RETAINER ASSEMBLY—Roof Deck Panel	1807	417

ALPHABETICAL INDEX—Continued

R—Continued	Sub-Group	Page No.
RETAINER ASSEMBLY—Transfer Case Drive Shaft Bearing	0802	191
RETAINER ASSEMBLY—Transfer Case Driven Shaft Bearing	0803	191
RETAINER ASSEMBLY—Transmission Main Shaft Rear Bearing	0704	168
RING—Blackout Driving Lamp Bulb Retainer	0608	153
RING—Blackout Sealed Beam Headlight Retaining	2308	492
RING—Carburetor Pump Retainer	0301	56
RING—Distributor Cam Lock Spring	0603	129-133
RING—Distributor Drive Shaft Cam and Stop Plate Lock Spring	0603	129
RING—Front Axle Universal Drive Shaft Lock	1005	222
RING—Generator Arm Snap	0601	115
RING—Generator Armature Snap	0601	109
RING—Piston	0103	12-13
RING—Power Take-off Drive Shaft Lock	2010	460
RING—Power Take-off Piston	2001	454
RING—Starting Motor Pinion and Clutch Shift Collar Shift Spring Lock	0602	118-121
RING—Steering Gear Housing Bracket Adjust Sleeve Lock	1403	284
RING—Tail Gate Hinge Pin Lock Clip	----	361
RING—Transmission Synchronizer Stop	0704	173
RING—Water Pump Seal Lock	0503	97
RING—Wheel Bead Lock	1301	272
RING—Wheel Bearing Oil Seal Retainer	1301	273
RING—Wheel Side	1301	272
RING—Winch Cable Drum Retainer	----	449-451
RING ASSEMBLY—Roof Ventilator Fan	2204	474
RIVET—Brake Shoe Lining	2317	502
RIVET—Countersunk Flat Head Tubular	2304	483
RIVET—Countersunk Head	2304	483
RIVET—Curtain Fastener Ring	2315	500
RIVET—Flat Countersunk Head Split	2304	483
RIVET—Flat Head	2304	483
RIVET—Flat Head Tubular	2304	483
RIVET—Liquid Container Bracket Chape	1701	320
RIVET—Liquid Container Bracket Strap to Bracket	1701	320
RIVET—Oval Head Split	2304	483
RIVET—Oval Head Tubular	2304	483
RIVET—Round Head	2304	484
RIVET—Tinned	2304	484
RIVET—Wagon Box Head	2304	484
ROCKER ARM ASSEMBLY—Fuel Pump	0302	61
ROD—Accelerator Pedal	0303	68
ROD—Accelerator Shaft to Throttle Control Bell Crank	0303	67-69
ROD—Battery	1803	407
ROD—Body Side Panel Tie	1807	354
ROD—Booster Brake Control Valve Piston	1210	270
ROD—Brake Shoe Guide	1203	255
ROD—Door Hinge	----	441
ROD—Front Axle Steering Knuckle Tie	----	230
ROD—Front Control Cross	----	361
ROD—Hood Prop	1704	326
ROD—Hood Side Hinge	1704	325
ROD—Map Board Support	----	378
ROD—Power Take-off Control	----	457
ROD—Power Take-off Piston	2001	454
ROD—Radiator Tie	0504	101
ROD—Rear Folding Step Hinge	----	442
ROD—Side Control	----	361
ROD—Starting Motor Pedal	0602	120-123
ROD—Tail Gate Hinge	----	362
ROD—Throttle Control Bell Crank to Carburetor	0303	71
ROD—Transfer Case Control	0806	183-186
ROD AND EYE BOLT ASSEMBLY—Shock Absorber Link	1603	314
ROD AND PISTON—Carburetor Vacuum Pump	0301	49
ROD AND PLATE ASSEMBLY—Carburetor Step-up Piston	0301	56
ROD AND PLUNGER ASSEMBLY—Carburetor Pump	0301	55
ROD AND TUBE ASSEMBLY—Front Shock Absorber Dust Shield Piston	1603	316
ROD ASSEMBLY—Brake Master Cylinder Piston Push	1205	258
ROD ASSEMBLY—Clutch Pedal Operating	0204	45
ROD ASSEMBLY—Connecting	0104	16
ROD ASSEMBLY—Hand Brake	1201	249
ROD ASSEMBLY—Hand Brake Lever Pawl	1201	248
ROD ASSEMBLY—Power Take-off Valve Control	----	457
ROD ASSEMBLY—Steering Tie	1402	281
ROD ASSEMBLY—Transfer Case Control Declutch Lever	0805	192
ROD ASSEMBLY—Transfer Case Control Shift Lever	0805	192
ROD ASSEMBLY—Transfer Case Declutch Shifter Shaft Lever	0805	188
ROD ASSEMBLY—Transfer Case Gearshift Lever	0806	189
ROLLER—Pintle Hook Latch	1502	289
ROLLER—Transfer Case Drive Gear Bearing	----	191
ROLLER—Transfer Case Driven Shaft	0803	191
ROLLER—Transmission Mainshaft Pilot Bearing	0704	173
ROLLER AND BUSHING ASSEMBLY—Propeller Shaft Universal Joint Cross	0902	211
ROLLER AND CAGE ASSEMBLY—Steering Gear Bearing	1403	285
ROLLER AND CONE—Power Take-off Taper Roller Bearing	2010	459
ROLLER AND CONE—Rear Spring Trunnion Bearing	1602	312
ROLLER AND CONE—Winch Worm Thrust Bearing	----	449-451
ROTOR—Distributor Drive Shaft	0603	128-129-132
RUN—Door Glass	1805	336-392-409-428
RUN—Side Window Glass	1805	392
RUNNING BOARD ASSEMBLY	1703	323

S

SADDLE—Exhaust Pipe	0402	83
SCREW—Binding Slotted Head Tapping	2304	484
SCREW—Brake Wheel Cylinder Bleeder	1207	259-260
SCREW—Brake Wheel Cylinder Bleeder Screw Cap	1207	260
SCREW—Camshaft Sprocket	0106	18
SCREW—Carburetor	0301	49-54
SCREW—Carburetor Idle Adjusting	0301	49
SCREW—Carburetor Idle Adjustment	0301	54
SCREW—Carburetor Throttle Adjusting	0301	54
SCREW—Crankshaft Bearing Cap	0102	11
SCREW—Cross Recess Cone Point Binding	2304	484
SCREW—Cup Point Headless Set	2304	484
SCREW—Fillister Head Machine	2304	484
SCREW—Flat Head Machine	2304	484
SCREW—Flat Head Sheet Metal	2304	484
SCREW—Flat Slotted Head Header Point	2304	484
SCREW—Hexagon Head Cap	2304	484
SCREW—Hexagon Head Header Point	2304	485
SCREW—Hexagon Head Tapping	2304	485
SCREW—Hexagon Head Washer Face Tapping	2304	485
SCREW—Hexagon Socket Set Screw Cone Point	2304	485
SCREW—Oval Head Cross Recess	2304	485
SCREW—Oval Head Machine	2304	485
SCREW—Oval Head Tapping	2304	485
SCREW—Oval Slotted Head Header Point	2304	484
SCREW—Round Head Cross Recess	2304	485
SCREW—Round Head Harden Metallic Drive	2304	485
SCREW—Round Head Machine	2304	485

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

S—Continued	Sub-Group	Page No.
SCREW—Round Point Headless Set	2304	485
SCREW—Round Slotted Head Header Point	2304	485
SCREW—Round Slotted Head Tapping	2304	485
SCREW—Square Head Set	2304	486
SCREW AND INTERNAL AND EXTERNAL TOOTH LOCKWASHER—Round Slotted Head	2304	486
SCREW AND INTERNAL TOOTH LOCKWASHER—Hexagon Head	2304	486
SCREW AND LOCKWASHER—Door Hinge	1805	334-390-413-427
	1807	415
SCREW DRIVER	2306	487-488
SEAL—Door	----	441
SEAL—Door Glass	----	442
SEAL—Door Striker Plate	----	442
SEAL—Folding Step Lock	----	443
SEAL—Fuel Tank Filler Tube Housing to Wheel House	0304	76
SEAL—Generator Regulator	0601	110
SEAL—Trailer Connector	0606	147
SEAL—Transfer Case Companion Yoke	0803	191
SEAL AND GUIDE ASSEMBLY—Shock Absorber Piston Rod	1603	316
SEAL AND WIRE—Carburetor Governor	0301	49
SEAL ASSEMBLY—Water Pump	0503	97
SEAL ASSEMBLY—Wheel Bearing Dust	1301	272
SEALER—Folding Top Back Window Glass	----	377
SEAT—Drag Link End	1401	281
SEAT—Front Axle Universal Drive Pivot	1005	228
SEAT—Front Spring Clip	1601	307
SEAT—Fuel Pump Strainer Bowl	0302	63
SEAT—Head Lamp Reflector Tension Spring	0607	150
SEAT—Longitudinal	1804	352
SEAT—Rear Spring Clip	1601	307
SEAT—Shock Absorber Rebound Valve Spring	1603	316
SEAT AND CUSHION ASSEMBLY	1804	371
SEAT AND MAP TABLE ASSEMBLY	1804	371
SEAT AND NEEDLE ASSEMBLY—Carburetor Float	0301	55
SEAT ASSEMBLY	1804	346-386-408
		362-377-442
SEAT ASSEMBLY—Attendants	----	444
SEAT ASSEMBLY—Auxiliary	1804	353-386
SEAT ASSEMBLY—Center	1804	386
SEAT ASSEMBLY—Cross	1804	354
SEAT ASSEMBLY—Driver's	1804	386
	----	444
SEAT ASSEMBLY—Longitudinal	1804	353
SEAT INSERT—Exhaust Valve	0105	17
SEAT INSERT—Valve	0105	17
SEAT MECHANISM—Driver's	----	444
SECTION—Front	1807	395-433
SECTION ASSEMBLY—Body Rear	1807	339
SECTOR—Hand Brake Lever	1201	248
SET		
Distributor Breaker Point	0603	127-129-131-529
Distributor Weight Spring	0603	128-129-132
Generator Brush	0601	109-111-115-526
Rear Axle Drive Gear and Pinion Matched	1104	241
Starter Motor Brush	0602	119
		122-528
SHACKLE—Front Spring	1602	310-311

S—Continued	Sub-Group	Page No.
SHACKLE—Front Spring Inner and Outer	1602	311
SHACKLE—Rear Spring	1602	316
SHACKLE AND BUSHING ASSEMBLY—Rear Spring	1602	311
SHAFT—Accelerator	0303	67-69
SHAFT—Brake Pedal	1204	256
SHAFT—Carburetor Air Shutter	0301	49
SHAFT—Clutch Pedal	0204	45
SHAFT—Distributor Drive	0603	128-132
SHAFT—Door Ventilator Window Handle	1805	425
SHAFT—Front Axle Differential Pinion	1002	217
SHAFT—Front Axle Universal Drive	1005	221
SHAFT—Oil Pump Drive	0107	23
SHAFT—Oil Pump Idler Gear	0107	23
SHAFT—Power Take-off	2010	460
SHAFT—Power Take-off Cross Head	2001	454
SHAFT—Power Take-off Drive	----	457
	2010	458-459-460-461
SHAFT—Power Take-off Drive Cluster Gear	2010	459
SHAFT—Power Take-off Idler Gear	2010	461
SHAFT—Power Take-off Propeller	2010	460
SHAFT—Power Take-off Pump Drive	----	455
SHAFT—Power Take-off Reverse Idler Gear	2010	459-460-461
SHAFT—Power Take-off Shift	2010	460-461
SHAFT—Power Take-off Shifter	2010	458-459
SHAFT—Rear Axle Differential Pinion	1103	240
SHAFT—Rear Axle Drive	1102	238
SHAFT—Steering Gear	1403	285
SHAFT—Sub Frame Body Hinge	----	359
SHAFT—Tire Carrier Arm Latch	1505	295
SHAFT—Transfer Case Declutch	0805	188
SHAFT—Transfer Case Declutch Shifter	0805	188
SHAFT—Transfer Case Drive	0802	191
SHAFT—Trasnfer Case Drive Gear	0802	179
SHAFT—Transfer Case Driven Gear	0803	180-188-191
SHAFT—Trasnfer Case Gear Shifter	0806	189
SHAFT—Transfer Case Idler Gear	0804	181-188-191
SHAFT—Transfer Case Main	0802	188
SHAFT—Transmission Main	0704	167-173
SHAFT—Transmission Reverse Idler Gear	0704	168-173
SHAFT—Water Pump	0503	96
SHAFT—Winch Cable Drum	----	449-451
SHAFT—Winch Shifter Fork Knob	----	449-451
SHAFT—Winch to Power Take-off Propeller	2010	461
SHAFT—Winch Universal Drive	1901	452
SHAFT—Winch Worm	----	449-451
SHAFT—Windshield Gear and Sprocket	1801	329
SHAFT AND ARM ASSEMBLY—Carburetor Throttle	0301	55
SHAFT AND BRACKET ASSEMBLY—Door Ventilator Window Handle	1805	425
SHAFT AND BRACKET ASSEMBLY—Rear Spring Trunnion	1602	312
SHAFT AND BRACKET ASSEMBLY—Transfer Case Control Hand Lever	0806	184
SHAFT AND BRACKET ASSEMBLY—Transfer Case Control Lever	0805	192
SHAFT AND DRIVE GEAR ASSEMBLY—Oil Pump	0107	23
SHAFT AND GEAR ASSEMBLY—Windshield Regulator Sprocket	1801	405
SHAFT AND GOVERNOR ASSEMBLY—Distributor	0603	127
SHAFT AND GOVERNOR ASSEMBLY—Distributor Drive	0603	127-129-132
SHAFT AND IMPELLER ASSEMBLY—Water Pump	0503	96

ALPHABETICAL INDEX—Continued

S—Continued	Sub-Group	Page No.
SHAFT AND LEVER ASSEMBLY—Carburetor Choke Control	0301	55
SHAFT AND LEVER ASSEMBLY—Transfer Case Control Shift	0806	186
SHAFT AND LEVER ASSEMBLY—Transfer Case Gearshift Lever	0805	189
	0806	189
SHAFT ASSEMBLY—Carburetor Throttle Lever	0301	49
SHAFT ASSEMBLY—Distributor Drive	0603	129
SHAFT ASSEMBLY—Front Axle Universal Drive	1005	220
SHAFT ASSEMBLY—Oil Pump Drive	0107	23
SHAFT ASSEMBLY—Propeller (Front) (Intermediate) (Rear) (Transfer Case to Front Rear Axle) (Transfer Case to Pillow Block) (Pillow Block to Rear Rear Axle)	0901	203-210
SHAFT ASSEMBLY—Speedometer Cable Drive	2203	472
SHELL—Door	1805	333-388-412-425
	1807	415
SHELL ASSEMBLY—Cab	1805	337
SHELL ASSEMBLY—Door	1805	388-412-425
	1807	415
SHELL ASSEMBLY—Headlamp	0607	149
SHELL ASSEMBLY—Radiator	0501	90
SHELL SIDE ASSEMBLY—Radiator	0501	90
SHELL TOP ASSEMBLY—Radiator	0501	90
SHIELD—Battery Splash	1803	371-385
SHIELD—Body Dust	1807	348
SHIELD—Body to Rear Fender Front	1702	322
SHIELD—Distributor Base	0603	131
SHIELD—Fuel Pump Heat	0302	63
SHIELD—Fuel Tank Filler Tire Chain	0304	78
SHIELD—Tail and Signal Lamp Body	0608	155
SHIELD—Tail Lamp Lens Blackout	0608	155-156
SHIELD ASSEMBLY—Front Fender Grille Dust	1701	319
SHIELD ASSEMBLY—Front Fender to Frame Splash	1702	321
SHIELD ASSEMBLY—Fuel Tank	0304	79
SHIELD ASSEMBLY—Headlamp	0607	149
SHIM—Brake Master Cylinder Piston	1205	258
SHIM—Cab Back Window	1805	333
SHIM—Clutch Pedal Reinforcement Bracket	0204	45
SHIM—Crankshaft Sprocket	0102	10
SHIM—Door Lock Striker	1805	393
SHIM—Door Lock Striker Plate	1805	410-429
SHIM—Front Axle Differential Bearing	1002	217-228
SHIM—Front Axle Drive Pinion Outer Bearing	1003	229
SHIM—Front Axle Steering Knuckle Flange Upper Bearing Cap	1006	226
SHIM—Front Axle Steering Knuckle Thrust Bearing	----	227-230
SHIM—Front Axle Universal Drive Flange	1005	223-224
SHIM—Front Axle Universal Drive Shaft Thrust Button	1005	222-223
SHIM—Hood Front Hinge Support to Shell	1704	324
SHIM—Lift Gate Lock Striker	1807	397
SHIM—Rear Axle Differential Bearing	1103	240
SHIM—Rear Axle Drive Pinion Front Bearing	1104	242
SHIM—Rear Axle Drive Pinion Outer Bearing	1104	243
SHIM—Rear Axle Drive Shaft Bearing	1102	239
SHIM—Rear Spring	1601	305
SHIM—Steering Gear Housing Cap	1403	263
SHIM—Tail Gate Striker	1807	396
SHIM—Transfer Case Declutch Shaft Carrier Cover	0805	188
SHIM—Transfer Case Drive Gear Bearing Retainer	0802	179
SHIM—Transfer Case Drive Pinion Rear Bearing Retainer	0802	188
SHIM—Transfer Case Driven Gear Bearing	0803	181
SHIM—Transfer Case Driven Shaft Bearing	0803	191

S—Continued	Sub-Group	Page No.
SHIM—Transfer Case Driven Shaft Rear Bearing Cover	0803	188
SHIM—Transfer Case Idler Gear Bearing Retainer	0804	182
SHIM—Transfer Case Idler Gear Shaft Bearing	0804	191
SHIM—Transfer Case Idler Shaft Front Cover	0804	188
SHIM—Transfer Case Idler Shaft Rear Cover	0804	188
SHIM—Transfer Case Main Shaft Front Cover	0802	188
SHOE AND LINING ASSEMBLY—Wheel Brake	1202	251
SHOE AND LINING ASSEMBLY—Winch Brake	----	449-451
SHROUD ASSEMBLY—Radiator Fan	0501	94
SHUTTER ASSEMBLY—Carburetor Air	0301	49
SIDE ASSEMBLY—Body	----	376
SIDEMEMBER—Frame	1506	296-297
SIDEMEMBER—Sub Frame	----	359
SILENCER—Steering Gear Housing Grease Tube	1403	283
SKIRT—Rear End	----	441
SLEEVE	2315	501
SLEEVE—Clutch Release Bearing	0203	43
SLEEVE—Fuse	2315	500
SLEEVE—Ignition Coil Primary Cable Terminal	0604	136
SLEEVE—Ignition Coil to Filter and Starter Cable Terminal	0604	136
SLEEVE—Instrument Board Wiring	0606	145
SLEEVE—Steering Gear Housing Bracket Eccentric Adjust	1403	284
SLEEVE—Trailer Electric Brake Control Terminal	0604	138
SLEEVE—Transmission Clutch Gear	0703	173
SLEEVE—Transmission Speedometer Drive Pinion	0705	169
SLEEVE—Truck Wiring Terminal	2313	499
SLEEVE AND GEAR ASSEMBLY—Transmission Clutch	0704	173
SLEEVE AND NUT ASSEMBLY	2315	500
SLEEVE ASSEMBLY—Shock Absorber Cylinder Tube	1603	316
SLIDE—Door Dovetail	1805	411
SLING ASSEMBLY—Litter	----	443
SLINGER—Brake Support Oil	1203	253
SLINGER—Front Axle Drive Pinion Bearing Oil	1003	220
SLINGER—Rear Axle Drive Pinion Front Bearing Oil	1104	242
SLINGER—Wheel Brake Drum Oil	1302	274
SNAP RING—Transfer Case Driven Gear Shaft Rollers	0803	191
SNAP RING—Transfer Case Idler Shaft Rear Cover	0804	188
SNAP RING—Transmission Clutch Gear	0704	173
SNAP RING—Transmission Main Drive Pinion Bearing Retainer	0703	167
SNAP RING—Transmission Mainshaft Pilot Bearing	0704	173
SNAP RING—Transmission Mainshaft Rear Bearing Retainer	0704	168
SNAP RING—Transmission Synchronizer	0704	173
SNAP RING—Wheel Bearing Oil Seal	1301	272-273
SOCKET—Carpet and Curtain Fastener	2315	501
SOCKET—Disc Wheel Wrench	2306	487-488-489
SOCKET—Dome Lamp Switch	0606	144
SOCKET—Drag Link Ball	1401	280
SOCKET—Folding Tap Dowel	----	376
SOCKET—Front Axle Housing Trunnion	1001	216
SOCKET—Headlamp Beam Indicator	0607	152
SOCKET—Instrument Lamp	0605	140
SOCKET—Tail and Signal Lamp	0608	155
SOCKET—Voltmeter Lamp	0605	142
SOCKET AND CABLE ASSEMBLY—Blackout Lamp	0608	154
SOCKET AND CABLE ASSEMBLY—Head Lamp	0607	150-151
SOCKET AND CABLE ASSEMBLY—Parking Lamp	0607	152
SOCKET ASSEMBLY—Dome Lamp	0608	159
SPACER—Accelerator Shaft Bracket	0303	69
SPACER—Battery Support Plate to Rear Fender	1803	385
SPACER—Blackout Driving Lamp Mounting Nut	0608	153
SPACER—Blackout Lamp Mounting	0608	153
SPACER—Body to Rear Fender Front Shield	1702	322
SPACER—Booster Brake Cylinder Operating Lever	1210	270

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

S—Continued	Sub-Group	Page No.
SPACER—Brake Pedal	1204	255
SPACER—Brake Shoe Anchor Bolt	1203	253
SPACER—Brake Tube Tee	1209	265
SPACER—Brake Wheel Cylinder	1207	260
SPACER—Bumper	2102	465
SPACER—Bumper Bracket	2102	465
SPACER—Door Regulator and Remote Control Handle	1805	334
SPACER—Door Remote Control Handle	1805	334-389-413-426
SPACER—Door Vent Wing	1805	430
SPACER—Door Wedge	1805	336-393-410
SPACER—Door Wedge Plate	1805	411-429
SPACER—Door Window Regulator Handle	1805	334-389-413-426
SPACER—Engine Rear Support	0110	38
SPACER—Engine Rear Support Insulator	0110	36
SPACER—Front Axle Drive Pinion Bearing	1003	219-220
SPACER—Front Spring Clip Seat	1601	307
SPACER—Fuel Tank Support Filler	0304	73
SPACER—Generator Arm	0601	115
SPACER—Generator Mounting Bracket Brace	0601	113
SPACER—Headlamp Beam Indicator	0607	152
SPACER—Manifold Heat Control Valve Adjusting Plate	0108	33
SPACER—Power Take-off Drive Cluster Gear	2010	459
SPACER—Power Take-off Idler Gear	2010	459-461
SPACER—Radiator Support	0504	99
SPACER—Rear and Rear Rear Spring Axle Bumper	1601	309
SPACER—Rear Auxiliary Spring	1601	307
SPACER—Rear Axle Drive Pinion Bearing	1104	243
SPACER—Rear Axle Drive Shaft Bearing Thrust Block	1102	239
SPACER—Rear Shock Absorber Frame Side Rail	1603	316
SPACER—Shock Absorber Piston Washer	1603	316
SPACER—Side Window Regulator	1805	392
SPACER—Side Window Regulator Handle	1805	389
SPACER—Starting Motor	0602	119
SPACER—Starting Motor Armature	0602	122
SPACER—Steering Post Bracket	1405	286
SPACER—Tail Gate Wedge	1807	396
SPACER—Tire Carrier Arm Hinge	1505	294
SPACER—Tire Carrier to Brace	1505	294
SPACER—Tow Hook	1501	288
SPACER—Trailer Electric Brake Control Switch	0604	138
SPACER—Transfer Case Control Lever	0805	192
SPACER—Transfer Case Control Shift Bracket	0805	192
SPACER—Transfer Case Control Shift Lever Bracket	0805	192
SPACER—Transfer Case Declutch Shaft Bearing	0805	188
SPACER—Transfer Case Drive Gear	0810	191
SPACER—Transfer Case Drive Gear Bearing Roller	0802	191
SPACER—Transfer Case Driven Shaft	0803	191
SPACER—Transfer Case Hand Lever Bracket	0806	183
SPACER—Transfer Case Idler Gear Bearing	0804	191
SPACER—Transfer Case Mounting Stud	0808	189
SPACER—Transmission Countershaft Bearing	0704	168-173
SPACER—Transmission Main Shaft Pilot Bearing	0704	167
SPACER—Transmission Shaft Flange	0902	208
SPACER—Transmission Speedometer Drive Gear	0705	169
SPACER—Winch Cable Guide	----	451
SPACER—Winch Worm Bearing	----	449-451
SPACER—Windshield Adjusting Arm	1801	420
SPACER—Windshield Adjusting Arm to Pillar Bracket	1801	328-382-404
SPACER—Windshield Clamp	1801	342-368
SPACER—Windshield Handle	1801	367
SPACER—Windshield Pull to Handle	1801	329-382-421
SPACER—Windshield Pull to Handle Stud	1801	404
SPACER—Windshield Wiper Motor	1801	330-384-406-422
SPACER—Windshield Wiper Mounting	1801	343-369
SPACER AND BEARING—Transmission Countershaft	0704	173
SPACER AND BRACKET ASSEMBLY—Rear Shock Absorber Left Frame	1603	316
SPACER AND BRACKET ASSEMBLY—Rear Shock Absorber Right Frame	1603	316
SPEEDOMETER ASSEMBLY	2203	472
SPIDER—Front Axle Differential Pinion	1002	228
SPIDER—Rear Axle Differential Pinion	1103	240
SPOUT—Housing Filler	....	440
SPRING	2315	501
SPRING—Accelerator Bell Crank Rod	0303	69
SPRING—Auxiliary Seat Support	1804	353
SPRING—Blackout Lamp Socket and Cable	0608	154
SPRING—Body Bolt	1807	337
SPRING—Body Bolt Tension	....	362
SPRING—Body Hold Down Bolt	1807	349
SPRING—Booster Brake Operating Cylinder Support	1210	270
SPRING—Brake Front Hose to Steering Knuckle	1209	266
SPRING—Brake Hose	1209	266
SPRING—Brake Pedal Pull Back	1204	256
SPRING—Brake Shoe Adjusting Cam	1203	254
SPRING—Brake Shoe Guide	1203	255
SPRING—Brake Wheel Cylinder Cup	1207	262
SPRING—Brake Wheel Cylinder Piston Cup	1207	261-262
SPRING—Carburetor Air Shutter	0301	49
SPRING—Carburetor Air Shutter Valve	0301	49
SPRING—Carburetor Choke Pull-back	0301	53
SPRING—Carburetor Idle Adjusting Screw	0301	49-53
SPRING—Carburetor Pump Conical	0301	53
SPRING—Carburetor Pump Link Pin	0301	53
SPRING—Carburetor Pump Plunger	0301	53
SPRING—Carburetor Step-up Piston	0301	53
SPRING—Carburetor Throttle Lever Adjustment	0301	53
SPRING—Carburetor Throttle Stop Screw	0301	49
SPRING—Carburetor Vacuum Pump	0301	49
SPRING—Clutch Pedal Pull Back	0204	44-45
SPRING—Clutch Pressure Plate	0202	42
SPRING—Clutch Release Bearing Sleeve Pull Back	0203	43
SPRING—Clutch Release Lever	0203	43
SPRING—Cowl Ventilator	1807	339-349-375-400-419-434
SPRING—Curtain Latch Handle	....	376
SPRING—Distributor Breaker Plate Arm	0603	127-131
SPRING—Distributor Cap Contact	0603	126-129-130
SPRING—Distributor Cap Hold Down	0603	126-129-130
SPRING—Distributor Vacuum Chamber	0603	129-133
SPRING—Door Dovetail	1805	411
SPRING—Door Lock and Link	1805	335-391-409-428
SPRING—Door Remote Control and Window Regulator Handle	1805	389
SPRING—Door Remote Control Handle Escutcheon	1805	413
SPRING—Door Vent Wing Lower Pivot	1805	431
SPRING—Door Ventilator Window Handle	1805	425
SPRING—Door Window Regulator Handle Escutcheon	1805	413
SPRING—Drag Link	1401	280
SPRING—Engine Front Support	0110	35
SPRING—Engine Rear Support	0110	38
SPRING—Front Axle Steering Knuckle Flange Oil Seal Felt Pressure	1006	226

ALPHABETICAL INDEX—Continued

S—Continued	Sub-Group	Page No.
SPRING—Front Axle Steering Knuckle Tie Rod End Dust Cover	....	230
SPRING—Front Axle Universal Drive Buffer	1005	229
SPRING—Front Axle Universal Drive Plunger	1005	229
SPRING—Front Seat Regulator Handle and Bracket	1804	408
SPRING—Front Shock Absorber Rebound Valve	1603	316
SPRING—Fuel Pump Diaphragm Oil Seal Gasket Retainer	0302	62
SPRING—Fuel Pump Diaphragm Push Rod	0302	62
SPRING—Fuel Pump Rocker Arm	0302	61
SPRING—Fuel Pump Top Cover Valve	0302	60
SPRING—Fuel Pump Upper Diaphragm	0302	62
SPRING—Generator Brush	0601	109-111-115
SPRING—Generator Capacitor Shield Guard	0601	112
SPRING—Generator Regulator Armature	0601	110-116
SPRING—Glove Box Door	1807	347-372-394-432
SPRING—Hand Brake Adjusting Bolt	1201	251
SPRING—Hand Brake Adjusting Operating	1201	251
SPRING—Hand Brake Band Anchor Clip	1201	250
SPRING—Hand Brake Lever Pawl Rod	1201	248
SPRING—Headlamp Beam Indicator Socket	0607	152
SPRING—Headlamp Reflector Lock	0607	150
SPRING—Headlamp Tension	0607	150
SPRING—Hood Lock Handle	1704	325
SPRING—Horn Button Retainer Plate Lock Ring	0609	160
SPRING—Instrument Lamp Socket	0605	141
SPRING—Oil Filter Cartridge	0107	31
SPRING—Oil Pressure Relief Valve	0107	24
SPRING—Pintle Hook Latch	1502	289
SPRING—Power Take-off Piston Rod Stop	2001	454
SPRING—Power Take-off Pump Ball Check	....	455
SPRING—Power Take-off Shift Shaft Ball	2010	461
SPRING—Power Take-off Shift Shaft Plunger	2010	460
SPRING—Power Take-off Shifter Shaft Ball	2010	459
SPRING—Power Take-off Shifter Shaft Lock Ball	2010	458
SPRING—Propeller Shaft Universal Joint	0902	211
SPRING—Propeller Shaft Universal Joint Centering Button	0902	211
SPRING—Rear Shock Absorber Rebound Valve	1603	316
SPRING—Seat Back Map Table Anti-Rattle Panel	1804	371
SPRING—Shock Absorber Piston Intake Valve Plate Spider	1603	316
SPRING—Side Curtain Latch	2310	496
SPRING—Spotlight Reflector	2204	473
SPRING—Starting Motor Brush	0602	119-122
SPRING—Starting Motor Pedal Rod Return	0602	120-123
SPRING—Starting Motor Pinion and Clutch Shift Collar Shift	0602	118-121
SPRING—Steering Gear Shaft Oil Seal	1403	285
SPRING—Steering Tie Rod End Dust Cover	1402	281
SPRING—Tail Gate Staff Catch	1807	355
SPRING—Throttle Control	0303	71
SPRING—Throttle Control Bell Crank Rod	0303	69
SPRING—Tire Carrier Arm Latch	1505	295
SPRING—Transfer Case Declutch Shifter Shaft Ball	0805	188
SPRING—Transfer Case Gear Shift Hand Lever Interlock	0806	189
SPRING—Transfer Case Gear Shifter Lock Ball Plunger	0806	189
SPRING—Transfer Case Shift Rail Poppet Ball	0805	191
	0806	184-189
SPRING—Transmission Gear Shift Lever	0706	170
SPRING—Transmission Gear Shift Lever Ball	0706	173
SPRING—Transmission Gear Shift Rail Poppet Ball	0706	171
SPRING—Transmission Gear Shift Rail Selector Ball	0706	173
SPRING—Transmission Gear Shift Reverse Stop Plunger	0706	170
SPRING—Transmission Synchronizer Spreader	0704	173
SPRING—Valve	0105	17
SPRING—Water Pump Seal Thrust	0503	97
SPRING—Water Pump Shaft and Bearing Lock	0503	96
SPRING—Wheel Brake Shoe Return	1202	252
SPRING—Winch Brake Shoe Link	....	449-451
SPRING—Winch Safety Brake Band	....	449-451
SPRING—Winch Shifter Fork	....	449-451
SPRING—Windshield Handle	1801	367
SPRING—Windshield Pull-to Handle	1801	329-382-421
SPRING—Windshield Pull-to Handle Spacer	1801	421
SPRING—Windshield Pull-to Handle Stud	1801	404
SPRING—Windshield Visor Bracket	1801	405
	1807	339
SPRING AND COVER ASSEMBLY—Seat Back	1804	346-408
SPRING ASSEMBLY—Brake Master Cylinder Piston Return	1205	258
SPRING ASSEMBLY—Front	1601	304
SPRING ASSEMBLY—Rear	1601	305
SPRING ASSEMBLY—Rear Auxiliary	1601	307
SPRING ASSEMBLY—Seat Back Cushion	1804	345-371
SPRING ASSEMBLY—Seat Cushion	1804	345-371
SPROCKET—Camshaft (Gear)	0106	18-19
SPROCKET—Crankshaft	0102	10
	0106	19
STANCHION AND WINDSHIELD ASSEMBLY	....	376
STANCHION ASSEMBLY—Windshield	....	376
STARTING MOTOR ASSEMBLY	0602	118-121
STEP—Tail Gate	....	362
STIFFENER—Sub Frame Sidemember	....	359
STOP—Blackout Lamp Socket and Cable	0608	154
STOP—Brake Master Cylinder Piston	1205	258
STOP—Bumper Body Step	2102	465
STOP—Door Bumper	1805	409
STOP—Door Check Arm Bumper	1805	333-38R-412-42-
STOP—Door Vent Lower Pivot	1805	431
STOP—Door Vent Wing Lower Pivot Washer	1805	431
STOP—Front Axle Universal Drive Shaft	1005	228
STOP—Transmission Gear Shift Rail	0706	171
STOP—Transmission Gear Shift Reverse Stop	0706	170
STRAINER—Fuel Tank Filler Tube	0304	73
STRAINER—Sponge Rubber Outside Panel	....	440
STRAINER ASSEMBLY—Fuel Tank Filler Tube	0304	74
STRAINER ASSEMBLY—Oil	0101	8
	0107	24
STRAP—Brake Master Cylinder Boot	1205	257
STRAP—Fuel Tank Hold-Down	0304	73
STRAP—Generator (to Regulator)	0601	112
STRAP—Generator Adjusting	0601	107-111-113
STRAP—Generator Field Terminal Cover Ground	0601	115
STRAP—Oil Filter Clamp	0107	30
STRAP—Roof Bow Rear Safety	2310	495-49
STRAP—Roof Poulin Roll-Up	2310	495-496
STRAP—Seat Safety	2310	495-496
STRAP—Tire Carrier	1505	294
STRAP ASSEMBLY—Floor	....	443
STRAP ASSEMBLY—Folding Top Stay	....	376-377
STRAP ASSEMBLY—Fuel Tank Support	0304	73
STRAP ASSEMBLY—Hold Down Top	2310	496
STRAP ASSEMBLY—Rear Bow to Shelf Top	2310	496
STRAP ASSEMBLY—Safety	....	362-37.
STRAP ASSEMBLY—Top Bow	....	362
STRAP ASSEMBLY—Top Rear Hold Down	....	376
STRAP ASSEMBLY—Upper Stay Top	2310	496
STRIKER—Door Lock	1805	393-42
STRIKER—Lift Gate Lock	1807	397
STRIKER—Tail Gate	1807	396

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

S—Continued	Sub-Group	Page No.
STRING—Cowl Ventilator	1807	375
STRIP—Door Glass Lower Channel Weather	1805	337
STRIP—Floor Board Skid	1802	351-385 407
STRIP—Floor Skid	1802	351
STRIP—Folding Top Deck Support	....	377
STRIP—Front Spring Front Cover Closing	1601	308
STRIP—Front Spring Rear Cover Closing	1601	308
STRIP—Rear Spring Front Cover Closing	1601	308
STRIP—Rear Spring Rear Cover Closing	1601	309
STRIP—Windshield Header Tacking	2310	496
STRIP ASSEMBLY—Folding Top Tacking	....	377
STRUT—Clutch Release Lever	0203	43
STUD	2315	501
STUD—Blackout Lamp Mounting	0608	153
STUD—Cab Side Panel Welt	1807	339-418
STUD—Carburetor Attaching	0301	49-52
STUD—Chassis Wiring Junction Block Insulator and Block Terminal	0606	146
STUD—Cowl Hood Lacing	1807	347-372- 395-417- 433
STUD—Cowl Hood Protector	....	337
	1807	433
STUD—Crankshaft Bearing Cap	0102	11
STUD—Cylinder Head	0101	9
	2205	477
STUD—Exhaust Manifold	0108	33
STUD—Folding Top Webbing Reinforcement	2310	496
STUD—Front Axle Differential and Carrier	1002	217
STUD—Front Axle Drive Pinion Carrier	1003	219
STUD—Front Axle Housing Cover	1001	216
STUD—Front Axle Steering Knuckle Flange	1006	224
STUD—Front Axle Steering Knuckle Flange Bearing Cap	1006	225
STUD—Front Axle Steering Knuckle Flange Bearing Upper Cap	1006	205
STUD—Front Axle Universal Drive Flange	1005	223
STUD—Front Shock Absorber Axle	1603	316
STUD—Front Spring Clip Plate	1601	307
STUD—Fuel Filter Element and Bowl	0302	65
STUD—Fuel Pump Heat Shield	0302	63
STUD—Hand Brake Spacer Link	1201	249
STUD—Junction Block Insulator Mounting	0606	146
STUD—Manifold Attaching	0108	32
STUD—Power Take-off End Plate	2010	460
STUD—Rear Axle Differential and Chassis	1103	239
STUD—Rear Axle Drive Pinion Carrier	1104	242
STUD—Rear Axle Drive Shaft	1102	238
STUD—Rear Axle Housing Cover Attaching	1101	238
STUD—Rear Shock Absorber Lower Pivot	1603	316
STUD—Rear Shock Absorber Upper Pivot	1603	316
STUD—Rear Spring Bearing Housing	1602	312
STUD—Side Panel	1807	434
STUD—Spare Tire Carrier	...	376
STUD—Steering Gear Housing Bracket	1403	283
STUD—Steering Gear Housing Bracket Adjusting	1403	284
STUD—Tail and Signal Lamp Mounting	0608	155-156
STUD—Throttle Control Bell Crank	0303	70
STUD—Tire Carrier	1807	419
STUD—Tire Carrier Arm	1505	295
STUD—Tire Carrier Support Lock	1505	294
STUD—Transfer Case Declutch Shifter Shaft Lever	0805	188
STUD—Transfer Case Drive Gear Bearing Retainer	0802	179
STUD—Transfer Case Driven Gear Bearing Retainer	0803	180
STUD—Transfer Case Driven Gear Shaft Bearing Retainer	0803	180
STUD—Transfer Case Idler Gear Bearing Retainer	0804	181
STUD—Transfer Case Idler Gear Shaft Bearing Retainer	0804	182

S—Continued	Sub-Group	Page No.
STUD—Transfer Case Mounting	0808	189
STUD—Wheel Hub	1302	275
STUD—Windshield Adjusting Arm	1801	382-420
STUD—Windshield Frame Pivot	1801	343
STUD—Windshield Handle	1801	367
STUD—Windshield Pull-to Handle	1801	329-383- 405-421
STUD—Windshield Wiper Arm Mounting	1801	369
STUD—Windshield Wiper Motor	1801	343
STUD AND ARM ASSEMBLY—Tire Carrier	1505	295
STUD AND BRACE ASSEMBLY—Tire Carrier	1807	419
STUD AND BRACE ASSEMBLY—Tire Carrier Support	1505	294
STUD AND BUSHING ASSEMBLY—Rear Spring Torque Line Ball	1602	312
STUD AND CUP ASSEMBLY—Rear Spring Trunnion Bearing Housing	1602	312
SUB-FRAME ASSEMBLY	....	359
SUPPORT—Battery Tray	1803	345
SUPPORT—Body Side Panel Flare Board	1807	354
SUPPORT—Cowl Trim	1807	395
SUPPORT—Cowl Trim Panel	1807	347-372- 433
SUPPORT—Engine Rear (To Clutch Housing)	0110	38
SUPPORT—Fender Front	1504	291
SUPPORT—Fender Rear	1504	292
SUPPORT—Folding Step	....	442
SUPPORT—Front Wheel Brake	....	227
SUPPORT—Fuel Tank Filler Tube Bracket	0304	75
SUPPORT—Hand Brake	1201	249
SUPPORT—Hood	1704	326
SUPPORT—Hood Windshield	1704	326
SUPPORT—Liquid Container Bracket to Fender Lower	1701	320
SUPPORT—Liquid Container Bracket to Fender Upper	1701	320
SUPPORT—Longitudinal Side Seat	....	443
SUPPORT—Muffler Front	0401	82
SUPPORT—Seat	....	362
	1804	408
SUPPORT—Starting Crank	2102	465-468
SUPPORT—Tail Gate Staff	1807	355
SUPPORT AND CROSSBAR ASSEMBLY—License Lamp and License Bracket	0608	157
SUPPORT AND HANGER ASSEMBLY—Battery	1803	385
SUPPORT ASSEMBLY—Auxiliary Seat	1804	353
SUPPORT ASSEMBLY—Battery	1803	331-344- 371-385- 407
SUPPORT ASSEMBLY—Battery Tray	1803	345-423
SUPPORT ASSEMBLY—Battery Tray Bracket	1803	423
SUPPORT ASSEMBLY—Brake	1203	252
SUPPORT ASSEMBLY—Engine Front	0110	34
SUPPORT ASSEMBLY—Fuel Tank	0304	73
SUPPORT ASSEMBLY—Hood Hinge	1704	324
SUPPORT ASSEMBLY—Radiator	0504	99
SUPPORT ASSEMBLY—Seat	1804	408
SUPPRESSION PARTS—Radio Noise	2205	475-476- 477
SUPPRESSOR—Ignition Coil Radio Interference	0604	139
SUPPRESSOR—Ignition Coil Spark Plug Cable	0604	137
SUPPRESSOR—Ignition Distributor Interference	0604	136
SUPPRESSOR—Radio Ignition Distributor Interference	2205	478
SUPPRESSOR—Spark Plug Cable	0604	139
SUPPRESSOR—Spark Plug Radio Interference	2314	499
SWITCH—Trailer Electric Brake Control	0604	138
SWITCH AND CABLE ASSEMBLY—Ignition Coil Lock	0604	135
SWITCH ASSEMBLY—Beam Control	0606	144
SWITCH ASSEMBLY—Blackout	0608	154
SWITCH ASSEMBLY—Blackout Driving Lamp	0608	153

ALPHABETICAL INDEX—Continued

S—Continued	Sub-Group	Page No.
SWITCH ASSEMBLY—Dome Lamp	0606	144
SWITCH ASSEMBLY—Ignition Coil Lock	0604	134
SWITCH ASSEMBLY—Ignition Lock	0604	139
SWITCH ASSEMBLY—Instrument Lamp	0606	144
SWITCH ASSEMBLY—Light	0606	144
SWITCH ASSEMBLY—Radio Feed	2204	474
SWITCH ASSEMBLY—Roof Ventilator Fan	2204	474
SWITCH ASSEMBLY—Signal Lamp	0608	157
SWITCH ASSEMBLY—Starting Motor (on Starter)	0602	120-123
SWITCH ASSEMBLY—Tail Lamp	0608	157
SWITCH ASSEMBLY—Trailer Electric Brake Load Control	0604	138
SWITCH ASSEMBLY—Voltmeter	0605	141
T		
TAB ASSEMBLY—Side Curtain Closure	----	377
TAB ASSEMBLY—Side Curtain Retaining	----	377
TABLE AND SEAT ASSEMBLY—Map	1804	371
TAKE-OFF—Power	2010	458-461
TANK—Booster Brake Supply	1210	270
TANK ASSEMBLY—Fuel	0304	72-74
TANK ASSEMBLY—Radiator Overflow	0501	102
TAPE—Windshield Regulator	1801	329-383-405
TAPPET—Valve	0105	17
TARPAULIN	----	361-362
TEE—Booster Brake Supply Tank	1210	270
TEE—Brake Tube	1209	264
TEE—Frame	1209	268
TEE—Front Axle Brake Tube	1209	268
TEE—Front Rear Axle Brake Tube	1209	268
TEE—Pipe	2315	500
TEE—Rear Rear Axle Brake Tube	1209	268
TEE AND TUBE ASSEMBLY—Windshield Wiper	1801	343-369
TERMINAL—Battery	2309	494
TERMINAL—Battery Ground Cable	0610	161
TERMINAL—Generator Field Coil	0601	113
TERMINAL—Generator Post	0601	109
TERMINAL—Generator Terminal Post Lead	0601	111
TERMINAL—Head Lamp Cable and Socket	0607	151
TERMINAL—Head Lamp Cable Ground	0607	151
TERMINAL—Heavy End Type	2315	501
TERMINAL—Ignition Coil Primary Cable	0604	136
TERMINAL—Ignition Coil Secondary Cable	0604	136-139
TERMINAL—Ignition Coil Spark Plug Cable	0604	137
TERMINAL—Ignition Coil to Filter and Starter Cable	0604	135
TERMINAL—Instrument Board Wiring	0606	145
TERMINAL—Mitre Type Cable	2315	501
TERMINAL—Mitre Type Spade	2315	501
TERMINAL—Starter Cable	0610	161
TERMINAL—Stud Type	2315	501
TERMINAL—Trailer Electric Brake Control	0604	138
TERMINAL—Truck Wiring	2313	499
TERMINAL—Two Wire Type	2315	501
TERMINAL BOX—Radio	0606	146
THERMOMETER ASSEMBLY	0605	143
THERMOSTAT	0502	94
TIP—Folding Top Finish Binding	----	377
TOGGLE—Auxiliary Seat Support Spring	1804	353
TOOL KIT ASSEMBLY	2306	487-488-489
TOOLS	2306	487-488-489
TOOLS—Clutch	2306	490
TOOLS—Cooling System	2306	490
TOOLS—Engine	2306	490
TOOLS—Front Axle	2306	491

T—Continued	Sub-Group	Page No.
TOOLS—Fuel System	2306	490
TOOLS—Miscellaneous	2306	491
TOOLS—Propeller Shaft	2306	491
TOOLS—Rear Axle	2306	491
TOOLS—Spring	2306	491
TOOLS—Transfer Case	2306	490
TOOLS—Transmission	2306	490
TOP ASSEMBLY—Folding	----	376-377
	2310	496
TRANSMISSION ASSEMBLY	0700	166-173
TRAY—Battery	1803	345
TRAY ASSEMBLY—Battery	1803	345-423
TRUNNION—Power Take-off Cylinder	2001	454
TUBE—Battery Tray Drain	1803	345-423
TUBE—Booster Brake Manifold to Check Valve	1210	270
TUBE—Brake	1209	263-264 265-266 267-268
TUBE—Camshaft Sprocket Oil	0106	19
TUBE—Carburetor Main Vent	0301	56
TUBE—Cowl Ventilator Drain	1807	339-349 375-400 419-434
TUBE—Cylinder Block Water Distributor	0101	8
TUBE—Drag Link	1401	280
TUBE—Engine to Oil Filter	0107	31
TUBE—Engine to Oil Gauge	0107	25
TUBE—Front and Rear Shock Absorber Cylinder	1603	316
TUBE—Front Axle Steering Knuckle Tie Rod	----	227
TUBE—Fuel Tank Filler	0304	73
TUBE—Fuel Tank Filler Vent	0304	79
TUBE—Fuel Tank Vent	0304	74
TUBE—Heater Defroster	2204	473
TUBE—Oil Filter to Engine	0107	31
TUBE—Oil Level Indicator	0107	26
TUBE—Propeller Shaft	0901	204-210
TUBE—Radiator Outlet	0505	101
TUBE—Shock Absorber Cylinder	1603	316
TUBE—Side Window Drain	1805	389
TUBE—Steering Gear	1403	285
TUBE—Steering Gear Housing Grease Retainer	1403	283
TUBE—Windshield Wiper	1801	330-343-344-369-384-406-422
TUBE AND BRACKET ASSEMBLY—Ignition Cable	2205	477
TUBE AND DIFFERENTIAL CARRIER ASSEMBLY—Rear Axle	1103	239
TUBE AND MOUNTING BRACKET—Ignition Cable	0604	139
TUBE AND MOUNTING BRACKET—Ignition Coil Cable	0604	136
TUBE AND PISTON ROD ASSEMBLY—Front Shock Absorber Dust Shield	1603	316
TUBE AND PISTON ROD ASSEMBLY—Rear Shock Absorber Dust Shield	1603	316
TUBE AND PLUG ASSEMBLY—Carburetor Idle Orifice	0301	56
TUBE AND REAR AXLE DIFFERENTIAL CARRIER ASSEMBLY—Axle Housing	1103	239
TUBE AND TEE ASSEMBLY—Windshield Wiper	1801	343-369
TUBE AND WORM ASSEMBLY—Steering Gear	1403	285
TUBE ASSEMBLY—Booster Brake Check Valve to Tee	1210	270
TUBE ASSEMBLY—Booster Brake Manifold to Check Valve	1210	270
TUBE ASSEMBLY—Brake	1209	268
TUBE ASSEMBLY—Brake Master Cylinder to Frame Tee	1209	263-268
TUBE ASSEMBLY—Carburetor Governor to Distributor	0301	56
TUBE ASSEMBLY—Carburetor to Distributor Vacuum Control	0301	56

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

T—Continued	Sub-Group	Page No.
TUBE ASSEMBLY—Carburetor to Governor	0301	56
TUBE ASSEMBLY—Crankcase Ventilator	0107	27
TUBE ASSEMBLY—Frame Tee to Front Hose Connection	1209	263
TUBE ASSEMBLY—Frame Tee to Front Hose Connector	1209	268
TUBE ASSEMBLY—Frame Tee to Rear Hose Connection	1209	263
TUBE ASSEMBLY—Front Axle Brake	1209	268
TUBE ASSEMBLY—Front Axle Differential and Axle Housing	1002	228
TUBE ASSEMBLY—Front Rear Axle Brake	1209	268
TUBE ASSEMBLY—Front Tee to Rear Tee Brake	1209	268
TUBE ASSEMBLY—Fuel Filter to Pump	0302	64
TUBE ASSEMBLY—Fuel Pump to Carburetor	0302	63
TUBE ASSEMBLY—Fuel Tank Filler	0304	73-74
TUBE ASSEMBLY—Fuel Tank to Fuel Filter	0304	76-78-79
TUBE ASSEMBLY—Fuel Tank to Fuel Pump	0304	75-77
TUBE ASSEMBLY—Radiator Overflow Tank Inlet	0501	102
TUBE ASSEMBLY—Rear Frame Tee to Rear Hose Connection	1209	263
TUBE ASSEMBLY—Rear Rear Axle Brake	1209	268
TUBE ASSEMBLY—Tee on Front Axle to Wheel Cylinder	1209	263
TUBE ASSEMBLY—Tee on Rear Axle to Wheel Cylinder	1209	263
U		
U-BOLT—Exhaust Pipe Saddle	0402	83
U-BOLT—Winch Cable and Chain	1905	452
UNION—Engine to Oil Gauge Tube	0107	25
UNION—Fuel Filter to Pump Hose	0302	64
UNION—Fuel Tank to Fuel Filter Tube	0304	76-79
UNION—Fuel Tank Tube to Fuel Filter Hose	0304	78
UNION—Inverted Flared Tube	2315	501
UNIT—Blackout Sealed Beam Headlight	2308	492
UNIT—Generator Voltage Regulator	0601	116
UNIT AND HOOD ASSEMBLY—Blackout Driving Lamp Sealed Beam	2308	492
UNIT ASSEMBLY—Tail and Signal Lamp	2308	492
UNIT ASSEMBLY—Tail and Signal Lamp Stop Light	2308	492
V		
VACUUM CHAMBER ASSEMBLY—Distributor	0603	129
VACUUM PUMP ASSEMBLY—Carburetor	0301	49
VALVE	0105	17
VALVE—Carburetor Air Shutter	0301	49
VALVE—Carburetor Throttle	0301	55
VALVE—Exhaust	0105	17
VALVE—Fuel Pump Top Cover	0302	60
VALVE—Intake	0105	17
VALVE—Power Take-off Pump	2001	455
VALVE—Power Take-off Valve Control Lever on Pump		457
VALVE ASSEMBLY—Booster Brake Check	1210	270
VALVE ASSEMBLY—Booster Brake Control	1210	270
VALVE ASSEMBLY—Brake Master Cylinder	1205	258
VALVE ASSEMBLY—Carburetor Choke	0301	55
VALVE ASSEMBLY—Carburetor Fuel	0301	49
VALVE ASSEMBLY—Carburetor Fuel Bowl Check	0301	49
VALVE ASSEMBLY—Carburetor Power Jet	0301	49
VALVE ASSEMBLY—Rear Shock Absorber Compression	1603	316
VALVE ASSEMBLY—Rear Spring Trunnion Bearing Housing Grease Relief	1602	312
VALVE SHAFT AND PLATE ASSEMBLY—Manifold Heat Control	0108	33
VALVE STEM—Carburetor Air Shutter	0301	49
VENT—Carburetor Well	0301	49
VENT ASSEMBLY—Front Axle Housing	1001	216
VENT ASSEMBLY—Front Rear Axle Stud	1209	268
VENT ASSEMBLY—Rear Axle Housing	1101	238

V—Continued	Sub-Group	Page No.
VENT ASSEMBLY—Rear Rear Axle Brake Stud	1209	268
VENTILATOR—Fuel Pump	1702	322
VENTILATOR—Roof		440
VENTURI—Carburetor	0301	49
VOLTMETER ASSEMBLY	0605	141
W		
WASHER—Air Grommet	2304	486
WASHER—Battery Ground Cable Terminal Felt	0610	161
WASHER—Battery Positive Terminal Anti-Corrosion	2309	494
WASHER—Blackout Lamp Mounting Spacer Cup	0608	153
WASHER—Blackout Lamp Socket and Cable Seal	0608	154
WASHER—Blackout Switch Mounting	0608	154
WASHER—Brake Master Cylinder Piston	1205	258
WASHER—Brake Shoe Anchor Bolt Oil	1203	254
WASHER—Carburetor Discharge Tube Fibre	0301	49
WASHER—Carburetor Fuel Bowl Fibre	0301	49
WASHER—Carburetor Fuel Valve Fibre	0301	49
WASHER—Carburetor Main Jet Fibre	0301	49
WASHER—Carburetor Power Jet Valve Fibre	0301	49
WASHER—Carburetor Throttle Lever Spring	0301	55
WASHER—Choke Control Guide and Housing Mounting	0303	71
WASHER—Countersunk	2304	486
WASHER—Curtain Fastener	2304	486
WASHER—Distributor Drive Shaft (.020" Thick)	0603	129
WASHER—Distributor Drive Shaft Thrust	0603	128-129-132
WASHER—Distributor Thrust	0603	128
WASHER—Distributor Vacuum Chamber	0603	129-133
WASHER—Door Check Arm	1805	333-388-412-424
WASHER—Door Remote Control	1805	335-409
WASHER—Door Ventilator Window Handle	1805	425
WASHER—Door Window Regulator	1805	428
WASHER—Engine Rear Support Insulator Bolt	0110	36
WASHER—Exhaust Manifold Stud	0108	33
WASHER—Floor Mat	1802	407
WASHER—Floor Mat Screw Plain	1802	385
WASHER—Front Axle Differential Pinion Thrust	1002	217
WASHER—Front Axle Drive Pinion Bearing	1003	219
WASHER—Front Axle Drive Pinion Bearing Oil Seal	1003	220
WASHER—Front Axle Drive Pinion Outer Bearing Adjusting Nut	1003	228
WASHER—Front Axle Steering Knuckle King Pin Set Screw Spring		227
WASHER—Front Axle Universal Drive Shaft Plain	1005	223
WASHER—Front Brake Shoe Anchor Bolt Oil		227
WASHER—Front Floor Mat Screw Plain	1802	331
WASHER—Front Shock Absorber Pivot Bushing Inner	1603	316
WASHER—Front Shock Absorber Pivot Bushing Outer	1603	316
WASHER—Fuel Filter Spacer	0302	64
WASHER—Fuel Pump Diaphragm Protector	0302	62
WASHER—Fuel Pump Rocker Arm Pin	0302	61
WASHER—Generator Adjusting Strap Cup	0601	107
WASHER—Generator Capacitor Shielding	0601	112
WASHER—Generator Commutator End Ball Bearing Retaining	0601	111-114
WASHER—Generator Commutator End Felt	0601	108-111-114
WASHER—Generator Commutator End Spring	0601	114
WASHER—Generator Drive End Felt	0601	111-114
WASHER—Generator Drive End Head Felt	0601	108
WASHER—Generator Field Connection Insulating	0601	115
WASHER—Generator Insulating	0601	109
WASHER—Generator Insulation	0601	111
WASHER—Generator Post Bottom Insulating	0601	115

ALPHABETICAL INDEX—Continued

W—Continued	Sub-Group	Page No.
WASHER—Generator Regulator	0601	110
WASHER—Generator Regulator Insulating	0601	116
WASHER—Generator Terminal Insulating	0601	115
WASHER—Headlamp Beam Indicator Mounting	0607	152
WASHER—Headlamp Lens Retainer	0607	149
WASHER—Hood Lock Handle Plunger	1704	325
WASHER—Horn Insulating	0609	160
WASHER—Ignition Coil Terminal Insulating	0604	134
WASHER—Instruments Lamp Switch Mounting Nut	0606	144
WASHER—Intake to Exhaust Manifold	0108	32
WASHER—Light Switch Mounting	0606	144
WASHER—Manifold Attaching Stud Clamp	0108	32
WASHER—Power Take-off Drive Shaft	2010	459
WASHER—Power Take-off Valve Control Bell	....	457
WASHER—Propeller Shaft Companion Flange Nut	0901	207-210
WASHER—Propeller Shaft Spline Yoke Dust	0901	210
WASHER—Propeller Shaft Spline Yoke Oil Seal	0901	205
WASHER—Propeller Shaft Universal Joint Cross	0902	208
WASHER—Propeller Shaft Universal Joint Cross Dust	0902	211
WASHER—Propeller Shaft Universal Joint Thrust	0902	212
WASHER—Radiator Dash Bracket	1807	347
WASHER—Radiator Tie Rod Bracket	1807	417
WASHER—Radiator Tie Rod Dash Bracket	1807	338-395-433
WASHER—Rear Axle Differential Pinion Thrust	1103	240
WASHER—Rear Axle Differential Side Gear Thrust	1103	240
WASHER—Rear Axle Drive Pinion Bearing Oil Seal	1104	243
WASHER—Rear Axle Drive Pinion Front Bearing	1104	242
WASHER—Rear Axle Drive Pinion Rear Bearing	1104	242
WASHER—Rear Axle Drive Shaft	1102	238
WASHER—Rear Compartment Floor Mat Plain	1802	370
WASHER—Rear Shock Absorber Inner Pivot	1603	316
WASHER—Rear Shock Absorber Outer Pivot	1603	316
WASHER—Shock Absorber Piston	1603	316
WASHER—Starting Motor Armature Thrust	0602	119-122
WASHER—Starting Motor Fibre	0602	119
WASHER—Starting Motor Terminal Post Insulating	0602	123
WASHER—Starting Motor Terminal Post Insulator	0602	120
WASHER—Steering Gear Shaft Thrust	1403	285
WASHER—Steering Tie Rod End Dust Cover	1402	281
WASHER—Sub-Frame Body Hinge Shaft	....	359
WASHER—Tail Lamp Switch Mounting Nut	0608	157
WASHER—Throttle Control Bell Crank Stud Spring	0303	70
WASHER—Throttle Control Guide and Housing Nut Mounting	0303	69
WASHER—Trailer Electric Brake Load Control Mounting	0604	138
WASHER—Transfer Case Control Declutch Lever Rod Yoke Spring	0805	192
WASHER—Transfer Case Control Shift Lever Rod Yoke Spring	0805	192
WASHER—Transfer Case Drive Shaft Thrust	0802	191
WASHER—Transfer Case Idler Gear Retainer Shaft Nut	0804	191
WASHER—Transfer Case Shift Rail Felt	0806	184
WASHER—Transmission Countershaft	0704	173
WASHER—Transmission Countershaft Thrust	0704	173
WASHER—Transmission Gear Shift Reverse Stop Plunger	0706	170
WASHER—Transmission Main Drive Pinion Bearing Retainer	0703	167
WASHER—Transmission Mainshaft Flange Nut	0901	173
WASHER—Transmission Mainshaft Rear Bearing Oil Retainer	0704	168
WASHER—Transmission Mainshaft Rear Bearing Retainer	0704	168
WASHER—Water Pump Body Cover Plate Screw	0503	96
WASHER—Water Pump Seal Retainer	0503	97
WASHER—Water Pump Thrust	0503	97
WASHER—Wheel Adjusting Nut	1301	273
WASHER—Wheel Bearing Adjusting	1301	272

W—Continued	Sub-Group	Page No.
WASHER—Windshield Adjusting Arm	1801	342-367-368-404-420
WASHER—Windshield Adjusting Arm Lock Nut	1801	328
WASHER—Wind hield Adjusting Arm Pivot	1801	368
WASHER—Windshield Adjusting Arm Rubber	1801	382
WASHER—Windshield Adjusting Arm Spring	1801	367-382
WASHER—Windshield Adjusting Arm to Frame	1801	328
WASHER—Windshield Clamp Handle	1801	368
WASHER—Windshield Side Arm Bracket Plain	1801	342
WASHER—Windshield Side Arm Pivot Wing Nut	1801	342
WASHER—Windshield Visor Bracket	1801	405
WASHER—Windshield Visor Bracket Spring	1807	339
WASHER AND FERRULE—Blackout Lamp Socket and Cable	0608	154
WASHER AND SCREW—Carburetor Body to Air Horn	0301	54
WASHER AND SCREW—Carburetor Body to Flange	0301	54
WASHER AND SCREW—Floor Board Plate	1802	344-370
WASHER AND SCREW—Floor Plate	1802	385
WASHER AND SCREW—Front Floor Transmission Cover Draft Pad	1807	398
WASHER AND SCREW—Rear Axle Differential Adjuster Lock	1103	240
WASHER AND SCREW—Transmission Cover Draft Pad	 1807	345 347
WASHER AND SCREW—Transmission Cover Lubricating Hole Cover	....	345
WASHER AND SCREW ASSEMBLY—Front Axle Differential Bearing Adjuster Lock	1002	218
WASHER ASSEMBLY—Steering Gear Thrust	1403	285
WATER THROWER—Water Pump Shaft and Bearing	0503	96
WEATHERCORD—Door	1805 1807	430 341-401-415-417-435
WEATHERCORD—Roof Deck Panel	1807	417
WEATHERSEAL—Roof Headlining Panel	1807	401
WEATHERSEAL—Roof Panel	1807	399
WEATHERSEAL—Roof Rear Panel	1807	418
WEATHERSEAL—Tail Gate	 1807	379 373
WEATHERSEAL ASSEMBLY—Windshield	2310	496
WEATHERSTRIP—Cab Back Window	1805	337
WEATHERSTRIP—Cowl Ventilator	1807	339-349-375-400-434
WEATHERSTRIP—Cowl Ventilator Ratchet and Support	1807	419
WEATHERSTRIP—Door	1807	415
WEATHERSTRIP—Door Glass Belt	1805	393
WEATHERSTRIP—Door Glass Lower Channel	1805	337-393-414-430
WEATHERSTRIP—Door Glass Outer Belt	1805	393-430
WEATHERSTRIP—Door Lower	1805	337-393-414-430
WEATHERSTRIP—Door Vent Window Division Bar	1805	430
WEATHERSTRIP—Door Vent Wing	1805	429
WEATHERSTRIP—Front Door Glass Outer Belt	1805	337
WEATHERSTRIP—Lift Gate	1807	397
WEATHERSTRIP—Lift Gate Glass	1807	397
WEATHERSTRIP—Side Window Lower Channel	1805	393
WEATHERSTRIP—Tail Gate	1807	396
WEATHERSTRIP—Windshield	1801	329-343-369-383-405-421
WEATHERSTRIP ASSEMBLY—Door Glass Outside Panel	1805	414
WEATHERSTRIP ASSEMBLY—Door Lower	1805	414

PRICES AND/OR SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

ALPHABETICAL INDEX—Continued

W—Continued	Sub-Group	Page No.
WEDGE—Door	1805	336-392-410-429
WEDGE—Tail Gate	1807	396
WEDGE ASSEMBLY—Door	1805	429
WEIGHT—Wheel Balance	1302	275
WEIGHT ASSEMBLY—Distributor	0603	128-132
WEIGHT ASSEMBLY—Distributor Drive Shaft	0603	129
WELL—Carburetor	0301	49
WELT—Body Side Panel	1807	418
WELT—Cab Side Panel	1807	339
WELT—Fender to Body and Running Board	1701	318
WELT—Front Side Panel and Body Side Panel	1807	399
WELT—Side Panel	1807	434
WELTCORD—Wheelhouse to Side Panel	....	441
WHEEL ASSEMBLY	1301	272
WHEEL ASSEMBLY—Steering	1404	286
WHEEL HOUSE ASSEMBLY	....	440
WHEEL HUB ASSEMBLY	1302	274
WICK—Brake Shoe Adjusting Pin	1203	254
WICK—Distributor Base Oiler Felt	0603	127-129-131
WICK—Distributor Cam Sleeve Felt	0603	129-133
WICK—Distributor Drive Shaft Cam and Stop Plate Sleeve Felt	0603	129
WICK—Distributor Felt	0603	127
WINCH PARTS	....	448-449-451-452
WINDSHIELD AND STANCHION ASSEMBLY	....	376
WINDSHIELD ASSEMBLY	1801	328-342-367-368-382-404-420
WIRE—Drag Link Ball Dust Cover	1401	280
WIRE—Trailer Connector Ground	0606	147
WIRE—Transfer Case Shift Fork Screw Lock	0805	191
	0806	184-189
WIRE AND BUTTON ASSEMBLY—Throttle Control	0303	69-71
WIRE AND SEAL—Carburetor Governor	0301	49
WIRE ASSEMBLY—Dual Tail Light Extension	0608	159
WIRING—Instrument Panel Clip	1807	433
WIRING—Trailer Electric Brake Control	0604	138

W—Continued	Sub-Group	Page No.
WIRING ASSEMBLY—Body	0606	145
WIRING ASSEMBLY—Chassis	0606	145
WIRING ASSEMBLY—Dome Lamp and Ventilator	0608	159
WIRING ASSEMBLY—Generator	0601	111
WIRING ASSEMBLY—Generator to Regulator	0601	106
WIRING ASSEMBLY—Ignition Coil to Filter and Starter	0604	135
WIRING ASSEMBLY—Instrument Board	0606	145
WIRING ASSEMBLY—Instrument Panel Light Switch	0606	144
WIRING ASSEMBLY—Roof Ventilator Fan and Dome Lamp	2204	474
WOODSILL—Sub-Frame	....	359
WORM—Winch	....	449-451
WORM AND TUBE ASSEMBLY—Steering Gear	1403	285
WRAPPER—Front Spring Front Cover Canvas	1601	308
WRAPPER—Rear Spring Front Cover Canvas	1601	308
WRENCH	2306	487-488
WRENCH—Auto	2306	487-488
WRENCH—Spark Plug	2306	487
WRENCH—Wheel Bearing Adjusting Nut	2306	487-488-489
WRENCH ASSEMBLY—Wheel	2306	487-488

Y

"Y" CONNECTOR—Windshield Wiper Tube	1801	334-344-369-384-406-422
YOKE—Booster Brake Control Valve Piston Rod	1210	270
YOKE—Hand Brake Cable	1201	249
YOKE—Hand Brake Rod	1201	249
YOKE—Power Take-off Valve Control Rod	....	457
YOKE AND CABLE ASSEMBLY—Hand Brake	1201	249
YOKE AND DRUM ASSEMBLY—Hand Brake	1201	250
YOKE ASSEMBLY—Propeller Shaft Spline	0901	205-210
YOKE ASSEMBLY—Propeller Shaft Spline (Front—Intermediate—Rear) (Transfer Case to Front Rear Axle) (Transfer Case to Pillow Block) (Pillow Block to Rear Rear Axle)	0901	205
YOKE ASSEMBLY—Starting Motor Shift	0602	120-123

MAJOR GROUP INDEX

GROUP NO.	NAME OF GROUP	PAGES
01	ENGINE	1 thru 38
02	CLUTCH	39 thru 46
03	FUEL	47 thru 80
04	EXHAUST	81 thru 85
05	COOLING	87 thru 102
06	ELECTRICAL	103 thru 162
07	TRANSMISSION	163 thru 174
08	TRANSFER CASE	175 thru 192
09	PROPELLER SHAFT AND UNIVERSAL JOINT	193 thru 212
10	FRONT AXLE	213 thru 230
11	REAR AXLE	231 thru 244
12	BRAKES	245 thru 270
13	WHEELS, HUBS AND DRUMS	271 thru 276
14	STEERING	277 thru 286
15	FRAME AND BRACKETS	287 thru 300
16	SPRINGS AND SHOCK ABSORBERS	301 thru 316
17	HOODS, FENDERS, RUNNING BOARDS, APRONS	317 thru 326
18	BODY	327 thru 446
	Closed Cab	328 thru 341
	Open Cab	342 thru 349
	Pick Up-Express-Weapon and Gun Motor Carriage	350 thru 355
	Dump Body	356 thru 361
	Cargo Body	362
	Telephone Body	363 thru 365
	Reconnaissance and Radio	366 thru 380
	Carry-All Body	381 thru 401
	Panel Body	402 thru 419
	Ambulance	420 thru 446
19	WINCH	447 thru 452
20	POWER TAKE-OFF	453 thru 462
21	BUMPER AND GUARD	463 thru 468
22	MISC. BODY, CHASSIS AND ACCESSORIES	469 thru 480
23	GENERAL USE, STANDARDIZED PARTS	481 thru 502
25	BEARING CHART	503 thru 506
26	SPECIFICATIONS LINES, HOSE AND TUBES	507 thru 510