

FRAME AND BRACKETS

GROUP

15


FROM PAGE 287 THRU 300

INDEX OF FRAME SUB-GROUPS

NO. SUB. GROUP	PARTS IN SUB GROUP	PAGE
1501	Front Tow Hook and Attaching Parts.....	288
1502	Pintle Hook and parts.....	289
1503	Front and Rear Spring Hangers.....	289
1504	Running Board Hangers and parts.....	290
	Front Fender Supports and parts.....	291-292
	Front and Rear Fender Support Bracket.....	293
1505	Tire Carrier Support Brace and parts.....	294-295
1506	Frame Assembly—Crossmembers and Parts.....	296
	Crossmember Gusset — Clinch Nut.....	297
	Crossmembers and parts.....	298-299

FRAME AND BRACKETS—GROUP 15

FRONT TOW HOOK AND PARTS—SUB-GROUP 1501



USM-FR-1

YEAR AND ENGINEERING SYMBOL	Front TOW HOOK		Tow Hook SPACER -		Tow Hook BOLT (Short)	Tow Hook NUT	Tow Hook LOCK- WASH'R	Tow Hook BOLT—Long		Tow Hook NUT	Front Tow Hook LOCK- WASH'R	
	Less Winch	With Winch	Less Winch	With Winch				Less Winch	With Winch			
	2 Req'd	2 Req'd	2 Req'd	2 Req'd				2 Req'd	2 Req'd		2 Req'd	
1940—T202	592299	☆	☆	☆	124169	120371	120384	124169	☆	120371	120384	
1940—T203	576458	577632	☆	☆	124306	124545	131046	120234	124169	120371	120384	
1941—T207	598379	598379	☆	916070	660378	120371	120384	530395	126038	120371	120384	
1941—T211	598379	☆	☆	☆	660378	120371	120384	530395	☆	120371	120384	
1941—T215	598379	598379	☆	916070	660378	120371	120384	530395	530395	120371	120384	
1941—T112	592299	☆	494153	☆	124169	120371	120384	124169	☆	120371	120384	
1941—T118	592299	☆	494153	☆	124169	120371	120384	124169	☆	120371	120384	
1942—T214	920763	920995	☆	☆	660378	120371	120384	124250	124250	121358	121574	
1943—T223	920763	920995	☆	☆	660378	120371	120384	124250	124250	121358	121574	


☆ Not Used

: CURRENT NUMBER—FOR PREVIOUS NUMBER, SEE PARTS SUPERSEDECE LIST.


FRAME AND BRACKETS—GROUP 15

PAGE 289

PINTLE HOOK PARTS—SUB-GRP. 1502



FRONT AND REAR SPRING HANGER—SUB-GROUP 1503



USM-FR-2

PINTLE HOOK ASSY.	Pintle Hook BOLT	Pintle Hook NUT	Pintle Hook LOCK- WASH'R	Front SPRING HANGER ASSY.—Front				Front Spring Front Bracket BUSH- ING	Front SPRING HANGER ASSY. Rear		Rear SPRING HANGER or BRACKET		
				Right Less Winch	Left Less Winch	Right With Winch	Left With Winch		Right	Left	Front	Rear	
1 Req'd	4 Req'd	4 Req'd	4 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	2 Req'd	1 Req'd	1 Req'd	2 Req'd	2 Req'd	
598456	124244	121358	121574	589560	589561	☆	☆	☆	589679	589679	598644	576032	
567847	☆	☆	☆	588700	588700	588700	588700	562302	588702	588702	588025	588025	
598456	124244	121358	121574	916126	916125	916128	916127	594254	915261	915261	598644	576032	
598456	124244	121358	121574	916126	916125	☆	☆	594254	915261	915261	598644	576032	
598456	124244	121358	121574	916126	916125	916128	916127	594254	915261	915261	598644	576032	
☆	☆	☆	☆	589560	589561	☆	☆	☆	589679	589679	590417	573505	
See Note 1 567847	☆	☆	☆	594935	594935	☆	☆	594937	594938	594938	588025	588025	
See Note 2 920762	123961	121358	121574	921420	921420	921420	921420	594254	921422	921423	921032	921032	
929330	8 Req'd 124174	8 Req'd 120371	8 Req'd 120384	921420	921420	921420	921420	594254	921422	921423	☆	☆	

PINTLE HOOK AND PARTS

PINTLE HOOK ASSEMBLY Part No. 929330	MODEL T214		MODEL T223	
USM-FR-2A Model T223	1—928361	Pintle Hook	1—928361	Pintle Hook
	1—928363	Pintle Hook Pin	1—928363	Pintle Hook Pin
	1—137254	Pintle Hook Cotter Pin	1—109354	Lubricating Fitting
	1—928364	Pintle Hook Latch	1—928364	Pintle Hook Latch
	1—928366	Latch Roller	1—928366	Latch Roller
	1—928367	Latch Roller Pin	1—928367	Latch Roller Pin
	1—928368	Latch Spring	1—928368	Latch Spring
	1—928365	Latch Pin	1—928365	Latch Pin
	2—103407	Latch Cotter Pin	2—103407	Latch Cotter Pin
			1—929344	Support Flange (Front)
			1—929337	Support Flange (Rear)
			1—929339	Pintle Hook Nut
			1—929338	Pintle Hook Lockwasher
			1—137298	Pintle Hook Nut Cotter Pin

☆ Not Used

NOTE 1

Used only on T118 after Serial No. 81334245.


NOTE 2

Used on all Models except Carryall and Emergency Repair Chassis

FRAME AND BRACKETS—GROUP 15

RUNNING BOARD PARTS—SUB-GROUP 1504

USM-FR-3



YEAR AND ENGINEER- ING SYMBOL	BODY STYLES	Running Board HANGER (Front)		Running Board HANG'R Inter- mediate (Left)	Running Board HANGER (Rear)		Running Board Hanger RIVET
		Right	Left		Right	Left	
		1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	As Req'd
1940—T202	RECONNAISSANCE AND RADIO	590691	590691	590691	593110	593110	104113
	PICK-UP AND CARRY ALL	590691	590691	☆	593110	593110	104113
1940—T203	CARGO AND DUMP BODY	591011	591011	☆	591011	591011	104113
	AMBULANCE	912601	912601	☆	592414	592414	104113
1941—T207	EXPRESS	590691	590691	☆	593110	593110	104113
	RECONNAISSANCE AND RADIO	590691	590691	590691	593110	593110	104113
	AMBULANCE	590691	590691	☆	916533	916533	104113
	RADIO	590691	590691	590691	☆	593110	104113
	CARRY ALL—PANEL	590691	590691	☆	590691	590691	104113
1941—T211	AMBULANCE—CLOSED CAB —NO BODY	590691	590691	☆	916533	916533	104113
	EXPRESS	590691	590691	☆	593110	593110	104113
	RADIO	590691	590691	590691	☆	593110	104113
	RECONNAISSANCE	590691	590691	590691	593110	593110	104113
	CARRY ALL—PANEL	590691	590691	☆	590691	590691	104113
1941—T215	EXPRESS	590691	590691	☆	593110	593110	104113
	RECONNAISSANCE	590691	590691	590691	593110	593110	104113
	RADIO	590691	590691	590691	☆	593110	104113
	CARRY ALL—PANEL— TELEPHONE	590691	590691	☆	590691	590691	104113
	AMBULANCE—CLOSED CAB —NO BODY	590691	590691	☆	916533	916533	104113
1941—T112	CARRY ALL—PANEL— TELEPHONE	590691	590691	☆	593110	593110	104113
	EXPRESS—PICK-UP	590691	590691	☆	593110	593110	104113
1941—T118	CAB AND CHASSIS	591011	591011	☆	591011	591011	104113
1942—T214	AMBULANCE	921845	921845	☆	921845	921845	☆
	RECONNAISSANCE	921845	925468	921845	☆	921845	☆
	CARRY ALL	921845	925468	921845	921845	921845	☆
	RADIO—WEAPON CARRIER	921845	925468	☆	921845	921845	☆
	GUN MOTOR CARRIAGE	921845	925468	☆	921845	921845	☆
	EMERGENCY REPAIR CHASSIS	921845	921845	☆	921845	921845	☆
	TELEPHONE MAINTENANCE AND INSTALLATION	921845	921845	921845	921845	921845	☆
1943—T223	PERSONNEL & CARGO	921845	925468	☆	921845	921845	☆

ALL MODELS EXCEPT T214—T223 USED RIVETS TO ATTACH RUNNING BOARDS, HANGERS, MODEL T214 USES BOLTS, NUTS, ETC., LISTED BELOW.

ALL T214 MODELS EXCEPT AMBULANCE, CARRY-ALL, EMERGENCY REPAIR CHASSIS AND TELEPHONE MAINTENANCE AND INSTALLATION

3—120647 Bolt—Upper
3—120369 Nut
6—178551 Lockwasher
3—120424 Bolt—Lower
3—120371 Nut
6—178591 Lockwasher

T214, AMBULANCE, CARRY-ALL, EMERGENCY REPAIR CHASSIS AND TELEPHONE MAINTENANCE AND INSTALLATION

4—120647 Bolt—Upper (Ambulance, Carry-All & Emergency Repair Chassis)
4—121615 Bolt—Upper (Intermediate Hanger)
(Telephone Maintenance and Installation)
4—120369 Nut
8—178551 Lockwasher
4—120424 Bolt—Lower
4—120371 Nut
8—178591 Lockwasher

ALL T214 MODELS EXCEPT AMBULANCE, EMERGENCY REPAIR CHASSIS AND TELEPHONE MAINTENANCE AND INSTALLATION

1—120647 Bolt (Left Front Hanger to Cab Bracket)
2—120677 (Left Front Hanger to Frame)
3—120369 Nut
6—178551 Lockwasher

MODEL T223 RUNNING BOARD HANGER ATTACHING PARTS


3—121615 Bolt—Upper (Front and Rear Hanger)
3—120369 Nut—Upper
6—178551 Lockwasher—Upper
3—120424 Bolt—Lower (Front and Rear Hangers)
3—120371 Nut—Lower
6—178591 Lockwasher—Lower
1—120647 Bolt (Left Front Hanger to Cab Bracket)
1—120369 Nut
2—178551 Lockwasher
2—120677 Bolt (Left Front Hanger to Frame)
2—120369 Nut
4—178551 Lockwasher

FRAME AND BRACKETS—GROUP 15

PAGE 291

FRONT FENDER SUPPORTS AND PARTS—SUB-GROUP 1504

USM-FR-4



YEAR AND ENGINEERING SYMBOL	Front SUP- PORT Right Less Winch	Front SUP- PORT Right With Winch	Front SUP- PORT Left Less Winch	Front SUP- PORT Left With Winch	Front Support Bracket to Fender RIVET	Front Support to Fender or Plate BOLT	Front Support to Fender or Plate NUT	Front Support to Fender or Plate Plain WASH'R	Front Support to Fender or Plate LOCK- WASH'R	Support to Radiator or Core Support SCREW	Support to Radiator or Core Support LOCK- WASH'R	Front Support ANTI- SQUEAK (Serviced by Foot)	Front Support BR'K'T Right With Winch
	A	A	A	A									
	1 Req'd	1 Req'd	1 Req'd	1 Req'd	18 Req'd	6 Req'd	8 Req'd	8 Req'd	8 Req'd	4 Req'd	4 Req'd	As Req'd	1 Req'd
1940—T202	913602	☆	913602	☆	4 Req'd 104266	2 Req'd 126442	2 Req'd 124573	2 Req'd 120395	2 Req'd 120383	123567	120383	313073	598956
1940—T203	594014	598938	594014	598939	4 Req'd 104266	2 Req'd 126442	2 Req'd 124573	2 Req'd 120395	2 Req'd 120383	123567	120383	313073	☆
1941—T207	915483	915483	915482	915482	104266	120647	179247	120394	120382	123567	120383	☆	☆
1941—T211 Up to Eng. No. 42001	915483	☆	915482	☆	104266	120647	179247	120394	120382	123567	120383	☆	☆
1941—T211 After Eng. No. 42001	915483	☆	915482	☆	104266	120647	179247	120394	120382	123567	120383	☆	☆
1941—T215	915483	915483	915482	915483	104266	120647	179247	120394	120382	123567	120383	☆	☆
1941—T112	913602	☆	913602	☆	☆	2 Req'd 126442	2 Req'd 124573	120395	120383	123567	120383	☆	☆
1941—T118	913496	☆	913496	☆	☆	2 Req'd 126442	2 Req'd 124573	120395	120383	123567	120383	313073	☆
1942—T214	924165	924165	924165	924165	☆	120647	☆	☆	178551	123572	178571	☆	☆
1943—T223	924165	924165	924165	924165	☆	120647	☆	☆	178551	123572	178571	☆	☆

A

A

FRONT FENDER TO FRONT SUPPORT PARTS WITH WINCH

Specify: 4—122007 Bolt
4—120376 Nut
8—120387 Plain Washer
4—120214 Lockwasher
For Model T203

FRONT FENDER FRONT SUPPORT TO SPLASH SHIELD BRACKET PARTS

Specify: 2—120741 Bolt
2—120368 Nut
2—120387 Plain Washer
2—120214 Lockwasher
Used on Models T207-T211-T215 Only


☆ Not Used

SNL G-657

FRAME AND BRACKETS—GROUP 15

FRONT FENDER AND FRAME SUPPORT BRACKET AND PARTS—SUB-GROUP 1504

USM-FR-5



YEAR AND ENGINEERING SYMBOL	Front Fender Blackout Lamp BRAK'T	Front Fender Rear Support BRAK'T	Frt. Fen. Frt. Support BRACE Right	Frt. Fen. Frt. Support BRACE Left	Frt. Fen. Frt. Support BRA'KT Assem'y Right	Frt. Fen. Frt. Support BRA'KT Assem'y Left	Frt. Fen. Rear SUP- PORT Right	Frt. Fen. Rear SUP- PORT Left	Frt. Fen. to Rear Support Frame Bracket BOLT	Frt. Fen. to Rear Support Frame Bracket Clinch NUT	Frt. Fen. to Rear Support Frame Bracket PLAIN WASH'R	Frt. Fen. to Rear Support Frame Bracket LOCK- WASH'R	Frt. Fen. Rear Support Frame BRACE or BRA'KT Right	Frt. Fen. Rear Support Frame BRACE or BRA'KT Left
	G	G	A	A	B	B	C	C					D	D
	1 Req'd	2 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	10 Req'd	10 Req'd	10 Req'd	10 Req'd	1 Req'd	1 Req'd
1940—T202	☆	☆	591556	591557	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
1940—T203	☆	☆	591556	591557	☆	See Note 1 598957	591112	591113	120647	120369	120394	120382	591352	591353
1941—T207	☆	☆	☆	☆	☆	☆	915304	915305	120647	120369	120394	120382	915298	915298
1941—T211 Up to Eng. No. 42001	☆	☆	☆	☆	☆	☆	915304	915305	120647	120369	120394	120382	915298	915298
1941—T211 After Eng. No. 42001	☆	☆	☆	☆	☆	☆	915304	915305	120647	120369	120394	120382	915298	915298
1941—T215	☆	☆	☆	☆	☆	☆	915304	915305	120647	120369	120394	178551	915298	915298
1941—T112	☆	☆	591556	591557	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
1941—T118	☆	☆	591556	591557	☆	☆	591112	591113	120647	120369	120394	120382	591352	591353
1942—T214	☆	☆	924168	924168	924182	SEE NOTE 2	922156	922157	120647	120369	☆	12 Req'd 178551	E 922144	E 922145
1943—T223	925383	922163	924168	924168	924182	926889	922156	922157	120647	120369	☆	12 Req'd 178551	F 922144	F 922145

NOTE 1

USED ON MODELS WITH WINCH
Also Specify: G—103487 Rivet

NOTE 2

Part No. 924183 Used Without Blackout Driving Lamp
Part No. 926889 Used With Blackout Driving Lamp

B

FRONT FENDER FRONT SUPPORT BRACKET
ATTACHING PARTS
Specify: 8—179247 Nut—T214
16—104268 Rivet
Used on Model T214-T223
Specify: 6—148248 Nut—T223

C

FRONT FENDER REAR SUPPORT BRACKET
AND ATTACHING PARTS
Specify: 10—104268 RIVET
4—122253 BOLT
4—120365 NUT
4—120395 PLAIN WASHER
4—1131048 LOCKWASHER
Used on Models T207-T211-T215 Only
Also: 4—104268 Rivet
Used on Model T203 Only

D

FRONT FENDER REAR SUPPORT FRAME
BRACKET PARTS
Specify: 16—104268 Rivet
12—103487 Rivet
Used on Models T207-T211-T215 Only
Specify: 4—104113 Rivet
Used on Model T203 Only
Also: 12—104268 Rivet
Used on Model T118 Only

Attaching Parts for Front Fender Rear
Support to Brace
4—120647 Bolt
4—120369 Nut
4—120394 Plain washer
4—120382 Lockwasher
Used on Models T207-T211-T215 Only

D

FRONT FENDER REAR SUPPORT TO FENDER
BOLT PARTS
Specify: 6—120647 Bolt (to Fender)
6—178551 Lockwasher (to Fender)
2—922183 Front Fender Rear Support
Bracket
2—179247 Front Fender Rear Support
Bracket Clinch Nut
Used on Model T214 Only

F

FRONT FENDER REAR SUPPORT FRAME
BRACKET
ATTACHING PARTS
Specify: 3—123572 Bolt (Short)
1—123841 Bolt (Long)
4—120370 Nut
6—178571 Lockwasher
Model T223

A

FRONT FENDER FRONT SUPPORT BRACE
ATTACHING PARTS
Specify: 4—123567 BOLT
4—120370 NUT
4—120395 PLAIN WASHER
4—120383 LOCKWASHER
Used on all Models shown except T214

E

FRONT FENDER REAR SUPPORT
FRAME BRACKET
(Bolt Parts)
Specify: 4—123572 Bolt
4—120370 Nut
8—178571 Lockwasher
Model T214


G

FRONT FENDER BLACKOUT LAMP PARTS
3—104268 Lamp Bracket RIVET
6—148248 Rear Support Bracket Clinch NUT
6—120647 Rear Support to Fender BOLT
6—178568 Rear Support to Fender BOLT
Lockwasher

FRAME AND BRACKETS—GROUP 15


PAGE 293

FRONT AND REAR FENDER SUPPORT BRACKETS AND PARTS—SUB-GROUP 1504



YEAR AND ENGINEERING SYMBOL	Front Fender Rear Support Brace RIVET	Front Fender Rear Support PLATE Right	Front Fender Rear Support PLATE Left	Front Fender Rear Support to Plate BOLT	Rear Fender Rear Support to Plate Bolt NUT	Front Fender Rear Support to Plate Plain WASH'R	Front Fender Rear Support to Plate LOCK- WASH'R	Front Fender Rear Support ANTI- SQUE'K	Rear Fender to Frame BRA'KT Except Recon- nals'nce	Rear Fender to Frame Bracket SCREW Except Recon- nals'nce	Rear Fender to Frame Bracket NUT Except Recon- nals'nce	Rear Fender to Frame Bracket Plain WASH'R Except Recon- nals'nce	Rear Fender to Frame Bracket LOCK- WASH'R Except Recon- nals'nce
	8 Req'd	1 Req'd	1 Req'd	2 Req'd	2 Req'd	4 Req'd	2 Req'd	As Req'd	2 Req'd	As Req'd	As Req'd	As Req'd	As Req'd
1940—T202	☆	☆	☆	☆	☆	☆	☆	313073	599054	122007	134556	120387	120214
1940—T203	104266	☆	☆	☆	☆	☆	☆	313073	☆	☆	☆	☆	☆
1941—T112	☆	☆	☆	☆	☆	☆	☆	313073	921916	4 Req'd 122017	4 Req'd 134556	4 Req'd 120387	4 Req'd 120214
1941—T118	104266	591354	591355	123567	120370	120395	120383	313073	☆	☆	☆	☆	☆

FRONT AND REAR FENDER SUPPORT BRACKETS AND PARTS—SUB-GROUP 1504



YEAR AND ENGINEERING SYMBOL	Rear Fender to Frame Bracket ANTI- SQUEAK Except Recon- nals'nce	Rear Fender to Frame BRACE Right	Rear Fender to Frame BRACE Left	Rear Fender to Frame Brace BOLT	Rear Fender to Frame Brace NUT	Rear Fender to Frame Brace Plain WASH'R	Rear Fender to Frame Brace LOCK- WASH'R
	See Note 1	1 Req'd	1 Req'd	4 Req'd	4 Req'd	4 Req'd	4 Req'd
1940—T202	313073	785936	785937	122126	134566	120394	120382
1940—T203	☆	☆	☆	☆	☆	☆	☆
1941—T112	313073	785936	785937	122126	134566	120387	120382
1941—T118	☆	☆	☆	☆	☆	☆	☆

☆ Not Used

NOTE 1

: CURRENT NUMBER—FOR PREVIOUS NUMBER, SEE PARTS SUPERSEDECE LIST.


Serviced by the Foot Length.

SNL G-657

FRAME AND BRACKETS—GROUP 15

TIRE CARRIER SUPPORT BRACE AND PARTS—SUB-GROUP 1505

USM-FR-7



YEAR AND ENGINEERING SYMBOL	BODY STYLES	Tire Carrier Support BRACE and STUD Ass'y	Tire Carrier Locking PLATE	Locking Plate Stud NUT	Tire Carrier BRACE	Tire Carrier Support to Frame BOLT	Support to Frame NUT	Support to Frame LOCK-WASH'R	Tire Carrier Support Lock STUD	Tire Carrier to Brace SPACER	Tire Carrier Spacer to Brace SCREW	Tire Carrier Spacer to Brace LOCK-WASH'R
		1 Req'd	1 Req'd	1 Req'd	1 Req'd	4 Req'd	4 Req'd	4 Req'd	1 Req'd	1 Req'd	3 Req'd	3 Req'd
1940—T202	EXPRESS	590862	590849	590867	☆	121615	120369	120382	☆	☆	☆	☆
	CARRY-ALL	☆	590849	590867	☆	☆	☆	☆	☆	☆	☆	☆
1940—T203	SEE NOTE 1—PAGE 253											
1941—T207	EXPRESS	915122	915501	576196	☆	121615	120369	120382	915123	☆	☆	☆
	PANEL—CARRY-ALL	909659	915501	576196	909452	☆	☆	☆	☆	☆	☆	☆
	RECONNAISSANCE & RADIO	☆	915501	576196	☆	☆	☆	☆	☆	☆	☆	☆
1941—T211	EXPRESS	915122	915501	576196	☆	121615	120369	120382	915123	☆	☆	☆
	PANEL—CARRY-ALL	909659	915501	576196	909452	☆	☆	☆	☆	950476	133037	134512
	RECONNAISSANCE & RADIO	☆	915501	576196	☆	☆	☆	☆	☆	☆	☆	☆
1941—T215	EXPRESS	915122	915501	576196	☆	121615	120369	120382	915123	☆	☆	☆
	PANEL/CARRY-ALL/TELE.	950473	915501	576196	909452	☆	☆	☆	☆	950476	☆	☆
	RECONNAISSANCE & RADIO	☆	915501	576196	☆	☆	☆	☆	☆	☆	☆	☆
1941—T112	EXPRESS	SEE NOTE 2	922048	576196	☆	☆	☆	☆	☆	☆	☆	☆
	PANEL/CARRY-ALL/TELE.	922050	922048	576196	909452	☆	☆	☆	☆	☆	133037	134512
1941—T118	TIRE CARRIER NOT A PART OF ORIGINAL EQUIPMENT											
1942—T214	EXC.—AMB./GUN M'T'R CAR. EMERGENCY REPAIR CHASIS—TELE. MAINTENANCE—INST. BODY	925324	915501	576196	☆	660378	120371	120384	915123	☆	☆	☆
1942—T214	TELEPHONE MAINTENANCE INSTALLATION BODY (See Note 3)	Support Assy. 927823	☆	☆	☆	601318	120371	120384	☆	☆	☆	☆
1943—T223	PERSONNEL AND CARGO	925324	915501	576196	☆	660378	120371	120384	915123	☆	☆	☆

NOTE 1

TIRE CARRIER CLAMPING PLATE

PART NO. 922216
Used on Model T112 on Panel, Carry-All and Telephone Body Types

NOTE 2

TIRE CARRIER PARTS PECULIAR TO T112—EXPRESS AND PICKUP

Part No.	Part Name	Part No.	Part Name
1—590229	HANGER Assembly	1—590924	Adjusting NUT
2—103487	RIVET	2—124847	Lock NUT
1—590234	BOLT—Right	1—125158	NUT (Bolt to Frame)
1—590235	BOLT—Left	1—119209	COTTER PIN
		1—589616	STRAP
		4—104113	RIVET

NOTE 3

TIRE CARRIER PARTS PECULIAR TO MODEL T214
TELEPHONE MAINTENANCE—INSTALLATION BODY


Part No.	Part Name
2—577496	Arm Assembly
2—576193	Arm Hinge Bolt
2—125267	Arm Hinge Bolt Nut
2—119209	Arm Hinge Bolt Cotter Pin
2—576194	Arm Hinge Spacer
1—927828	Arm Clamp Bolt—Right
1—927829	Arm Clamp Bolt—Left
2—576196	Arm Clamp Bolt Nut
6—103399	Arm Clamp Bolt Cotter Pin

FRAME AND BRACKETS—GROUP 15

PAGE 295

TIRE CARRIER SUPPORT BRACE AND PARTS—SUB-GROUP 1505

USM-FR-8



YEAR AND ENGINEER- ING SYMBOL	BODY STYLES	Tire Carrier to Brace SCREW	Tire Carrier to Brace Screw LOCK- WASH'R	Tire Carrier Brace to Front Cross Sill BOLT	Tire Carrier Brace to Front Cross Sill NUT	Tire Carrier Brace to Front Cross Sill LOCK- WASH'R	Tire Carrier Brace to Front Cross Sill Plain WASH'R	Tire Carrier Locking Plate WASH'R	Tire Carrier Lock HOUS- ING	Tire Carrier LOCK CYL- INDER AND KEYS	Tire Carrier LOCK CYL- INDER Less Keys	Tire Carrier Lock Cylinder KEY
		3 Req'd	3 Req'd	2 Req'd	2 Req'd	2 Req'd	2 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd
1940—T202	EXPRESS	☆	☆	☆	☆	☆	☆	☆	585872	830038	☆	786659
	CARRY-ALL	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
1940—T203		SEE NOTE 1							588493	830038	☆	786659
1941—T207	EXPRESS	☆	☆	☆	☆	☆	☆	131017	588493	☆	☆	☆
	PANEL—CARRY-ALL	120228	134512	128685	134556	120214	120387	☆	☆	830038	☆	786659
	RECONNAISSANCE & RADIO	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
1941—T211	EXPRESS	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
	PANEL—CARRY-ALL	120228	134512	128685	134556	120214	120387	131017	588493	☆	947081	947079
	RECONNAISSANCE & RADIO	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
1941—T215	EXPRESS	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
	PANEL/CARRY-ALL/TELE.	133837	134512	128685	134556	120214	120387	131017	588493	☆	947081	947079
	RECONNAISSANCE & RADIO	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
1941—T112	EXPRESS	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆
	PANEL/CARRY-ALL/TELE.	120685	134512	128685	134556	120214	120387	131017	588493	☆	947081	947079
1941—T118		TIRE CARRIER NOT A PART OF ORIGINAL EQUIPMENT										
1942—T214	EXC.—AMB./GUN M'T'R CAR.											
	PERSONNEL AND CARGO	☆	☆	☆	☆	☆	☆	131017	924049	☆	947081	947079
1943—T223	EMERGENCY REPAIR											
	CHASSIS	☆	☆	☆	☆	☆	☆	131017	924049	☆	929144	947079

NOTE 1

☆ Not Used

TIRE CARRIER PARTS PECULIAR TO MODEL T203						
No. Req'd	Part No.	Name	No. Req'd	Part No.	Name	
1	598542	TIRE CARRIER BRACKET	1	598547	TIRE CARRIER ARM LATCH	
1	585194	BRACKET Assembly (Includes Stud)	1	122017	LATCH	
6	108684	NUT (Bracket Stud)	1	124824	Stop SCREW	
		RIVET (Bracket to Frame)	1	598548	Lock NUT (Stop Screw)	
1	598564	TIRE CARRIER ARM	1	142521	Latch SHAFT	
2	441145	ARM and STUD Assembly	1	598549	PIN	
2	585192	STUD (for Wheel)	2	121615	BRACKET (Latch Shaft)	
1	441145	NUT	2	120369	BOLT	
		STUD (for Lock)	2	120382	NUT	
1	598546	TIRE CARRIER ARM HINGE BOLT	2	598550	LOCKWASHER	
1	128027	BOLT			Latch SPRING	
1	119209	NUT				
		COTTER PIN				


☆ CURRENT NUMBER—FOR PREVIOUS NUMBER, SEE PARTS SUPERSEDEANCE LIST.

SNL G-657

FRAME AND BRACKETS—GROUP 15

FRAME ASSEMBLY AND PARTS—SUB-GROUP 1506

USM-FR-9




YEAR AND ENGINEERING SYMBOL	BODY STYLES	FRAME Ass'y	FRAME SIDE MEMBER		FRAME Front Support CROSS- MEM'R Ass'y	Frame Cross REIN- FORCE- MENT	FRAME CROSS MEM'R (Transfer Case)
			Right	Left			
			1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd
1940—T202	PICK-UP EXPRESS	599043	599090	599091	598639	:921522	599867
	RECONNAISSANCE	599100	599102	599103	598639	:921522	599867
	RADIO BODY	599101	599104	599105	598639	:921522	599867
	CARRY-ALL/PANEL	912471	912472	912473	598639	:921522	599867
1940—T203	AMBULANCE/CARGO BODY (WITH WINCH)	599029	599030	599031	598967	589194	588671
	CARGO-DUMP BODY (LESS WINCH)	598249	598250	598251	589183	589194	588671
1941—T207	PICK-UP EXPRESS (WITH WINCH)	915264	917026	917027	917317	591439	599867
	PICK-UP-EXPRESS (LESS WINCH)	915263	917024	917025	917318	591439	599867
	RECONNAISSANCE	SEE PAGE 255 FOR THESE PECULIAR PARTS				591439	599867
	RADIO	915701	917034	917035	917318	591439	599867
	CARRY ALL—PANEL	915533	917038	917039	917318	591439	599867
	AMBULANCE	915265	917036	917037	917318	591439	599867
1941—T211	RECONNAISSANCE/PICK-UP/EXPRESS	918062	919030	919031	917318	591439	599867
	RADIO BODY	918816	919032	919033	917318	591439	599867
	CARRY ALL/PANEL	918065	919036	919037	917318	591439	599867
	AMBULANCE	918064	919034	919035	917318	591439	599867
	CLOSED CAB—(NO BODY)	920209	920224	920225	917318	591439	599867
1941—T215	RECONNAISSANCE/PICK-UP/EXPRESS (WITH WINCH)	918063	920714	920715	917317	591439	599867
	RECONNAISSANCE/PICK-UP/EXPRESS (LESS WINCH)	918062	919030	919031	917318	591439	599867
	RADIO	918816	919032	919033	917318	591439	599867
	CARRY-ALL/PANEL/TELEPHONE	918065	919036	919037	917318	591439	599867
	AMBULANCE	921455	921460	921461	917318	591439	599867
	CLOSED CAB (NO BODY)	920209	920224	920225	917318	591439	599867
1941—T112	PICK-UP/EXPRESS (LESS WINCH)	921462	921748	921749	589745	:921522	☆
	CARRY ALL/PANEL	921463	921750	921751	589745	:921522	☆
	CLOSED CAB/TELEPHONE	921464	922376	922377	589745	:921522	☆
1941—T118	CLOSED CAB—CHASSIS { UP TO SERIAL NO. 81334245 AFTER SERIAL NO. 81334245	921465	922000	922001	591024	919784	☆
		925724	926218	926219	591024	919784	☆
1942—T214	WEAPON CARRIER/RECONNAISSANCE (WITH WINCH)	922825	921746	921747	924124	924126	921003
	WEAPON CARRIER/RECON. (L. WIN.)/RADIO BODY	921681	921684	921685	924124	924126	921003
	GUN MOTOR CARRIAGE (WITH WINCH)	925065	925068	925069	924124	924126	921003
	CARRY-ALL	921609	921610	921611	924124	924126	921003
	AMBULANCE	922021	922036	922037	924124	924126	921003
	EMERGENCY REPAIR CHASSIS	927843	927846	927847	924124	924126	921003
	TELEPHONE MAINTENANCE INSTALLATION	927975	927978	927979	924124	924126	921003
1943—T223	PERSONNEL AND CARGO (LESS WINCH)	928222	928312	928313	924124	924126	921003
	PERSONNEL AND CARGO (WITH WINCH)	928223	928316	928317	924124	924126	921003

FRAME AND BRACKETS—GROUP 15

PAGE 297

FRAME BRACKETS—SUB-GROUP 1506

USM-FR-10



Frame Transfer Case
Crossmember GUSSET

Frame
Cross-
member
to Engine
Front
Support
Plate
CLINCH
NUT

Frame
Cross-
member
to
Radiator
Support
Bracket
CLINCH
NUT

Front		Rear			
Right	Left	Right	Left		
1 Req'd	1 Req'd	1 Req'd	1 Req'd	2 Req'd	2 Req'd
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
588672	588673	588673	588672	☆	☆
588672	588673	588673	588672	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
598732	598733	598730	598731	☆	☆
☆	☆	☆	☆	657417	☆
☆	☆	☆	☆	657417	☆
☆	☆	☆	☆	657417	☆
☆	☆	☆	☆	☆	☆
☆	☆	☆	☆	☆	☆
924156	924157	924158	924159	657419	657419
924156	924157	924158	924159	657419	657419
924156	924157	924158	924159	657419	657419
924156	924157	924158	924159	657419	657419
924156	924157	924158	924159	657419	657419
924156	924157	924158	924159	657419	657419
924156	924157	924158	924159	657419	657419
924156	924157	924158	924159	657419	657419
924156	924157	924158	924159	657419	657419
924156	924157	924158	924159	657419	657419
924156	924157	924158	924159	657419	657419
924156	924157	924158	924159	657419	657419

PARTS PECULIAR TO MODEL T207—RECONNAISSANCE

- 1—916528—Frame Assy. (Less Winch) (Up to Serial No. 8651791)
- 1—916529—Frame Assy. (With Winch) (Up to Serial No. 8650566)
Also used from Serial No. 8650871 to 8650917.
- 1—915263—Frame Assy. (Less Winch) (After Serial No. 8651791)
- 1—915264—Frame Assy. (With Winch) (After Serial No. 8650566)
Except from Serial No. 8650871 to 8650917.


- 1—917024 Right SIDE MEMBER (Less Winch)
- 1—917026 Right SIDE MEMBER (With Winch)

- 1—917031—Left SIDEMEMBER (Less Winch) (Up to Serial No. 8651791)
- 1—917033—Left SIDEMEMBER (With Winch) (Up to Serial No. 8650566)
Also used from Serial No. 8650871 to 8650917.
- 1—917025—Left SIDEMEMBER (Less Winch) (After Serial No. 8651791)
- 1—917027—Left SIDEMEMBER (With Winch) (After Serial No. 8650566)
Except from Serial No. 8650871 to 8650917.

- 1—917317—Frame CROSS MEMBER Assy. Front Support (With Winch)
- 1—917318—Frame CROSS MEMBER Assy.—Front Support (Less Winch)

FRAME AND BRACKETS—GROUP 15

CROSSMEMBERS AND PARTS—SUB-GROUP 1506



USM-FR-11


YEAR AND ENGINEER- ING SYMBOL	BODY STYLES	Inter- mediate CROSS- MEM'R Ass'y	Intermediate Crossmember GUSSET		CROSS- MEM'R Assy. (to Rear Spring Front Bracket)	CROSS- MEM'R Ass'y (to Rear Spring Rear Bracket)	Fuel Tank Support CROSS- MEM'R	CROSS- MEM'R Ass'y (Rear)	Rear Crossmember BRACE			
			Front	Rear					Right		Left	
									Upper	Lower	Upper	Lower
A	B	B			C		E		E			
		1 Req'd	As Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	
1940—T202	PICK-UP/EXP./RECON.	☆	☆	☆	589649	598569	598927	598570	598574	598571	598571	598574
	RADIO BODY	☆	☆	☆	589649	598569	598927	598570	598574	598571	598571	598574
	CARRY-ALL	☆	☆	☆	589649	598569	912588	598570	598574	598571	598571	598574
1940—T203	AMBULANCE	☆	☆	☆	574025	562862	☆	598292	☆	☆	☆	☆
	CARGO/DUMP BDY. (L. WIN.)	☆	☆	☆	574025	562862	☆	598292	☆	☆	☆	☆
	CARGO BODY (WITH WINCH)	☆	☆	☆	574025	562862	☆	598292	☆	☆	☆	☆
1941—T207	PICK-UP/EXP./RECON.	☆	☆	☆	916133	598569	598927	916139	598574	916207	598571	916207
	RADIO	☆	☆	☆	916133	598569	598927	916139	598574	916207	598571	916207
	CARRY-ALL—PANEL	☆	☆	☆	916133	598569	598927	916139	598574	916207	598571	916207
	AMBULANCE	☆	☆	☆	916133	598569	598927	916706	598574	598571	598571	598574
1941—T211	PICK-UP/EXP./RECON.	☆	☆	☆	916133	598569	598927	918599	598574	916207	598571	916207
	RADIO	☆	☆	☆	916133	598569	598927	918599	598574	916207	598571	916207
	CARRY-ALL—PANEL	☆	☆	☆	916133	598569	598927	918599	598574	916207	598571	916207
	AMB./CL. CAB (NO BODY)	☆	☆	☆	916133	598569	598927	919839	598574	598571	598571	598574
1941—T215	PICK-UP/EXP./RECON.	☆	☆	☆	916133	598569	598927	918599	598574	916207	598571	916207
	RADIO	☆	☆	☆	916133	598569	598927	918599	598574	916207	598571	916207
	CARRY-ALL/PANEL/TELE.	☆	☆	☆	916133	598569	598927	918599	598574	916207	598571	916207
	AMB./CL. CAB (NO BODY)	☆	☆	☆	916133	598569	598927	919839	598574	598571	598571	598574
1941—T112	PICK-UP EXPRESS	589652	☆	☆	589649	SERV. IN ASSY.	☆	925220	☆	☆	☆	☆
	CARRY-ALL/PANEL/TELE.	589652	☆	☆	589649	589653	☆	918599	☆	☆	☆	☆
1941—T118	UP TO SERIAL NO. 81334245	562092	2 Req'd 548010	548011	574025	562862	☆	☆	☆	☆	☆	☆
	AFTER SERIAL NO. 81334245	562092	548010	548011	574025	562862	☆	598292	☆	☆	☆	☆
1942—T214	WEAPON CAR./RECON.	925551	925552	925553	921342	☆	921024	921339	922830	☆	922830	☆
	RADIO	925551	925552	925553	921342	☆	921024	921339	922830	☆	922830	☆
	CARRY-ALL	925551	925552	925553	921342	924190	921024	925271	922830	☆	922830	☆
	AMBULANCE	☆	☆	☆	921342	924190	921024	921761	598574	598571	927767	598574
	EMERG. REPAIR CHASSIS	☆	☆	☆	921342	☆	921024	928060	☆	☆	☆	☆
	TELE. MAINT. AND INST.	☆	☆	☆	921342	☆	921024	928060	922830	☆	922830	☆
	GUN MOTOR CARRIAGE	☆	☆	☆	921342	☆	921024	921339	922830	☆	922830	☆
1943—T223	PERSONNEL AND CARGO	FRONT 925551	FRONT 925552	FRONT 925553	☆	☆	928417		922830	☆	922830	☆

FRAME AND BRACKETS—GROUP 15

PAGE 299

CROSSMEMBERS AND PARTS—SUB-GROUP 1506

JSM-FR-12



Crossmember Rear BRACKET		Rear Pintle Hook BRACE	Rear Cross- member BRACE	Rear Brace BAR	REINFORCEM'T (Rear Brace Bar)		Pintle Hook Brace	Pintle Hook Brace
Right	Left				Right	Left	Upper	Lower
					D	D		
1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd	1 Req'd
☆	☆	598572	☆	☆	☆	☆	☆	☆
☆	☆	598572	☆	☆	☆	☆	☆	☆
912520	912521	☆	☆	☆	☆	☆	☆	☆
☆	☆	☆	598295	567849	598300	598301	☆	☆
☆	☆	☆	598295	567849	598300	598301	☆	☆
☆	☆	☆	598295	567849	598300	598301	☆	☆
☆	☆	598572	☆	☆	☆	☆	☆	☆
☆	☆	598572	☆	☆	☆	☆	☆	☆
916140	916141	☆	☆	☆	☆	☆	☆	☆
☆	☆	915883	☆	☆	☆	☆	☆	☆
☆	☆	919003	☆	☆	☆	☆	☆	☆
☆	☆	919003	☆	☆	☆	☆	☆	☆
916140	916141	☆	☆	☆	☆	☆	☆	☆
☆	☆	915883	☆	☆	☆	☆	☆	☆
☆	☆	919003	☆	☆	☆	☆	☆	☆
☆	☆	919003	☆	☆	☆	☆	☆	☆
916140	916141	☆	☆	☆	☆	☆	☆	☆
☆	☆	915883	☆	☆	☆	☆	☆	☆
☆	☆	☆	☆	☆	☆	☆	☆	☆
916140	916141	☆	☆	☆	☆	☆	☆	☆
☆	☆	☆	☆	☆	☆	☆	☆	☆
☆	☆	☆	598295	567849	598300	598301	☆	☆
☆	☆	921437	☆	☆	☆	☆	☆	☆
☆	☆	921437	☆	☆	☆	☆	☆	☆
☆	☆	☆	☆	☆	☆	☆	1 Req'd 924275	1 Req'd 924276
☆	☆	921759	☆	☆	☆	☆	☆	☆
☆	☆	☆	☆	☆	☆	☆	☆	☆
☆	☆	☆	☆	☆	☆	☆	Rear 928061	Rear 928211
☆	☆	921437	☆	☆	☆	☆	☆	☆
☆	☆	☆	☆	☆	☆	☆	☆	☆

A

INTERMEDIATE CROSSMEMBER ATTACHING PARTS ALL T214 MODELS EXCEPT EMERGENCY REPAIR CHASSIS, TELEPHONE MAINTENANCE AND INSTALLATION, AMBULANCE MODEL T223

4 Req'd—Part No. 120647—Bolt (Short)
4 Req'd—Part No. 120382—Lockwasher
4 Req'd—Part No. 120369—Nut
6 Req'd—Part No. 120424—Bolt (Long)
6 Req'd—Part No. 120384—Lockwasher
2 Req'd—Part No. 120371—Nut
4 Req'd—Part No. 657419—Clinch Nut

B

INTERMEDIATE CROSSMEMBER GUSSET TO SIDE RAIL ATTACHING PARTS T214 GUN MOTOR CARRIAGE

4 Req'd—Part No. 120424—Bolt
4 Req'd—Part No. 120384—Lockwasher
4 Req'd—Part No. 120371—Nut

B

FRAME FRONT INTERMEDIATE CROSS- MEMBER GUSSET TO CROSSMEMBER ATTACHING PARTS

Model T223
4 Req'd—No. 120424—Screw
4 Req'd—No. 120384—Lockwasher

C

FUEL TANK SUPPORT CROSSMEMBER TO FRAME ATTACHING PARTS T202, T207, T211, T215, T214, T223

4 Req'd—Part No. 120647—Bolt
4 Req'd—Part No. 120382—Lockwasher
4 Req'd—Part No. 120369—Nut

D

CROSSMEMBER REINFORCEMENT BRACE BAR ATTACHING PARTS T203, T118 AFTER SERIAL NO. 81,334,245

6 Req'd—Part No. 1260378—Bolt
6 Req'd—Part No. 120384—Lockwasher
6 Req'd—Part No. 120371—Nut

E

FRAME REAR CROSSMEMBER BRACE ATTACHING PARTS

Model T223
8 Req'd—No. 123572—Bolt
4 Req'd—No. 120370—Nut
4 Req'd—No. 120383—Lockwasher

ALL T214 MODELS EXCEPT AMBULANCE

2 Req'd—Part No. 921403—Reinforcement
(Rear Axle Bumper)

BODY OUTRIGGER PARTS T214 AMBULANCE

1 Req'd—Part No. 922554—Bracket—Right
1 Req'd—Part No. 922555—Bracket—Left
4 Req'd—Part No. 123567—Bolt
4 Req'd—Part No. 120383—Lockwasher
4 Req'd—Part No. 120370—Nut

FRAME REAR AXLE BUMPER REINFORCEMENT

Specify 4 Req'd—No. 928272—Reinforcement
Model T223

FRAME AND BRACKETS—GROUP 15**CROSSMEMBERS AND PARTS—SUB-GROUP 1506****PARTS PECULIAR TO MODEL T223 (6x6)**

NO.	PART REQ'D	NO.	PART NAME
1	929331		Frame Rear CROSSMEMBER (Front)
1	929336		Frame Rear CROSSMEMBER (Rear)
1	929332		Frame Rear Crossmember REINFORCEMENT
1	928239		Frame Intermediate CROSSMEMBER
1	928240		Frame Intermediate Crossmember GUSSET
1	928252		Frame Trunnion Bracket CROSSMEMBER (Front)
1	928251		Frame Trunnion Bracket CROSSMEMBER (Rear)
1	928253		Frame Trunnion Bracket Crossmember REINFORCEMENT (Upper)
1	928254		Frame Trunnion Bracket Crossmember REINFORCEMENT (Lower)
2	928255		Frame Trunnion Bracket Crossmember GUSSET (Upper)
2	928256		Frame Trunnion Bracket Crossmember GUSSET (Lower)